


VMS4200-x / 5200-x MID

Track and trace system

SICK
Sensor Intelligence.



Described product VMS4200-x / 5200-x MID

Document no. 8026366

Manufacturer SICK AG
Erwin-Sick-Str. 1 · 79183 Waldkirch · Germany
www.sick.com

Legal notes This work is protected by copyright. The associated rights are reserved by SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal provisions of copyright law. Any modification, abridgment, or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks mentioned in this document are the property of their respective owners.

© SICK. All rights reserved

Original documents This document is an original document from SICK AG.

Content

1	About this document.....	6
1.1	Limitation of liability.....	6
1.2	Purpose of this document.....	6
1.3	Target groups.....	6
1.4	Further information.....	7
1.5	Other relevant technical documentation/information	7
1.6	Document conventions.....	7
2	For your safety.....	8
2.1	Intended use.....	8
2.2	General safety notes.....	9
2.3	Requirements for the qualification of personnel	9
2.4	Sources of danger.....	10
2.5	Protective devices.....	10
2.6	System warranty.....	10
2.7	RoHS Directive.....	11
2.8	Safety conventions	11
2.9	Warning symbols on the system components	12
2.10	Mandatory symbols.....	12
3	System description.....	13
3.1	Scope of delivery.....	13
3.2	System components	14
3.2.1	LMS4x21 LiDAR sensors.....	16
3.2.2	Photoelectric sensor array	17
3.2.3	Object detection photoelectric sensor (optional)	19
3.2.4	Cabinet.....	20
3.2.5	Cross belt conveyor elements	21
3.2.6	Expanding the system with a reading station.....	23
3.3	VMS4200-x / 5200-x MID without object detection	24
3.3.1	Measurement principle	24
3.3.2	Transport conditions for single cross belt sorters	26
3.3.3	Transport conditions for double belt sorters	27
3.4	VMS4200-x / 5200-x MID with object detection (optional)	29
3.4.1	How object detection works	29
3.4.2	Overhang tolerance for single belt systems	32
3.4.3	Overhang tolerance for double belt systems.....	34
3.5	Recording of measured values and data processing.....	37
3.6	Data output.....	38
3.7	Additional functions.....	40
3.8	Nominal operating conditions.....	41
3.9	Legal for trade operation	46
3.9.1	Information labels	46
3.9.2	Security seal.....	54
3.9.3	Alibi memory and firmware	61
3.9.4	LFT display	64
3.9.5	Test instructions for market surveillance	67
3.10	System requirements for legal for trade operation.....	71
3.10.1	Requirements on the ambient conditions.....	71
3.10.2	Requirements on the conveying equipment.....	71
3.10.3	Mounting requirements.....	73

- 3.10.4 Object requirements 76
- 4 Mounting 78**
 - 4.1 Mounting the LiDAR sensors 78
 - 4.1.1 Overview 78
 - 4.1.2 Assembling profiles of the telescopic tube 79
 - 4.1.3 Mounting the telescopic tube on the frame 80
 - 4.1.4 Fastening the LiDAR sensors to the mounting plates 80
 - 4.2 Mounting the photoelectric sensor array 81
 - 4.3 Mounting the object detection photoelectric sensor (optional) 82
 - 4.4 Mounting the cabinet 83
- 5 Electrical installation 84**
 - 5.1 Connection overview 85
 - 5.2 Connecting the voltage supply 86
 - 5.3 Connection for LFT Ethernet switch (set up at the factory) 87
 - 5.4 Connection for the LiDAR sensors 88
 - 5.5 Connection for the LFT display (set up at the factory) 90
 - 5.6 Connection for the photoelectric sensor array 91
 - 5.7 Connection for the cross-belt signal 92
 - 5.8 Connection for the object detection photoelectric sensor (optional) . 93
 - 5.9 Connecting the customer interface 94
- 6 Commissioning 95**
 - 6.1 Switching on the system 95
 - 6.2 Configuring the system with SOPAS 96
 - 6.2.1 Installing SOPAS ET 96
 - 6.2.2 Installing SOPAS 97
 - 6.2.3 Assigning IP addresses 98
 - 6.2.4 Opening the configuration interface 104
 - 6.2.5 Logging on to device 105
 - 6.2.6 Saving the parameters permanently 106
- 7 Maintenance and repair 107**
 - 7.1 Monitoring and cleaning work 108
 - 7.1.1 Control measurements 108
 - 7.1.2 Visual inspection 108
 - 7.1.3 Cleaning the LiDAR sensors 109
 - 7.1.4 Cleaning the deflector mirror 110
 - 7.1.5 Cleaning the photoelectric sensors 111
 - 7.1.6 Cleaning the cabinet 111
 - 7.2 Replacing components 112
 - 7.2.1 Replacing the LiDAR sensor 112
 - 7.2.2 Replacing the deflector mirror 114
 - 7.2.3 Replacing photoelectric sensor array components 115
 - 7.2.4 Replacing the object detection photoelectric sensor 116
 - 7.2.5 Replacing the battery in the SIM2000-2 Prime controller . 117
- 8 Fault diagnosis 118**
 - 8.1 Fault indications of the components 118
 - 8.1.1 Fault indication on the LMS4x21 118
 - 8.1.2 SIM2000 fault indication 119
 - 8.1.3 Fault indication on the object detection photoelectric sensor
..... 120

8.1.4	Fault indication on the photoelectric sensor array.....	121
8.2	Detailed fault analysis	122
9	Technical data	123
9.1	Data sheet	123
9.2	Dimensional drawings	125
9.2.1	Dimensional drawings for the LiDAR sensor	125
9.2.2	Dimensional drawings for the cabinet.....	126
9.3	Compliance with EU directives.....	127
10	Disposal	128

1 ABOUT THIS DOCUMENT

1 About this document

These supplementary operating instructions on the VMS4200-x/ 5200-x MID multi-dimensional measurement system:

- Contain information that is required during the life cycle of the system.
- Must be available to all those who work with the system.
- Should be read through carefully, and the contents fully understood before working with the system.

1.1 Limitation of liability

Applicable standards and regulations, the latest technological developments, and our many years of knowledge and experience have all been taken into account when assembling the data and information contained in this document.

The manufacturer accepts no liability for damage caused by:

- Failure to observe this document.
- Non-compliance with notes and regulations.
- Unauthorized mounting and installation.
- Unauthorized technical and other changes.
- Use of unauthorized spare parts, wear and tear parts, and accessories.
- Unauthorized changes, adjustments, and/or manipulations of software.
- Failure to perform and document regular maintenance work.

The actual scope of delivery may differ from the features and illustrations shown here where special variants are involved, if optional extras have been ordered, or as a result of the latest technical changes.

1.2 Purpose of this document

This document describes the VMS4200-x/5200-x MID multi-dimensional measurement system with an SIM200-2 Prime controller.



The supplementary operating instructions for the VMS4200-x/5200-x MID with a SIM2000-2 Prime Controller are only valid in conjunction with the main operating instructions for the VMS4200-x/VMS5200-x MID (*Multicontroller*) (8024627 DE / 8024628 EN).

Unless otherwise specified in this document, the information in the main operating instructions for the VMS4200-x/VMS5200-x MID (*Multicontroller*) will apply.

1.3 Target groups

This document is intended for qualified persons who operate the VMS4200-x / 5200-x MID.

1.4 Further information

Special local conditions

The local laws, regulations, technical rules and internal company operating instructions at the installation location must be observed.

Storage of documents

This document and other relevant technical documentation/information:

- Must be kept available for reference.
- Must be handed over to new system operators/new specialist personnel.

1.5 Other relevant technical documentation/information

- Technical system documentation
 - E300817 A (EPLAN)
 - Technical data
 - Connection diagram
 - Terminal diagram
- Operating instructions for the following system components:

Component	Manufacturer
LMS4000 2D LiDAR sensor operating instructions	SICK
SIM2000-2 Prime Sensor Integration Machine operating instructions	SICK
Operating instructions for TTC100-2 track and trace cabinet in combination with SIM2000-2 Prime	SICK

1.6 Document conventions

- ▶ Instructions
- ✓ Result of action

- All measurement units used in this document are metric.
- Subject to change without notice.
- Figures may differ from the actual design.

2 For your safety

2.1 Intended use

The VMS4200-x / 5200-x MID multi-dimensional measurement system is used to measure cubic and irregularly shaped objects on cross-belt sorting systems. The objects to be measured must be dimensionally stable, opaque, and non-reflective.

The cross-belt conveyor system can be designed as a conventional single cross belt sorter or as a double belt sorter (see also the explanations in section [3.2.5 Cross belt conveyor elements](#) on page 21 f.). The two LMS4x21 LiDAR sensors are mounted horizontally above the cross belt sorter and, just like the VMS4200/5200 MID, typically rotated at an angle of 45°. All components have been configured for use on cross-belt sorting systems.

The VMS4200-x / 5200-x MID determines the length, width and height. These dimensional values can be used to calculate the volume of the smallest rectangular box that fully encloses the object.

The measurement results can be transferred to the customer network via the data interface of the SIM2000-2 Prime controller.

Using the optional object detection photoelectric sensor, it is also possible to measure overhanging cubic objects.

The VMS5200-x MID multi-dimensional measurement system can be verified as legal for trade and, after a successful MID conformity assessment, used for billing purposes.

NOTE! Intended use also includes observance of this system description, in particular the safety notes and repair and maintenance requirements as well as proper installation, in particular for billing operation.

2.2 General safety notes

- ▶ Please read this document through carefully and observe all the safety notes and information before working on the multi-dimensional measurement system.
- ▶ Only qualified persons from the relevant departments are permitted to work on the multi-dimensional measurement system.
- ▶ Follow operating processes.
- ▶ Follow local regulations.
- ▶ Follow all local regulations relating to working with electrical components.
- Only authorized persons are permitted access to the multi-dimensional measurement system.

System damage/transport damage

Damage to the individual components can lead to malfunctions of the system as a whole.

- ▶ Do not ignore any damage caused to system components during transport.
- ▶ In case of damage, contact SICK Service.

2.3 Requirements for the qualification of personnel

Only qualified persons with the relevant technical expertise are permitted to work on the system.

- Qualified persons have the specialist training, skills, and experience, as well as knowledge of the relevant regulations and standards, to be able to perform work assigned to them and to identify and avoid any potential dangers independently.
- Electricians have the professional training, skills and experience, and knowledge of the relevant standards and provisions to work on electrical systems and to detect and avoid any potential dangers independently.

2.4 Sources of danger

Optical radiation:

Laser class 2

The 2D LiDAR sensors of the VMS4200-x/5200-x MID use a class 2 laser.

The human eye is not at risk when briefly exposed to the radiation for up to 0.25 seconds. Exposure to the laser beam for longer periods of time may cause damage to the retina. The laser radiation is harmless to human skin.

- ▶ Never look directly into the laser beam.
- ▶ Never point the laser beam at people's eyes.
- ▶ During commissioning or maintenance work, suitable eye protection must be worn.
- ▶ Avoid laser beam reflection caused by reflective surfaces. In particular during mounting and alignment work.
- ▶ Do not open the housing.
- ▶ Current national regulations regarding laser protection must be observed.

Electrical voltage

Touching live devices, which may still be energized, can lead to death, burns or electrical shock.

- ▶ Electrical work may only be performed on the system by qualified specialist personnel.
- ▶ Before working on electrical components, observe the five safety rules:
 - ▶ Disconnect.
 - ▶ Secure against being switched back on.
 - ▶ Ensure that there is no voltage.
 - ▶ Ground and short-circuit.
 - ▶ Cover or enclose live parts in the vicinity.

Suspended loads

- ▶ Never enter the area under suspended loads.
- ▶ Pay close attention when lifting loads.
- ▶ Comply with lifting instructions to prevent injuries and accidents.
- ▶ Use suitable, undamaged lifting tools.
- ▶ Wear personal protective equipment (safety helmet, safety shoes).

2.5 Protective devices

The multi-dimensional measurement system is designed in a way that allows for safe operation. Protective devices reduce potential risks to the maximum possible extent.

- Laser protective cover for the LMS4x21 LiDAR sensor

2.6 System warranty

No warranty claims will be accepted if:

- ▶ The safety notes and measures in this document are not observed.
- ▶ Parts or components of the multi-dimensional measurement system have been installed, mounted or modified without authorization.
- ▶ The multi-dimensional measurement system has been altered or modified.
- ▶ The software has been modified, customized, and/or tampered with without authorization.

2.7 RoHS Directive

This product has been designed for specific applications in large industrial systems according to Article 2 (4) e, RoHS 2011/65 / EU, and must therefore only be used in such systems.

The product is neither suitable nor approved for use outside of these systems. SICK therefore cannot provide any warranty or accept any liability whatsoever for such use.

2.8 Safety conventions

The warnings used in this manual have the following meanings:

 **DANGER**

Identifies an imminent danger, which will lead to death or serious injuries if not prevented.

 **WARNING**

Identifies a situation presenting danger, which will lead to death or serious injuries if not prevented.

 **CAUTION**





Identifies a possibly hazardous situation which may lead to minor or moderate bodily injuries or material damage if not prevented.

NOTE





Important information and useful notes.

2.9 Warning symbols on the system components

Warning labels must not be removed or covered up. If labels are missing, these must be affixed. Damaged labels must be replaced.

Symbol	Meaning
	Hazardous point warning
	Hazardous electrical voltage warning
	Laser beam warning
	Suspended load warning

2.10 Mandatory symbols

Symbol	Meaning
	Read document
	Use head protection
	Use foot protection
	Disconnect before maintenance or repairs

3 System description

3.1 Scope of delivery

NOTE!

- ▶ After delivery, inspect the system for transport damage and report any such damage immediately.
- ▶ Check that the delivery includes all components listed on the delivery note.

System components

- 2 LMS4421R-16000 2D LiDAR sensors with laser protective cover for the VMS4200-x MID or
2 LMS4521R-16000 2D LiDAR sensors with laser protective cover for the VMS5200-x MID
- 1 modular mounting set
- 1 LFT display - VMS5200-x MID only
- 1 TTC100-2 cabinet with a SIM2000-2 Prime controller, power supply unit modules and LFT Ethernet switch
- 1 photoelectric sensor array consisting of 4 WL100L photoelectric sensors (or functionally compatible)
- 2 beam blockers
- Connecting cables

Optional

- 1 photoelectric retro-reflective sensor (e.g. RAY26) for object detection.
- 1 deflector mirror for reducing the mounting height of the 2D LiDAR sensors

NOTE

**These operating instructions use the product name of the controller: SIM2000-Prime.
The device name is SIM2000ST-E.**

3 SYSTEM DESCRIPTION

3.2 System components

Devices




Fig. 1: Components of the VMS4200-x / 5200-x MID

Legend

- | | |
|---|---|
| 1 | LMS4x21 LiDAR sensor with laser protective cover |
| 2 | LFT display - VMS5200-x MID only |
| 3 | Photoelectric sensor array consisting of 4 photoelectric retro-reflective sensors for speed detection, e.g. WL100L or functionally compatible |
| 4 | Cross-belt signal |
| 5 | Object detection photoelectric sensor for object detection (optional) |
| 6 | Cabinet with a SIM2000-2 Prime controller and power supply unit(s) |

Mounting

- Mount the system components according to the technical drawing on a frame provided by the customer.
- Additional glare protection on the frame (beam blocker) prevents objects located outside of the measuring range from being included in the calculation of measured values.

System variant with deflector mirror




Fig. 2: VMS4200-x/ 5200-x MID with deflector mirror

Legend

- | | |
|---|--|
| 1 | LMS4x21 2D LiDAR sensors with laser protective cover |
| 2 | Deflector mirror |

- If the 2D LiDAR sensors cannot be mounted at the prescribed minimum height, the measurement points can be captured by a deflector mirror mounted parallel to the 2D LiDAR sensors.
- The resulting extension of the light path means that you can save space when mounting the 2D LiDAR sensor on the conveying equipment.
- The deflection via the mirror is free of loss thanks to its special surface metallization, as this rules out light refraction.
- The upper figure shows a visualization example of the arrangement of the 2D LiDAR sensors and the deflector mirror over the transport belt.
- The remaining system setup and operating principle of the VMS4200-x/ 5200-x MID satisfy the requirements for the relevant type approval certificate.

NOTE! These supplementary operating instructions describe system variant without deflector mirror.

3 SYSTEM DESCRIPTION

3.2.1 LMS4x21 LiDAR sensors




Fig. 3: LMS4x21 LiDAR sensors with LFT display - VMS5200-x MID only

Legend

- | | |
|---|---|
| 1 | LMS4x21 LiDAR sensor |
| 2 | Laser protective cover |
| 3 | LFT display for billing-capable VMS5200-x MID measurement systems |

Features

- Consists of two LMS4x21 LiDAR sensors with laser protective covers that are mounted on a profile and located on the right and left above the cross-belt conveyor.
- The LMS4x21 LiDAR sensors are configured as master and slave.

Function

- Used to determine the relevant object dimensions by contactlessly detecting objects on single cross belt sorters or double belt sorters.

LFT display

- VMS5200-x MID measurement systems operating in legal for trade applications also have a separate LFT display to show the measurement results, status information, firmware version, and the logbook (version history).

3.2.2 Photoelectric sensor array

The photoelectric sensor array is used to determine the conveyor speed in single cross belt sorters or double belt sorters.




Fig. 4: Photoelectric sensor array

Legend

- | | |
|---|---|
| 1 | WL100L photoelectric retro-reflective sensor (or functionally compatible) |
| 2 | Reflector |
-

Features

- Optical photoelectric sensor array consisting of four photoelectric sensors with reflector.
- Used in place of a rotary measuring wheel encoder since the conveyor belt is divided into individual cross-belt conveyor elements.

3 SYSTEM DESCRIPTION




Fig. 5: Determining speeds with the photoelectric sensor array

Legend

- 1 Photoelectric sensor array
 - 1a Photoelectric sensor signal
 - 2 Master
 - 3 SIM2000-2 Prime controller
 - 3a Transfer of speed and increment data
-

- The feed speed of the conveyor belt is detected by the photoelectric sensor array like a measuring wheel encoder.
- To that end, the SIM2000-2 Prime controller determines the times at which the photoelectric sensors were passed when a transport unit passes through.
- The speed of the transport unit can be calculated together with the parameterized distances between the individual photoelectric sensors.
- These speed values are then used to calculate the increment required to determine the object's position on the conveying equipment (referred to as "tracking").

3.2.3 Object detection photoelectric sensor (optional)




Fig. 6: Object detection photoelectric sensor and reflector

Legend

- | | |
|---|---------------------------------------|
| 1 | Object detection photoelectric sensor |
| 2 | Reflector |

Features

- The light band emitted by the object detection photoelectric sensor is reflected back by a reflector.
- Sender and receiver are arranged parallel to one another in the housing.

Function




Fig. 7: Object trigger and cross-belt signal

Legend

- | | |
|---|---|
| 1 | Cross belt signal: trigger signal relating to the leading edge of the carrier. |
| 2 | Object trigger: is triggered when the leading edge of the object passes through the photoelectric sensor. |

- Object is detected as it passes through the object detection photoelectric sensor.
- The object detection photoelectric sensor, together with the cross belt signal, determines the position of the object on the belt segment in the conveying direction.
- The position of the object is required to detect the presence of overhangs.

3 SYSTEM DESCRIPTION

3.2.4 Cabinet




Fig. 8: Cabinet for the VMS4200-x/5200-x MID

Legend

- 1 Air inlet for cooling (with filter mat and cooler)
- 2 Terminals for voltage supply IN (100–264 V AC / 50–60 Hz)
- 3 SIM2000-2 Prime controller with alibi memory
- 4 RCD (residual current device) for protective contact plug
- 5 Circuit breaker
- 6 Power supply unit for supplying voltage to the SIM2000-2 Prime controller and 2D LiDAR sensors
- 7 Air outlet for cooling (with filter mat)
- 8 Air outlet for cooling (with filter mat)
- 9 Circuit breaker
- 10 Terminals (24 V DC) and fuse module OUT
- 11 LFT Ethernet switch for connecting the LFT components
- 12 Ethernet switches for connecting additional sensors
- 13 Air inlet for cooling (with filter mat and fan)

Properties

- Contains power supply units for the central voltage supply to system components.
- Contains the SIM2000-2 Prime controller, the central processing unit, and the control unit of the VMS4200-x / 5200-x MID.
- The SIM2000-2 Prime controller contains the legally relevant memory (alibi memory).

Function

- Central voltage supply for all system components.
- Coordinates all connected sensors and processes the measured values received.
- The SIM2000-2 Prime controller uses the signals from the photoelectric sensor array to calculate the incremental signal for position determination. The signals are transmitted to the LMS4x21 master.
- The SIM2000-2 Prime controller receives the measuring points from the LiDAR sensors and uses the 2D sections to calculate a three-dimensional model.
- Determines the box volume and dimensional values based on the calculated 3D model.
- The data is sent to the higher-level customer system via the SIM200-2 Prime controller in a host telegram with a defined format.

NOTE! In the case of the VMS5200-x MID, the measurement results are saved in the SIM2000-2 Prime controller alibi memory, which is required for legal-for-trade verification.

3.2.5 Cross belt conveyor elements

Single cross belt sorter




Fig. 9: Single cross belt sorter with cross-belt conveyor elements

Legend

- | | |
|---|-----------------------------|
| 1 | Carrier |
| 2 | Cross-belt conveyor element |
| 3 | Transported item |
-

- The conveyor belt is divided into individual cross-belt conveyor elements that are mounted on a carrier.
- Similar to a conventional conveyor belt, the individual cross-belt conveyor elements are moved in a contiguous line in the conveying direction.
- The cross-belt conveyor elements can also be loaded and unloaded perpendicularly to the conveying direction via their integrated conveyors.
- Loads are loaded onto cross-belt conveyor elements by coordinated placement on the individual carrier units.

3 SYSTEM DESCRIPTION

Double belt sorter




Fig. 10: Double belt sorter (singulated mode / synchronized mode)

Legend

- 1 Singulated mode on a double belt carrier
 - 2 Synchronized mode on a double belt carrier
-

- Each transport element on a double belt sorter consists of two cross-belt conveyor elements that are mounted on the carrier.
- The two cross-belt conveyor elements are separated by a belt gap.
- The two cross-belt conveyor elements mounted on each carrier can be operated either in singulated (one object per cross-belt conveyor element) or synchronized (one object occupies both cross-belt conveyor elements of a double belt carrier) mode.
- This means that small objects can be transported on single cross-belt conveyor elements, while larger objects can be transported across two cross-belt conveyor elements.
- This can significantly increase the throughput of the system.

NOTE! When transporting objects in synchronized mode on a double belt carrier, the restrictions on the minimum object size and accuracy need to be taken into consideration (see section [3.8 Nominal operating conditions](#)).

3.2.6 Expanding the system with a reading station




Fig.11: Expanding the system with a reading station

Legend

- | | |
|---|------------------------|
| 1 | VMS4200-x / 5200-x MID |
| 2 | Reading systems |
| 3 | CAN bus |

Properties

- Expansion of the VMS4200-x / 5200-x MID multi-dimensional measurement system with a reading station.
- Depending on the application, this station can consist of scanners, cameras, application-specific trigger elements and/or a combination of these components in any desired arrangement.

Function

- Allows automated object identification using bar codes.
- Streamlines process automation.

NOTE! The multi-dimensional measurement system can also supply the focus information for the connected camera systems.

Connection

- The devices are connected to the multi-dimensional measurement system via the CAN bus of the SIM2000-2 Prime controller.
- The SIM2000-2 Prime controller links the acquired identification data with the dimension values calculated by the VMS4200-x/5200-x MID.
- Identification data and dimension values are output together to the higher-level system.

3 SYSTEM DESCRIPTION

3.3 VMS4200-x / 5200-x MID without object detection

The VMS4200-x / 5200-x MID multi-dimensional measurement system measures cubic and irregularly shaped objects that are linearly moved past the measuring station on single cross belt sorters or double belt sorters.

3.3.1 Measurement principle




Fig. 12: Measurement principle

Legend

- | | |
|---|------------------|
| 1 | Measurement site |
| 2 | Scanning line |
-

- The objects are always measured **separately**.
- Only **one object** can be in the **measuring range** at any given time.

NOTE! The objects must be located fully on the cross-belt conveyor element. The measuring field is limited to the cross-belt conveyor element.

The VMS4200-x / 5200-x MID will otherwise deliver invalid measurement results. In the case of the VMS5200-x MID, these are designated as NON-LFT.

**Triggering of
recording of
measured values
without object
detection**




Fig. 13: Triggering of recording of measured values

Legend

- | | |
|---|---|
| 1 | Cross-belt signal |
| 2 | Leading edge of the carrier |
| 3 | Reading interval |
| 4 | No signal when the cross-belt conveyor element is empty |

- In the system variant without object detection, the measurement process is activated by the cross-belt signal. The customer transmits a signal for the leading edge of the carrier to the SIM2000-2 Prime controller.
- The cross-belt signal is only activated if the cross-belt conveyor element is occupied. No signal is delivered for cross-belt conveyor elements that are empty.
- The cross-belt signal activates the LiDAR sensors and opens the internal reading interval.
- The reading gate determines the start and end of the measuring process. It corresponds to the trigger length in the conveying direction.
- The measuring process lasts for as long as the reading gate is open, regardless of whether the object is entering or leaving the scanning line.

Object tracking

- The system increment is determined by evaluating the incremental signals of the photoelectric sensor array. This can then be used to establish the exact position of the object on the conveyor relative to the cross-belt signal (see item 1 in the above figure).
- This information is required to calculate the length information and for correct assignment of the measurement results to the object.

3 SYSTEM DESCRIPTION

3.3.2 Transport conditions for single cross belt sorters




Fig. 14: Singulated mode on a transport unit with one cross-belt conveyor element

- Each object to be measured is transported on exactly one cross-belt conveyor element.
 - The VMS4200-x / 5200-x MID is informed that a cross-belt conveyor element is occupied via a suitable cross-belt signal.
- NOTE!** It is not permitted for multiple objects to be present on the same cross-belt conveyor element.
- The maximum measurement accuracy for cubic and irregularly shaped objects is: 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

3.3.3 Transport conditions for double belt sorters

Double belt sorters support three operating modes:

Double-belt systems (singulated mode)




Fig. 15: Singulated mode on a transport unit with two cross-belt conveyor elements

- In the permanently enabled singulated mode, the object to be measured is transported on exactly one cross-belt conveyor element.
- The two cross belts can be controlled independently.
- Only one object is permitted on a cross-belt conveyor element at any given time.
- The VMS4200-x / 5200-x MID is informed that the two cross-belt conveyor elements of a carrier are occupied by means of two short signals.
- Singulated mode allows a measurement accuracy for cubic and irregularly shaped objects of 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Double-belt systems (synchronized mode)




Fig. 16: Synchronized mode on a transport unit with two cross-belt conveyor elements

- In the permanently enabled synchronized mode, the object to be measured is positioned on both cross-belt conveyor elements such that it covers the belt gap.
- Both conveyor elements are operated in sync with one another.
- Only one object is allowed to be present on the double-belt carrier at any given time.
- The VMS4200-x / 5200-x MID is informed that the two cross-belt conveyor elements of a carrier are occupied by means of a long signal.
- Synchronized mode allows a measurement accuracy for cubic and irregularly shaped objects of 10 mm x 10 mm x 10 mm (0.4" x 0.4" x 0.4").

3 SYSTEM DESCRIPTION

Double-belt systems with dynamic presence detection




Fig. 17: Dynamic presence detection on double-belt conveyor systems

- Dynamic presence detection is the alternative to the permanently enable singulated mode or synchronized mode.
- The same transport conditions apply as for singulated and synchronized mode.
- A short signal identifies that an object is present on one cross-belt conveyor element.
- A long signal indicates that an object is present across both cross-belt conveyor elements of the transport element.
- If there is no signal, then the transport unit is empty.
- Depending on how the transport unit is occupied, the measurement accuracy of the VMS4200-x / 5200-x MID dynamically switches between singulated mode (5 mm x 5 mm x 5 mm / 0.2" x 0.2" x 0.2") and synchronized mode (10 mm x 10 mm x 10 mm / 0.4" x 0.4" x 0.4")
- This switching is implemented by linking the cross-belt signal with the signals from the photoelectric sensors connected to the SIM2000-2 Prime controller.
- In billing-related operation, the measurement accuracy selected for a specific measurement is stored in the alibi memory together with the measured value.

3.4 VMS4200-x / 5200-x MID with object detection (optional)

In the system variant with additional object detection, the VMS4200-x / 5200-x MID multi-dimensional measurement system also takes overhanging cubic objects into account. This requires an additional object detection photoelectric sensor.

Objects projecting beyond the edge of the belt are detected by comparing the object trigger with the cross-belt signal.

3.4.1 How object detection works

Allowed object overhang




Fig. 18: Allowed overhangs

Legend

- | | |
|---|---|
| 1 | Allowed overhang of <u>cubic</u> objects |
| 2 | Not allowed: Overhang of irregularly shaped objects |
| 3 | Not allowed: The center of gravity of a cubic object lies outside the cross-belt conveyor element |

- In the system variant with object detection, cubic elements overhanging any of the four sides of the belt by typically 100 mm are taken into account.
- To accommodate this, the measuring field is extended beyond the limits of the cross-belt conveyor element.
- The center of gravity of the object must lie on the cross-belt conveyor element.
- Overhanging irregularly shaped objects are not permitted.

NOTE! The VMS4200-x / 5200-x MID will otherwise deliver invalid measurement results. In the case of the VMS5200-x MID, these are designated as NON-LFT.

Principle of object detection




Fig. 19: Principle of object detection

Legend

- | | |
|---|---------------------------------------|
| 1 | Object detection photoelectric sensor |
| 2 | Cross-belt signal |
| 3 | Object trigger signal |
-

- Overhanging objects are detected with the help of an additionally mounted object detection photoelectric sensor.
- The object detection photoelectric sensor detects the leading edge of the object located on the cross-belt conveyor element and sends a suitable trigger signal to the control unit.
- The exact position of the object on the cross-belt conveyor element is then calculated based on the relative timing of the object trigger and cross-belt signal.

**Triggering of recording
of measured values
with object detection**




Fig. 20: Triggering of recording of measured values for systems with object detection

Legend

- | | |
|---|---|
| A | Cross-belt signal |
| B | Object trigger signal |
| C | Reading interval |
| 1 | Reading interval is opened by the object trigger and closed by the cross-belt signal. |
| 2 | Reading interval is opened by the cross-belt signal and closed by the object signal. |
| 3 | Reading interval is opened and closed by the object trigger. |
| 4 | Reading interval is opened and closed by the cross-belt signal. |

- Just like for the system variant without object detection, the reading interval determines the start and end of the measuring process.
- Depending on the position of the object on the cross-belt conveyor element, it is jointly determined from the object trigger and cross-belt signal.

3 SYSTEM DESCRIPTION

3.4.2 Overhang tolerance for single belt systems

Example 1




Fig. 21: Example 1 of overhang calculation for single belt systems

- All objects are located within the measuring range for the overhang calculation.
- The measurement accuracy for all cubic and irregularly shaped objects in this example is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Example 2




Fig. 22: Example 2 of overhang calculation for single belt systems

- Object 2 is projecting into the measuring range of object 3 and is therefore outside the measuring range.
- Two objects are detected in the measuring range of object 3.
- Object 2 and object 3 deliver invalid measurement results.
- The measurement accuracy of the other objects is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Example 3




Fig. 23: Example 3 of overhang calculation for single belt systems

- No gap is detected between object 2 and object 3. The two objects are detected as one object.
- Object 2 and object 3 deliver invalid measurement results.
- The measurement accuracy of the other objects is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Example 4




Fig. 24: Example 4 of overhang calculation for single belt systems

- The irregularly shaped objects 2, 3 and 4 deliver invalid measurement results due to the overhang.
- The measurement accuracy for the irregularly shaped object 1 located fully on the cross-belt conveyor element is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

3 SYSTEM DESCRIPTION

3.4.3 Overhang tolerance for double belt systems

Example 1 (singulated mode)




Fig. 25: Example 1 of overhang calculation for double belt systems (singulated mode)

- All objects are located within the measuring range for the overhang calculation.
- The measurement accuracy for all cubic and irregularly shaped objects in this example is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Example 2 (singulated mode)




Fig. 26: Example 2 of overhang calculation for double belt systems (singulated mode)

- The irregularly shaped object 1 delivers invalid measurement results due to the overhang.
- Object 4 is projecting into the measuring range of object 3. Two objects are detected in the measuring range of object 3. Object 3 and object 4 deliver invalid measurement results.
- No gap is detected between object 7 and object 8. The two objects are detected as one object. Object 7 and object 8 deliver invalid measurement results.
- The measurement accuracy of the other objects is 5 mm x 5 mm x 5 mm (0.2" x 0.2" x 0.2").

Example 3
(synchronized mode)




Fig. 27: Example 3 of overhang calculation for double belt systems (synchronized mode)

- All objects are located within the measuring range for the overhang calculation.
- The measurement accuracy for all cubic and irregularly shaped objects is 10 mm x 10 mm x 10 mm (0.4" x 0.4" x 0.4").

Example 4
(synchronized mode)




Fig. 28: Example 4 of overhang calculation for double belt systems (synchronized mode)

- Object 1 is projecting into the measuring range of object 2.
Two objects are detected in the measuring range of object 2. Object 1 and object 2 deliver invalid measurement results.
- No gap is detected between object 3 and object 4.
The two objects are detected as one object. Object 3 and object 4 deliver invalid measurement results.

3 SYSTEM DESCRIPTION

Example 5 (synchronized mode)




Fig. 29: Example 5 of overhang calculation for double belt systems (synchronized mode)

- The irregularly shaped objects 2 and 3 deliver invalid measurement results due to the overhang.
- The measurement accuracy of the other objects is 10 mm x 10 mm x 10 mm (0.4" x 0.4" x 0.4").

3.5 Recording of measured values and data processing




Fig. 30: Measuring point determination of the VMS4200-x / 5200-x MID

- The measurement process is activated by the cross-belt signal.
- The two LiDAR sensors span a two-dimensional measuring range and perform a non-contact scan of the surface of the object on the cross belt conveying equipment.
- They cyclically transmit the detected measuring points to the SIM2000-2 Prime controller for further processing.




Fig. 31: Building 3D model in the SIM2000-2 Prime controller

- When the detected conveyor speed and the specific position of the object on the belt are factored in, a spatial model is created.
- The SIM200-2 Prime controller calculates the length, width and height of the smallest rectangular box that fully encloses the object. These dimension values can be used to calculate the volume of the rectangle.
- In billing-related operation, the measurement results of the VMS5200-x MID are shown on a separate LFT display.

3 SYSTEM DESCRIPTION

3.6 Data output

Data output of the VMS4200-x MID




Fig. 32: Data output of the VMS4200

Legend

- 1 Data output via Ethernet
- 2 Data output via fieldbus
- 3 Data output via RS-232 / RS422

- The SIM2000-2 Prime controller assigns the calculated measurement results to the respective object.
- The measurement results are issued to a higher-level system.
- The data is issued via a host telegram coordinated by the customer.
- The calculated 3D point cloud of the calculated model can also be optionally output here.

Data output of the VMS5200-x MID




Fig. 33: Data output of the VMS5200

Legend

- 1 SIM2000-2 Prime controller
- 1a Saving of measurement results in alibi memory
- 1b Display of measurement results on LFT display
- 1c Data output via Ethernet, fieldbus, RS-232 / RS422

- During billing-related operation of the VMS5200, before the data is output the measurement results are saved in the SIM2000-2 Prime controller alibi memory, which is required for legal-for-trade verification.
- The measurement results are also displayed on the LFT display.

Configuring output times




Fig. 34: Configuring the time of the data output

Legend

- 1 After a defined distance from the scan plane relative to the rear edge of an object.
 - 2 After a defined distance from the scan plane relative to the leading edge of an object.
-

- The output time is configured using SOPAS.

3.7 Additional functions




Fig. 35: Contour data as focus data for connected reading systems

- If the VMS4200-x / 5200-x MID is operated as part of a complete system with a reading station (see section [3.2.6 Expanding the system with a reading station](#)), the contour data can be used as the basis for dynamic camera focusing.
- For this purpose, the SIM200-2 Prime controller supplies continuous information about the distance of the measurement sensor to the object surface via the CAN bus.

3.8 Nominal operating conditions

The VMS4200-x / 5200-x MID multi-dimensional measurement system can determine the length, width, and height of the smallest rectangular box that fully encloses cubic and irregularly shaped measuring objects. The VMS5200-x MID is certified to the Measuring Instruments Directive specified in section 9.3 *Compliance with EU directives*.

The different nominal operating conditions for single cross belt sorters and double belt sorters are described below.

Nominal operating conditions in singulated mode (single cross belt, double belt)

When single cross belt sorters and double belt sorters are operated in singulated mode, the VMS4200-x / 5200-x MID determines the measuring range and measurement accuracy for all transport units based on the object size.




Fig. 36: Nominal operating conditions in singulated mode (single cross belt, double belt)

Measuring range and scale interval value for VMS4200-x / 5200-x MID operating condition 1				
	Min.	Max.	Scale value (d)	Note
Length	≥ 50 mm ≥ 2.0"	≤ 2,500 mm ≤ 98.0"	5 mm 0.2"	Longest dimension of the measuring object
Width	≥ 50 mm ≥ 2.0"	≤ 1,600 mm ≤ 63.0"	5 mm 0.2"	Dimension of the measuring object orthogonal to the longest dimension
Height	≥ 50 mm ≥ 2.0"	≤ 1,100 mm ≤ 43.0"	5 mm 0.2"	Maximum height of the measuring object relative to the transport belt surface

Tab. 1: Measuring range and scale interval value for VMS4200-x / 5200-x MID - operating condition 1

3 SYSTEM DESCRIPTION

Measuring range and scale interval value for VMS4200-x / 5200-x MID operating condition 2				
	Min.	Max.	Scale value (d)	Note
Length	≥ 100 mm ≥ 4.0"	≤ 2,500 mm ≤ 98.0"	10 mm 0.4"	Longest dimension of the measuring object
Width	≥ 50 mm ≥ 2.0"	≤ 1,600 mm ≤ 63.0"	5 mm 0.2"	Dimension of the measuring object orthogonal to the longest dimension
Height	≥ 50 mm ≥ 2.0"	≤ 1,100 mm ≤ 43.0"	5 mm 0.2"	Maximum height of the measuring object relative to the transport belt surface

Tab. 2: Measuring range and scale interval value for VMS4200-x / 5200-x MID - operating condition 2

Measuring range and scale interval value for VMS4200-x / 5200-x MID operating condition 3				
	Min.	Max.	Scale value (d)	Note
Length	≥ 100 mm ≥ 4.0"	≤ 2,500 mm ≤ 98.0"	10 mm 0.4"	Longest dimension of the measuring object
Width	≥ 100 mm ≥ 4.0"	≤ 1,600 mm ≤ 63.0"	10 mm 0.4"	Dimension of the measuring object orthogonal to the longest dimension
Height	≥ 50 mm ≥ 2.0"	≤ 1,100 mm ≤ 43.0"	5 mm 0.2"	Maximum height of the measuring object relative to the transport belt surface

Tab. 3: Measuring range and scale interval value for VMS4200-x / 5200-x MID - operating condition 3

Measuring range and scale interval value for VMS4200-x / 5200-x MID operating condition 4				
	Min.	Max.	Scale value (d)	Note
Length	≥ 100 mm ≥ 4.0"	≤ 2,500 mm ≤ 98.0"	10 mm 0.4"	Longest dimension of the measuring object
Width	≥ 100 mm ≥ 4.0"	≤ 1,600 mm ≤ 63.0"	10 mm 0.4"	Dimension of the measuring object orthogonal to the longest dimension
Height	≥ 100 mm ≥ 4.0"	≤ 1,100 mm ≤ 43.0"	10 mm 0.4"	Maximum height of the measuring object relative to the transport belt surface

Tab. 4: Measuring range and scale interval value for VMS4200-x / 5200-x MID - operating condition 4

Nominal operating conditions in synchronized mode (double belt)

When a double belt sorter is running in synchronized mode, the following measuring ranges, measurement accuracy, and scale values apply.




Fig. 37: Nominal operating conditions in synchronized mode (double belt)

Measuring range and scale interval value for VMS4200-x / 5200-x MID operating condition 5				
	Min.	Max.	Scale value (d)	Note
Length	$\geq 150 \text{ mm}$ $\geq 6.0''$ or 3 x belt gap	$\leq 2,500 \text{ mm}$ $\leq 98.0''$	10 mm 0.4''	Longest dimension of the measuring object
Width	$\geq 150 \text{ mm}$ $\geq 6.0''$ or 3 x belt gap	$\leq 1,600 \text{ mm}$ $\leq 63.0''$	10 mm 0.4''	Dimension of the measuring object orthogonal to the longest dimension
Height	$\geq 100 \text{ mm}$ $\geq 4.0''$	$\leq 1,100 \text{ mm}$ $\leq 43.0''$	10 mm 0.4''	Maximum height of the measuring object relative to the transport belt surface

Tab. 5: Measuring range and scale interval value for VMS4200-x / 5200-x MID - operating condition 5

Nominal operating conditions in combined singulated mode and synchronized mode (double belt)

When a double belt sorter is running in combined singulated mode and synchronized mode, the dynamic presence detection determines for each transport type whether it is operating in singulated mode or synchronized mode and automatically switches to the corresponding measuring range.




Fig. 38: Nominal operating conditions in singulated mode and synchronized mode (double belt)

Transport conditions for dynamic presence detection
Cubic and irregularly shaped objects on single cross belt and double belt sorting systems $v_{\min} \geq 0.5 \text{ m/s}$ $v_{\max} \leq 4.0 \text{ m/s}$ Dynamic measuring range switchover is based on the cross-belt signal. Overhanging cubic objects are only allowed in the system variant with object detection.

3 SYSTEM DESCRIPTION

Dynamic scale value switchover (singulated mode only)

For single cross belt sorters and double belt sorters, the scale interval value can be changed depending on the particular object dimension measured, i.e., length, width or height. For double belt systems with dynamic presence detection, single belt object placements can occur with or without scale value switchover. Synchronized mode always uses the fixed scale value 10/10/10 mm (0.4"/0.4"/0.4").

The change to the second scale interval value occurs separately for each dimension value once that dimension has reached the preset switchover point. It is therefore possible to individually change scale values, i.e. if one dimension is greater or less than the predefined switchover point, only the scale value for that dimension is changed.

For example, if the switchover point is defined for the length dimension, a length that exceeds the switchover point will result in scale value 2 being applied to the length. Scale value 1 will continue to apply to the determined width and height.

The switchover point is set during commissioning and cannot be changed when the calibration switch is activated and locked (for information on the calibration switch, see section 3.9.3 *Alibi memory and firmware*). Scale interval value 1 and scale interval value 2 must be documented on two separate information labels. Only scale interval values based on the Nominal operating conditions may be selected.

Example 1




Fig. 39: Dynamic scale value switchover (length dimension as switchover point)

Legend

- 1 Switchover point 2,000 mm
- 2 Identification label for scale interval value 1
- 3 Identification label for scale interval value 2

In example 1, the multi-dimensional measurement system is working with the two scale interval values 5 mm x 5 mm x 5 mm and 10 mm x 5 mm x 5 mm. An object length of 2,000 mm has been defined as the switchover point during commissioning.

Objects with a length less than or equal to 2,000 mm are measured with scale interval value 1 (5 mm x 5 mm x 5 mm). For objects with a length greater than 2,000 mm, the multi-dimensional measurement system automatically uses scale interval value 2 (here 10 mm) for the length dimension due to the detected object length, and continues to use scale interval value 1 (here 5 mm x 5 mm) for the width and height.

Example 2

SICK VMS5200-x MID
Gisele-Sick-Str. 1
D-79276 Reute
Made in Germany

Conveyor:
 single belt
 double belt

Mode double belt:
 singulated
 synchronized

Scale value:
 fix
 dynamic

Overhang activated

	L	W	H
max ≤	500	400	300
min =	50	50	50
d =	5	5	5

Vmin = m/s Vmax = m/s

Temperaturbereich/Temperature range -10°C/+50°C. Nur ein Objekt je Cross Belt erlaubt! No overhanging irregular objects allowed.
 Only one object per Cross Belt. Keine irregulären überhängende Objekte erlaubt! Only one object per Cross Belt.
 Mehrdimensionales Messgerät für die Messung quaderförmiger, unregelmäßig geformter, nicht reflektierender, formstabiler und lichtdurchlässiger Objekte. Es wird der kleinste das Messobjekt umhüllende Quader bestimmt.
 Multi-dimensional measuring instrument for measuring rectangular, irregular shaped, non-reflective, dimensionally stable and opaque boxes. The smallest rectangular box that fully encloses the object shall be determined.

SICK VMS5200-x MID
Gisele-Sick-Str. 1
D-79276 Reute
Made in Germany

Conveyor:
 single belt
 double belt

Mode double belt:
 singulated
 synchronized

Scale value:
 fix
 dynamic

Overhang activated

	L	W	H
max ≤	2000	1200	1000
min >	500	400	300
d =	10	10	10

Vmin = m/s Vmax = m/s

Temperaturbereich/Temperature range -10°C/+50°C. Nur ein Objekt je Cross Belt erlaubt! Only one object per Cross Belt.
 Umschaltung Skalenerwerte (1)&(2) erfolgt dimensionenweise / Change of scale value (1)&(2) per dimension.
 In der Betriebsart singuliert und Skalenerwert 5/5/5 (0,2"/0,2"/0,2") sind kubische und irreguläre Objekte zulässig.
 In case of operating mode singulated and scale value 5/5/5 (0,2"/0,2"/0,2") cubic and irregular shapes are allowed.

Fig. 40: Dynamic scale value switchover (switching point for length, width and height)

In example 2, the multi-dimensional measurement system is working with the two scale interval values 5 mm x 5 mm x 5 mm and 10 mm x 10 mm x 10 mm. The change of scale interval values occurs for all three dimensions. The switching points are 500 mm for the length, 400 mm for the width, and 300 mm for the height.

The following table shows the scale interval values based on each respective measured object dimension.

L	B	H	d			L _{min}	L _{max}	B _{min}	B _{max}	H _{min}	H _{max}
mm	mm	mm	mm			mm	mm	mm	mm	mm	mm
450	350	250	5	5	5	445	455	345	355	245	255
450	250	350	5	5	10	445	455	245	255	340	360
350	450	250	5	10	5	345	355	440	460	245	255
350	250	450	5	5	10	345	355	245	255	440	460
250	450	350	5	10	10	245	255	440	460	340	360
250	350	450	5	5	10	245	255	345	355	440	460

3 SYSTEM DESCRIPTION

3.9 Legal for trade operation

The MID-compliant, and therefore capable of being verified as legal for trade, VMS5200-x MID system has been type-tested by the Physikalisch-Technische Bundesanstalt (PTB). It can therefore be used for billing purposes.

When operating the VMS5200-x MID in an application requiring official legal-for-trade verification, be sure to comply with applicable national law. SICK can assist you with this in an advisory capacity on request. However, this assistance is not a substitute for legal advice.

3.9.1 Information labels

There are several types of information labels in use:

System information labels

SICK VMS5200-x MID
 Gisela-Sick-Str. 1
 D-79276 Reute
 Made in Germany

DE-19-MI009-PTB023

mm inch

	L	W	H
max ≤			
min =			
d =			

scale value (1)
in L/W/H

Vmin = m/s Vmax = m/s

Conveyor:
 single belt
 double belt

Mode double belt:
 singulated
 synchronized

Scale value:
 fix
 dynamic

Overhang activated

Temperaturbereich/Temperature range - 10°C/+50°C. Nur ein Objekt je Cross Belt erlaubt!
 Only one object per Cross Belt. Keine irregulären überhängende Objekte erlaubt! No overhanging irregular objects allowed.

Mehrdimensionales Messgerät für die Messung quaderförmiger, unregelmäßig geformter, nicht reflektierender, formstabiler und lichtundurchlässiger Objekte. Es wird der kleinste das Messobjekt umhüllende Quader bestimmt.
 Multi-dimensional measuring instrument for measuring rectangular, irregular shaped, non-reflective, dimensionally stable and opaque boxes. The smallest rectangular box that fully encloses the object shall be determined.

Fig. 41: System information label for the VMS5200-x MID

- To ensure that the VMS5200-x MID is operated in such a way that it can be verified as legal for trade, one to three **system information labels** – depending on whether fixed scale values or dynamic scale value switchover is used – containing information about the maximum and minimum dimensions for the length (L), width (W), and height (H), as well as the relevant scale value (d) must be attached to the multi-dimensional measurement system in a highly visible location.
- The missing values are to be entered by hand on site, using waterproof permanent ink. Alternatively, printable templates are available online.
- The respective system identification labels must be attached to the system in such a manner that they can be seen by the operator and associated with the multi-dimensional measurement system.

Metrology information
label of the
VMS5200-x MID




Fig. 42: Sample label for the metrology marking, CE marking, and number of the notified body with the type labels for the SIM2000-2 Prime controller and the two LiDAR sensors

Legend

- | | |
|---|--|
| 1 | Metrology marking |
| 2 | Type label of the SIM2000-2 Prime controller |
| 3 | Type labels of the two LiDAR sensors |

- A **metrology identification label** must also be attached.
- The metrology marking – **M21** for the year 2021 in the above figure – must be indicated in accordance with Article 21 of the MID.
- Additionally, the CE marking and the number of the notified body – **0102** for PTB in the above figure – must be indicated.
- After successful commissioning and conformity assessment, the type labels of the LiDAR sensors and the type label of the SIM2000-2 Prime controller must be affixed to the metrology information label.

NOTE! The nature of the metrology information label must be such that its removal will result in the destruction of the label itself or of a security seal.

3 SYSTEM DESCRIPTION

Single cross belt sorter with fixed scale values

When the VMS5200-x MID is operated on single cross belt sorters with fixed scale values, the **Conveyor=single belt** and **Scale value=fix** options on the system information label should be marked.

The associated dimension values with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 43: Information labels for the VMS5200-x MID on single cross belt sorters with fixed scale values and with affixed type labels

Legend

- 1 System information label when working with single cross belt sorters with fixed scale values
- 2 Metrology information label with affixed type labels

Single cross belt sorter with dynamic scale value switchover

When the VMS5200-x MID is operated on single cross belt sorters with dynamic scale value switchover, the values for the two selected scale intervals must be described in two separate system information labels and attached to the system indelibly.

For scale interval value 1, the **Conveyor=**single belt and **Scale value=dynamic** options on the system information label should be marked. The dimension values with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

When specifying scale interval value 2, the **single belt/double belt: singulated** system information label must also be used and the **dynamic** operating mode marked. The dimension values for scale interval value 2 with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 44: Information labels for the VMS5200-x MID on single cross belt sorters with dynamic scale value switchover and with affixed type labels

Legend

- 1 System information label for scale interval value 1 when working with single cross belt sorters with dynamic scale value switchover
- 2 System information label for scale interval value 2
- 3 Metrology information label with affixed type labels

3 SYSTEM DESCRIPTION

Double belt sorter in singulated mode with fixed scale values

When the VMS5200-x MID is operated on double belt sorters in singulated mode with fixed scale values, the **Conveyor=double belt, Mode double belt=singulated and Scale value=fix** options on the system information label should be marked.

The associated dimension values with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 45: Information labels for the VMS5200-x MID on double belt sorters in singulated mode with fixed scale values and with affixed type labels

Legend

- 1 System information label on double belt sorters in singulated mode with fixed scale values
- 2 Metrology information label with affixed type labels

Double belt sorter in synchronized mode with fixed scale values

When the VMS5200-x MID is operated on double belt sorters in synchronized mode with fixed scale values, the **Conveyor=double belt, Mode double belt=synchronized** and **Scale value=fix** options on the system information label should be marked.

The associated dimension values with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 46: Information labels for the VMS5200-x MID on double belt sorters in synchronized mode with fixed scale values and with affixed type labels

Legend

- 1 System information label on double belt sorters in synchronized mode with fixed scale values
- 2 Metrology information label with affixed type labels

3 SYSTEM DESCRIPTION

Double belt sorter in singulated mode with dynamic scale value switchover

When the VMS5200-x MID is operated on double belt sorters in singulated mode with dynamic scale value switchover, the values for the two selected scale intervals must be described in two separate system information labels and attached to the system indelibly.

For scale interval value 1, the **Conveyor=double belt, Mode double belt=singulated and Scale value=dynamic** options on the system information label should be marked. The dimension values with unit of measurement (**mm or inch**) must be specified in indelible ink.

When specifying scale interval value 2, the **single belt/double belt: singulated** system information label must also be used and the **dynamic** operating mode marked. The dimension values for scale interval value 2 with unit of measurement (**mm or inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 47: Information labels for the VMS5200-x MID on double belt sorters in singulated mode with dynamic scale value switchover and with affixed type labels

Legend

- 1 System information label for scale interval value 1 when working with double belt sorters in singulated mode with dynamic scale value switchover
- 2 System information label for scale interval value 2
- 3 Metrology information label with affixed type labels

Double belt sorter in singulated mode and in synchronized mode with fixed scale values as well as in singulated mode with dynamic scale value switchover

When the VMS5200-x MID is operated on double belt sorters in singulated mode and in synchronized mode with fixed scale values, as well as in singulated mode with dynamic scale value switchover, the values for the selected scale intervals must be described in three separate system information labels and attached to the system indelibly.

For scale interval value 1, the **Conveyor=double belt, Mode double belt=singulated** and **Mode double belt=synchronized** as well as the **Scale value=dynamic** options on the system information label should be marked. The dimension values with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

When specifying scale interval value 2, the **single belt/double belt: singulated** system information label must be used and the **dynamic** operating mode marked. The dimension values for scale interval value 2 with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

When specifying scale interval value 3 (synchronized mode with fixed scale values), the third system information label with the operating mode **synchronized fix** must be marked. The dimension values for scale interval value 3 with unit of measurement (**mm** or **inch**) must be specified in indelible ink.

The type labels for the two LMS4x21 LiDAR sensors as well as for the SIM2000-2 Prime controller must be affixed to the corresponding fields of the metrology information label.




Fig. 48: Information labels for the VMS5200-x MID in singulated mode and in synchronized mode with fixed scale values as well as in singulated mode with dynamic scale value switchover and with affixed type labels

Legend

- 1 System information label for scale interval value 1 when working with double belt sorters in singulated mode and in synchronized mode with fixed scale values as well as in singulated mode with dynamic scale value switchover
- 2 System information label for scale interval value 2 (dynamic scale value switchover in singulated mode)
- 3 System information label for scale interval value 3 (fixed scale value in synchronized mode)
- 4 Metrology information label with affixed type labels

3 SYSTEM DESCRIPTION

3.9.2 Security seal

In order to protect measurement systems that have been verified as legal for trade against manipulation, all legally relevant components that influence the measurement result must be provided with seals in accordance with the seal diagram depicted in the figure below.

The security seals are attached to the VMS5200-x MID components after mounting and the conformity assessment.

NOTE! Never break any seals. A broken seal causes the legal for trade calibration period to end ahead of schedule. The VMS5200-x MID is then no longer permitted to be used for billing purposes.

- The incident must be reported to the manufacturer and the office of weights and measures.

Seal on the LiDAR sensor

Security seals prevent the attachment mechanism of the LiDAR sensors and the plug connections of the connections from misaligning.




Fig. 49: Security seal on the LiDAR sensors of the VMS5200-x MID

Legend

- 1 Security seal on the mounting plate of the modular bracket on the frame
- 2 Security seal on the two adjusters of the telescopic tube
- 3 Security seal on the mounting plates of the LiDAR sensors
- 4 Security seal on all plug connections for the electrical connections

Seals on the deflector mirror

In system setups with deflector mirror, the attachment mechanism is secured with security seals.




Fig. 50: Example of security seals on the deflector mirror

Legend

- 1 Security seal on the contact point between mounting bracket/
mounting frame
 - 2 Security seal on the contact point between mounting bracket/
system mount
 - 3 Security seal on the contact point between mounting bracket/
mirror holder
-

3 SYSTEM DESCRIPTION

Security seal on SIM2000-2 Prime controller




Fig. 51: SIM2000-2 Prime controller security seal

Legend

- | | |
|---|---|
| 1 | Manipulation guard |
| 2 | Security seal on the manipulation guard |
| 3 | Security seal on card slot with alibi memory card |
| 4 | Security seal on calibration switch |

- A manipulation guard protects the SIM2000-2 Prime controller installed in the cabinet against disassembly and removal of the legally-relevant connections.
- The manipulation guard is sealed.
NOTE The two adhesive seal are also a form of protection against unauthorized opening of the SIM2000 housing.
- The card slot is sealed to prevent removal of the alibi memory card.
- The calibration switch is sealed to prevent it from being misaligned.

Securing the data connections

The legally relevant data lines are protected against disconnection by a manipulation guard (Ethernet connections X13 and X14 in this example).

NOTE! The X11 and X12 Ethernet connections and/or fieldbus connections can be considered legally relevant. In this case, an appropriately modified manipulation guard is applied.




Fig. 52: Securing the legally relevant Ethernet connections (X13 + X14 in this example) of the SIM2000-2 Prime controllers in the VMS5200-x MID

Securing connected sensors and I/Os

The connections of legally relevant sensors and I/Os of the SIM2000-2 Prime controller are secured by covering the relevant plug connectors with a manipulation guard.




Fig. 53: Securing connected sensors and I/Os of the SIM2000-2 Prime controller in the VMS5200-x MID

3 SYSTEM DESCRIPTION

Calibration switch and alibi memory card security

Secure the alibi memory card in the designated card slot on the right side of the SIM2000-2 Prime controller with an adhesive seal on the slot opening.

Secure the calibration switch on the front of the SIM2000-2 Prime controller with an adhesive seal on the switch.




Fig. 54: Securing the alibi memory card with security seal on the card slot of the SIM2000-2 Prime controller and securing the calibration switch with security seal on the switch on the front of the housing

Security seal on LFT Ethernet switch

A manipulation guard protects the LFT Ethernet switch against disassembly and removal of the connecting cables.




Fig. 55: LFT Ethernet switch security seals

Legend

- 1 Manipulation guard.
- 2 Security seal on the manipulation guard.

Security seal on the photoelectric sensor array




Fig. 56: Security seal on the photoelectric sensors of the photoelectric sensor array

Legend

- 1 Security seal on the bracket
- 2 Security seal on the male connector

Security seal on the object detection photoelectric sensor

The photoelectric sensors of the photoelectric sensor array are protected against disassembly and disconnection of the connecting cable by corresponding adhesive seals.




Fig. 57: Security seals on the object detection photoelectric sensor

Legend

- 1 Security seal on the bracket
- 2 Security seal on the male connector

3 SYSTEM DESCRIPTION

Security seals on the LFT display

The LFT display is protected against disassembly and disconnection of the connecting cable by corresponding adhesive seals.




Fig. 58: Security seals on the LFT display

Legend

- 1 Security seal on the LFT display housing
 - 2 Security seal on the male connectors.
-

3.9.3 Alibi memory and firmware




Fig. 59: Micro SD card with alibi memory and firmware

Legend

- | | |
|---|---|
| 1 | MicroSD1 card slot
Micros D card with alibi memory. |
| 2 | MicroSD2 card slot
Micro SD card containing the firmware (included with delivery). |
-

SD card with alibi memory

- Measurement and calibration legislation stipulates that a measured value which is detected on a measurement device that has been verified as legal for trade in an application requiring official verification and is transmitted to an electronic data processing system must be documented in a manipulation-proof manner for a period dating back at least 90 days.
- Documentation occurs in the alibi memory on the SD card of the SIM2000-2 Prime controller. The alibi memory must be approved by the Physikalisch-Technische Bundesanstalt (PTB) or another notified body.
- The VMS5200-x MID ensures compliance with calibration legislation for measurement data as well as the traceability of all measurement processes in the measurement system.

For this purpose, all measured values obtained are stored in a legally compliant manner in the alibi memory along with their date, time, and a unique consecutive alibi ID (“identification index”), which together form the legally relevant identifier of a measurement data record.

The manipulation-proof status of the alibi memory storage was verified as part of an official WELMEC SW check by the appropriate authority.

3 SYSTEM DESCRIPTION

NOTE! When the legally relevant measurement data records are transmitted via the customer interface, the alibi ID (marked in red in the image below) is always included in order to assist the operating entity with the traceability of the data.

The screenshot shows the SICK customer interface with a navigation bar containing 'MEASUREMENT', 'VERSION', and 'ALIBI ID/WEITER'. Below the navigation bar are date selection fields for Year (2021), Month (03), and Day (29), and a pagination control showing '21 - 36 of 36'. The main content is a table of measurement data records. Each record consists of an ID, a timestamp, an alibi ID (highlighted in red), and a long alphanumeric string representing the measurement data.

ID	Timestamp	Alibi ID	Measurement Data
21	aff4b106; 2021-03-29; 09:55:14	00000000	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000055; 000050; 000020; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 985; L;
22	bbef422; 2021-03-29; 09:55:15	00000001	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000000; 000000; 000000; 005; 005; 002; mm; 0001; 00000001; 19391834; Speed: 985; N;
23	6c8f7ca4; 2021-03-29; 09:55:15	00000002	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 985; L;
24	c6b67a60; 2021-03-29; 09:55:16	00000003	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 985; L;
25	89eaab04; 2021-03-29; 09:55:30	00000004	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000055; 000050; 000020; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 999; L;
26	9df1ed20; 2021-03-29; 09:55:31	00000005	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000000; 000000; 000000; 005; 005; 002; mm; 0001; 00000001; 19391834; Speed: 999; N;
27	9453da75; 2021-03-29; 09:55:32	00000006	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000204; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 999; L;
28	448601f2; 2021-03-29; 09:55:33	00000007	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000405; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 999; L;
29	b23c-f055; 2021-03-29; 09:55:47	00000008	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000055; 000055; 000020; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;
30	ae332280; 2021-03-29; 09:55:48	00000009	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000000; 000000; 000000; 005; 005; 002; mm; 0001; 00000001; 19391834; Speed: 998; N;
31	f380387; 2021-03-29; 09:55:48	00000010	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;
32	32b0e82c; 2021-03-29; 09:55:49	00000011	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;
33	03f94dc2; 2021-03-29; 09:56:04	00000012	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000055; 000055; 000020; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;
34	f9321b5b; 2021-03-29; 09:56:05	00000013	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000000; 000000; 000000; 005; 005; 002; mm; 0001; 00000001; 19391834; Speed: 998; N;
35	6ad9eb2d; 2021-03-29; 09:56:05	00000014	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000400; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;
36	bbbcfaae; 2021-03-29; 09:56:06	00000015	0000000000; 00; 0000000000; 0000000000; 7; 0001; 1939183421023117; 205002632050025320490192; 000405; 000300; 000202; 005; 005; 002; mm; 0000; 00000000; 19391834; Speed: 998; L;

Fig. 60: Transmission of the legally relevant measurement data record including alibi ID (marked in red in the image)

NOTE! The operating entity of the VMS5200-x MID is responsible for complying at all times with the relevant regulations and guidelines in connection with operating the system in a way that is verified as legal for trade.

Firmware




Fig. 61: Separation of firmware into an application part and a metrologically relevant part

Legend

- 1 Metrologically relevant part
- 2 Application

- The firmware is separated into an **application part** and a **metrologically relevant part**.
- The separation allows customer-specific parameters to be changed via the SOPAS configuration software without violating the LFT conformity of the multi-dimensional measurement system.

Calibration switch




Fig. 62: Calibration switch for interlocking the metrological software parameters

- The software relevant to the LFT conformity with the accompanying LFT parameters is protected by a calibration switch.
- The calibration switch is located on the front of the SIM2000-2 Prime controller.
- It is interlocked by turning the calibration switch to the zero position.

3 SYSTEM DESCRIPTION

3.9.4 LFT display




Fig. 63: User interface of the LFT display

Legend

- 1 Menu bar with individual tabs
- 2 Display pane

Features

- When operating in a legal for trade application, the VMS5200-x MID also includes a separate LFT display
- To control the display, gently touch the respective button (touchscreen).
NOTE! Only touch the display with your fingers. Do not apply pressure, and do not use pointed objects.

Function

- Is used to display the measurement results during operation.
- Allows the display of status information, firmware versions and the logbook (version history) for market surveillance.
NOTE! Measurement and system data cannot be edited.

MEASUREMENT

Length	Unit	Divider
400	mm	5
Width	Unit	Divider
300	mm	5
Height	Unit	Divider
202	mm	2
Status	Albi ID	
0000	0000023	

Fig. 64: LFT display - display of the measurement results

- Visualizes the results of the last measurement.
- The length, width, and height are output with scale values in mm.
- The status provides additional information about the measurement result. Valid measurement results have the status **0 0 0 0**. Other numerical sequences indicate the reason why a measurement was invalid.

VERSION

Displays the current firmware version, the associated firmware checksum, and the parameter checksum for all LFT-relevant devices (SIM2000, LMS4x21 and LFT display).




Fig. 65: LFT display - display of the firmware versions

- Displays the firmware history per system component including the associated firmware checksums for all LFT-relevant devices (SIM2000, LMS4x21 and LFT display).
- Accessed via the **HISTORY** button in the **Checksum** column.




Fig. 66: LFT display - display of the firmware versions (history)

3 SYSTEM DESCRIPTION

- Displays the parameter checksum history for all LFT-relevant devices (SIM2000, LMS4x21 and LFT display).
- Accessed via the **HISTORY** button in the **Parameter Checksum** column.




Fig. 67: LFT display - display of the parameter checksum history

ALIBI BROWSER




Fig. 68: LFT display - display of the data sets saved in the alibi memory

- Outputs the alibi data sets.
- Enter a starting date for displaying the data sets. The display is automatically updated.

3.9.5 Test instructions for market surveillance

This section describes the procedure for inspecting the certified VMS5200x- MID measurement system with regard to:

- The performance of metrological measurements with defined test objects and the display of the measurement results on the LFT display.
- The display of data sets stored in the alibi memory on the LFT display.
- The display of system component firmware versions via the LFT display.

Starting the system

- ▶ Establish the voltage supply to the devices via the power supply unit in the cabinet.
- All system components start up automatically and are then ready for use.
- The **MEASUREMENT** tab is active in the menu bar. No measured values are available yet.

Measuring test objects

- ▶ Measure test objects made from a dimensionally stable material of various shapes and surface qualities.
- ▶ Perform the measurements.

NOTE! The nominal dimensions (length, width, height) must cover approximately 90%, 50%, and 10% of the total measuring range for each dimension. The actual dimensions must not be less than the minimum dimensions or exceed the maximum dimensions specified for the VMS5200-x MID.
- ▶ Ensure that the required minimum distance of 50 mm is maintained between the test objects.
- ▶ Compare the actual values for each measured test object with the dimension values on the LFT display.

NOTE!

- Valid measurement results have the status **0 0 0 0**. They are LFT-verified and can be used for billing.

SICK		
MEASUREMENT	VERSION	ALIBI BROWSER
Length	Unit	Divider
400	mm	5
Width	Unit	Divider
300	mm	5
Height	Unit	Divider
202	mm	2
Status	Alibi ID	
0000	0000023	


3 SYSTEM DESCRIPTION

Displaying values saved in the alibi memory

- ▶ Tap **ALIBI BROWSER** in the menu bar.

The data sets saved in the alibi memory are listed line by line. A maximum of 20 data sets can be displayed on one page.

NOTE! Valid measurement results have the status **0 0 0 0**. They are LFT-verified and can be used for billing.



- ▶ Use the arrow buttons to change between individual pages.
- ▶ Note the display of the current page number and the total number of pages.


Icon	Meaning
	Opens the first page.
	Changes from the current page to the previous page.
	Changes from the current page to the next page.
	Opens the last page.

- ▶ Enter a date to limit the period for the displayed data sets. This list is updated automatically.

**Displaying
firmware versions**


- ▶ Tap **VERSION** in the menu bar.

On the left-hand side, the current firmware status of the system components is displayed together with the checksum saved in the SIM2000-2 Prime controller.



NOTE! In the case of the VMS5200-x MID, the screen content of the **VERSION** tab needs to be scrolled into view using the scrollbar.

- ▶ Tap the **HISTORY** button to call up current and older versions for a component.




3 SYSTEM DESCRIPTION

Displaying the history of the checksum for LFT parameters

- ▶ Tap **VERSION** in the menu bar.


The checksum of the metrologically relevant LFT check parameters saved in the SIM2000-2 Prime controller and in the individual system components is displayed in the **Parameter Checksum** column.



NOTE! In the case of the VMS5200-x MID, the screen content of the **VERSION** tab needs to be scrolled into view using the scrollbar.

- ▶ Tap the **HISTORY** button to the right of the parameter checksum to call up current and older checksums of the LFT parameters.

NOTE! Altered LFT parameters must be officially disclosed to the appropriate weights and measures authority (“maintenance provider report”).



3.10 System requirements for legal for trade operation

To ensure the object dimensions are measured in a consistent and reproducible manner and with maximum accuracy, the object limitations and ambient condition described in the following sections must be taken into consideration.

Any conditions outside the limits will lead to problems or a reduction in measurement accuracy.

3.10.1 Requirements on the ambient conditions

The operation site of the multi-dimensional measurement system must have the following features:

- Closed or covered room
- Flat and firm surface
- Low-vibration environment
- Protected from wind and free of drafts
- Maximum ambient light: 2000 Lux
- No direct sunlight
- Clean and dry (air humidity 95%, non-condensing)
- Room temperature of -10 °C to 50 °C

Regardless of the space required for the components, there must be enough space at the operation site for the following activities:

- Reading the measurement results off the LFT display
- Opening the cabinet door completely
- Cleaning, maintenance, and service

3.10.2 Requirements on the conveying equipment

- The objects must not slip during the measurement process. Slippage-free conveying must be ensured.
- The measuring objects must not be exposed to any vibrations during measurement.
- Relative movements of the measuring objects are not permitted during measurement.
- The conveyor speed must be within the permissible speed range of 0.5 m/s to 4.0 m/s.
- The conveyor segments must be synchronized and running at the same belt speed.
- Start/stop operation is not supported. Starts and stops should be avoided to ensure no slipping/shaking of objects during the measurement process.

NOTE

- Any relative movement of an object to the conveyor belt will result in distorted measurement results.
 - If the objects rotate, vibrate, roll, or slip on the conveyor belt and on uneven conveying surfaces, accuracy may be impaired.
-

3 SYSTEM DESCRIPTION

General requirements

- In an area before and after the measuring station, the conveying equipment must run straight and evenly. The conveyor belt must have a uniform and flat surface. The front and back area corresponds to the maximum length of the measuring object (see also section 3.8 Nominal operating conditions).

NOTE! If the specific installation position of the measuring system fails to satisfy this requirement, the maximum length for the measuring objects must be restricted accordingly and indicated on the identification label (see section 3.9.1 Information labels).

- Positive or negative slopes of the conveying equipment must be kept flat enough to prevent the measuring objects from sliding.
- The conveying equipment must not have any shiny or reflective surfaces. This can have a negative impact on the measurement results.
- No guides for measuring objects may be installed in the vicinity of the measuring station.
- The objects must be measured separately (singulated). A minimum object separation of 50 mm is required.

NOTE! The customer must ensure that the required minimum distance is adhered to.

Special requirement for double-belt sorters




Fig. 69: System requirements for double belt sorters

Legend

- | | |
|---|--|
| A | Carrier |
| B | Cross belt |
| C | Belt gap |
| 1 | Width of the cross belt conveyor, max. 1,600 mm |
| 2 | Width of the belt, typically 250 mm + x mm |
| 3 | Carrier length (in conveying direction), max. 2,000 mm |
| 4 | Height difference cover <-> transport belt, max. 4 mm (tolerance: - 4 mm / + 1 mm) |
| 5 | Belt gap on a carrier, typically approx. 70 mm |

3.10.3 Mounting requirements

Frame

- ▶ Use a stable frame that is secured to prevent twisting and has sufficient load-bearing capacity.
- ▶ Attach the frame to the conveying system in such a way that it cannot shake or vibrate.
- ▶ Align the frame at a right angle to the conveying direction.

NOTE! Use Item aluminum profiles.

LMS4x21




Fig. 70: Working range of the LMS4x21

Legend

- | | |
|---|--|
| 1 | Maximum working sensing range: 3 m |
| 2 | Zero point of the distance measurement. In the delivery state, this point is the origin of the laser (marked with a point on the upper and lower side of the housing). |
| 3 | Minimum distance between the zero point of the measurement and the measuring object: 900 mm |
| 4 | Aperture angle: 70° |

Mounting the LMX4x21




Fig. 71: Requirements for mounting the LMS4x21

- ▶ The LiDAR sensors are mounted on the right and left of the conveyor in such a way that it is free of vibrations and oscillations.

NOTE! Use the supplied mounting kit with telescopic tube and fastening elements. See also section 4.1 *Mounting the LiDAR sensors*.

The telescopic tube must be mounted precisely at right angles to the conveying equipment.

Optimizing the scan result

- The smallest permissible distance of the measuring object from the zero point of the LMS4x21 is typically 900 mm. The zero point is marked on both the upper and lower side of the housing of the LMS4x21.
- ▶ Observe the minimum distance of the LMS4x21 to the measuring object. The required space for installation of the LiDAR sensor is approximately 900 mm above the tallest object.
- ▶ Maximum detection must be limited to a working sensing range of three meters. Otherwise, it may not be possible to attain the specified scale interval value.
- ▶ Make sure that the LMS4x21 has a clear view of the conveying equipment.
- Ensure sufficient distance of the LMS4x21 from curves, induction lines, start/stop areas, areas with upward and downward inclines, and breaks in the conveyor system.
- LFT measurements over the belt gap are not permitted.

Beam restriction




Fig. 72: Beam blockers for restricting the laser beams to the measuring range

- ▶ Attach beam blockers to the mounting frame to restrict LMS4x21 laser beams to the application space.

NOTE! Detection of people or objects located outside the measuring range is not permitted. This would otherwise distort the measurement result.

3 SYSTEM DESCRIPTION

3.10.4 Object requirements

Required object properties

- Dimensionally stable (not deformable)
- Opaque surface (not transparent)
- Non-reflective surface (no shiny or reflective surface)

Remission factor

The remission of the objects must be between 10% and max. 200%.

NOTE! Black objects with extremely low remission (< 10%) cannot be measured with high accuracy.

Object color	Remission factor [%]
Black cardboard	10
Blue	16
Red	75
White	98
Black with shiny tape	107

Measuring range restrictions in singulated mode on single cross belt sorters/double belt sorters

Measuring range related restrictions in singulated mode on single cross belt sorters or double belt sorters.

- The minimum measuring range values for length, width and height must be equal to at least **10 x scale interval d**.
Example: For an accuracy of 5 x 5 x 2 mm, the minimum object size is 50 mm / 50 mm / 20 mm (length x width x height).
- The maximum measuring range values for length, width and height must be equal to at least **15 x scale interval d**.

Measuring range restrictions in synchronized mode on double belt sorters

Measuring range related restrictions in synchronized mode on double belt sorters.

- The minimum object size in terms of height is 10 x scale interval d.
Because of the belt gap present, a minimum object size of **n x scale interval d** with **n x d ≥ 3* belt gap** applies for the object length and width, in order to ensure that the objects are stably guided over the gap.
Example: 68 mm x 3 = 204 mm → minimum length and width = 210 mm; but at least 150 mm if a different, e.g., smaller belt gap is chosen.
- The maximum measuring range values for length, width and height must be equal to at least **15 x scale interval d**.

Handling of dimensionally unstable objects



Fig. 73: Handling of dimensionally unstable objects

- Objects such as plastic bags or other unstable items are not suitable for MID-compliant dimensioning (automated LFT billing).
- The shape and size of these types of objects are not dimensionally stable. The repeatability of the measurement result is therefore not guaranteed.

NOTE!

- After the manufacturer has placed the measurement system on the market, the operating entity must ensure that dimensionally unstable, transparent or reflective objects are excluded from billing operation.
- The possibility of multiple objects being present on a single conveyor element must be excluded.
- The so-called **operating entity's responsibility** applies!

► The risk of incorrect measurements can be avoided as follows:

- Process the objects in a separate package stream that bypasses the LFT volume measurement.
- Use additional bar codes to identify dimensionally unstable objects and to tag the measurement as a non-LFT compliant measurement.
- Use a classification system for dimensionally unstable objects (e.g. Deep Learning) and tag the measurement results with a flag to indicate invalid measurement conditions.

4 Mounting

All transport, assembly, mounting, and electrical installation work must only be carried out by qualified persons.

- Qualified persons have the specialist training, skills, experience and knowledge of the relevant regulations and standards needed to be able to perform work assigned to them and to identify and avoid any potential dangers independently.
- Electricians have the professional training, skills, experience and knowledge of the relevant standards and provisions needed to work on electrical systems and to detect and avoid any potential dangers independently.

4.1 Mounting the LiDAR sensors

4.1.1 Overview




Fig. 74: Mounting the LiDAR sensors

Legend

- 1 Telescopic rod with adjuster via defined wells
 - 2 Components of the attachment mechanism for mounting the modular bracket on the frame
 - Mounting plate
 - Spring plate
 - 3 Mounting plates for mounting the LMS4x21 LiDAR sensors
-

Mounting kit

- The LiDAR sensors are mounted above the conveying equipment using the mounting kit included in the scope of delivery.
- The mounting kit has a modular design and is preconfigured accordingly upon delivery.
- It consists of a width-adjustable telescopic tube with pre-mounted and pre-aligned mounting plates to hold the LiDAR sensors.
- The telescopic tube is attached to the customer's frame via a pre-mounted attachment mechanism, consisting of a mounting plate and a spring plate.

Installation steps

- ▶ Assemble the profiles of the telescopic tube.
- ▶ Mount the telescopic rod on the frame.
- ↪ Fasten the LiDAR sensor to the mounting plate

NOTE! Adjustment after mounting is not required. The LiDAR sensors have been correctly pre-aligned at the factory by adjusting the orientation of the retaining plates on the telescopic rod.

If an alternative attachment method is used (e.g., mounting the LiDAR sensors on a hollow shaft), adjustment will be required.


4.1.2 Assembling profiles of the telescopic tube

Fig. 75: Assembling profiles of the telescopic tube

Legend

- | | |
|---|--------------------------------|
| 1 | Main tube |
| 2 | Right and left telescopic tube |

Mounting

- ▶ Slide the right and left telescopic tubes into the main tube and fasten them with screws.
- ▶ Adjust the tube to the desired width with the help of the markings.



Fig. 76: Markings on the telescopic tube

4 MOUNTING

4.1.3 Mounting the telescopic tube on the frame




Fig. 77: Mounting the telescopic tube on the frame

Mounting

- ▶ Attach the telescopic tube to a profile using the mounting and spring plate that is pre-mounted on the base tube.

4.1.4 Fastening the LiDAR sensors to the mounting plates




Fig. 78: Fastening the LiDAR sensors to the mounting plates

Mounting

Each mounting plate has an injection bush on its rear side to accommodate the LiDAR sensor. This coding prevents the device from being incorrectly rotated by 180° when mounted.

- ▶ Insert the injection bush of the mounting plate into the locating hole of the LiDAR sensor.
- ▶ Press the device into place with one hand and screw the device to the mounting plate.
- ▶ Make sure that the device is securely screwed on.

4.2 Mounting the photoelectric sensor array




Fig. 79: Mounting the photoelectric sensor array

Legend

- | | |
|---|--|
| 1 | Bracing of the cross belt conveyor |
| 2 | Photoelectric sensor |
| 3 | Reflector |
| 4 | Attachment location for the WL100L photoelectric sensor (or functionally compatible) |
| 5 | Attachment location for the reflector |

Mounting

- ▶ Mount the photoelectric sensors and reflectors below the conveyor at suitable attachment locations.
- ▶ Position the reflector within the beam path and opposite to the object detection photoelectric sensor.
- ▶ Mount the sensor in such a way that the light beam is broken by the bracing of the cross belt conveyor.

4.3 Mounting the object detection photoelectric sensor (optional)




Fig. 80: Mounting the object detection photoelectric sensor

Legend

- 1 Clinch stud. Secures the object detection photoelectric sensor to the mounting bracket.
 - 2 M5 hexagon screws
-

Mounting

- ▶ Mount the object detection photoelectric sensor on the mounting bracket using the two M5 hexagon screws.
- ▶ Secure the photoelectric sensor using the clinch stud.
- ▶ Align the photoelectric sensor correctly on the reflector. The reflector must be positioned within the beam path of the object detection photoelectric sensor.

4.4 Mounting the cabinet




Fig. 81: Mounting the cabinet

⚠ DANGER!

RISK OF INJURY FROM SUSPENDED LOADS

The track and trace cabinet can weigh up to 36 kg depending on the variant.
Severe injury or death.

- ▶ Never stand under suspended loads.
- ▶ Pay close attention when lifting loads.
- ▶ Comply with lifting instructions to prevent injuries and accidents.
- ▶ Use suitable, undamaged lifting tools.
- ▶ Prevent the cabinet from tipping over during transport.
- ▶ Wear personal protective equipment (safety helmet, safety shoes).
- ▶ Obtain the assistance of at least one other person during mounting.
- ▶ Use the mounting accessories included with delivery.

Prerequisites

- ▶ The cabinet should generally be mounted as close to the measuring system as possible so that all connecting cables can be laid easily.
- ▶ Make sure that the cabinet doors can be easily opened.
- ▶ Ensure that the air inlets and outlets on the sides of the cabinet are not covered.

NOTE! To change the replaceable filter mats, the covers (louvered grills) can be opened downwards. The cabinet needs additional freely accessible work areas of approx. 140 mm on the left and right.

Mounting

A mounting kit in a minigrip bag is supplied with the cabinet.

- ▶ Insert the sliding nuts into the two aluminum transverse profiles as per the technical drawing and screw in the setscrews.
- ▶ Mount the track and trace cabinet above the two mounting rails and into the setscrews and secure the threaded connection with a washer and hexagonal nut.

NOTE! Use two people to lift the track and trace cabinet. Observe the ergonomic factors.

5 Electrical installation

All electrical work may only be performed by qualified persons.

- Qualified persons have the specialist training, skills, experience and knowledge of the relevant regulations and standards needed to be able to perform work assigned to them and to identify and avoid any potential dangers independently.
- Electricians have the professional training, skills, experience and knowledge of the relevant standards and provisions needed to work on electrical systems and to detect and avoid any potential dangers independently.

⚠ DANGER!

HAZARDOUS ELECTRICAL VOLTAGE

The system is supplied with line voltage. Risk of electrical shock. Contact will result in death, burns or shock.

- ▶ Electrical work may only be performed on the system by qualified specialist personnel.
 - ▶ Interrupt the voltage supply.
 - ▶ Check residual voltage on the system components.
 - ▶ Use extra caution.
 - ▶ Always connect equipotential bonding (earthing).
 - ▶ Do not disconnect or remove the protective conductor.
 - ▶ The voltage supply must be disconnected when attaching or detaching electrical connections.
-

⚠ DANGER!

HAZARDOUS ELECTRICAL VOLTAGE

An incorrect supply voltage may result in damage to the device.

- ▶ Only operate the cabinet with the specified supply voltage.
 - ▶ All connected circuits must be designed as SELV circuits (in accordance with EN 60950 or ES1 EN 60368-1).
-

NOTE!

The connections of the VMS5200-x MID system, which can be verified as legal for trade, may differ from the connections of the VMS4200-x depending on the project.

5.1 Connection overview




Fig. 82: Connection overview for the VMS4200-x / 5200-x

Legend

- 1 LiDAR sensor (master)**
- 1a CAN bus
- 1b Increment and synchronization
- 1c CAN bus
- 1d Ethernet
- 2 LiDAR sensor (slave)**
- 2a Synchronization
- 2b Ethernet
- 3 LFT display - VMS5200-x MID only**
- 3a Ethernet
- 3b Voltage supply
- 4 Cabinet**
- 4a Feed 100 ... 264 V AC / 50 ... 60 Hz
- 5 SIM2000-2 Prime controller**
- 6 LFT Ethernet switch**
- 6a Ethernet
- 7 Photoelectric sensor array**
- 7a Signals for determining the speed and increment
- 8 Cross-belt signal**
- 8a Leading edge of the cross-belt conveyor element
- 9 Object detection photoelectric sensor (optional)**
- 9a Signal for object detection (leading edge of the object)
- 10 Customer server**
- 10a Data output via Ethernet, fieldbus, or serial connection
- 11 Reading station (optional)**
- 11a CAN bus

5.2 Connecting the voltage supply




Fig. 83: Pin assignment of the -X100 terminal block in the cabinet

Terminal	Color	Signal	Function
-X100/1.1	Gray	L	Line voltage 100...264 V AC / 50...60 Hz (phase)
-X100/1.4	Blue	N	Line voltage 100 ... 264 V AC / 50 ... 60 Hz (neutral conductor)
-X100/1.6	Green-yellow	PE	Protective conductor

Tab. 6: Pin assignment of the -X100 terminal block in the cabinet

NOTE!

- Make sure that cables are securely connected.

No visible metal surfaces are permitted on the wires.

- Tighten the coupling nuts to provide strain relief on the cabinet. Doing so also maintains the enclosure rating.

5.3 Connection for LFT Ethernet switch (set up at the factory)



Fig. 84: Connection for LFT Ethernet switch (set up at the factory)

Voltage supply			
No.	Wire color	Area on fuse block	Connection
1	Dark blue	FC1	13 +
	Dark blue/Red	FC1	23 -
SIM2000-2 Prime Ethernet connection			
No.	Connection on LFT Ethernet switch		Port on SIM2000-2 Prime
2	8		X14 ETH 4

Tab. 7: Connection for LFT Ethernet switch (set up at the factory)

5.4 Connection for the LiDAR sensors




Fig. 85: Connection for the 2D LiDAR sensors on the SIM2000-2 Prime controller

Legend

- A LMS master
- B LMS slave

LMS master

CAN bus/voltage supply				
No.	Connection for the LMS4x21	Wire color	SIM2000-2 Prime terminal	Connection
1	POWER CAN_IN	White	X8 CAN	1 CAN_H
		Blue	X8 CAN	2 CAN_L
		Red	-FC2	11 +
		Black	-FC2	22 -
	Connection for the LMS4x21 (master)		Connection for the LMS4x21 (slave)	
1a	POWER CAN OUT		POWER CAN IN	
Increment / synchronization				
No.	Connection for the LMS4x21	Wire color	SIM2000-2 Prime terminal	Connection
2	TACHO INPUT	Gray	X4 INPUT A	3 IN2+
		Black	X5 INPUT B	2 IN5+
		White	X5 INPUT B	4 IN6+
		Blue	X5 INPUT B	12 GND ISO (X5)
Ethernet				
No.	Connection for the LMS4x21	Port on LFT Ethernet switch		
3	Ethernet	1		

Tab. 8: Connection for LMS4x21 master

LMS slave

CAN				
No.	Connection for the LMS4x21 (slave)	Connection for the LMS4x21 (master)		
4	POWER CAN IN	POWER CAN OUT		
4a	POWER CAN OUT - termination			
Synchronization				
No.	Connection for the LMS4x21	Wire color	SIM2000-2 Prime terminal	Connection
5	Sync	Blue	X4 INPUT A	4 IN2+
		Gray	X4 INPUT A	12 GND ISO (X4)
Ethernet				
No.	Connection for the LMS4x21	Port on LFT Ethernet switch		
6	Ethernet	2		

Tab. 9: Connection for LMS4x21 slave

5.5 Connection for the LFT display (set up at the factory)




Fig. 86: Connection for the LFT display (set up at the factory)

Voltage supply			
No.	Wire color	Area on fuse block	Connection
1	Brown	FC2	15 +
	Blue	FC2	25 -
Ethernet data cable			
No.	Connection on LFT display		Port on LFT Ethernet switch
2	Ethernet (X118)		3
No.	Port on LFT Ethernet switch		Port on SIM2000-2 Prime
3	8		X14 ETH 4

Tab. 10: Connection for the LFT display (set up at the factory)

5.6 Connection for the photoelectric sensor array




Fig. 87: Connection for the photoelectric sensor array

Connection -BG110		
Wire color	Terminal	Connection
White	X5 INPUT B	1 IN5+
Brown	X5 INPUT B	7 24 V
Blue	X5 INPUT B	8 GND ISO (X5)
Connection -BG111		
Wire color	Terminal	Connection
White	X5 INPUT B	3 IN6+
Brown	X5 INPUT B	7 24 V
Blue	X5 INPUT B	8 GND ISO (X5)
Connection -BG112		
Wire color	Terminal	Connection
White	X5 INPUT B	5 IN7+
Brown	X5 INPUT B	9 24 V
Blue	X5 INPUT B	10 GND ISO (X5)
Connection -BG113		
Wire color	Terminal	Connection
White	X5 INPUT B	6 IN8+
Brown	X5 INPUT B	9 24 V
Blue	X5 INPUT B	10 GND ISO (X5)

Tab. 11: Connection for the photoelectric sensor array

5.7 Connection for the cross-belt signal




Fig. 88: Connection for the cross-belt signal

Connection

Cross-belt signal	
Terminal	Connection
X4 INPUT A	1 IN1+
X4 INPUT A	7 24 V
X4 INPUT A	8 GND ISO (X4)

Tab. 12: Connection for the cross-belt signal

- Set the **S1** DIP switch to **GND**.

5.8 Connection for the object detection photoelectric sensor (optional)




Fig. 89: Connection for the object detection photoelectric sensor (optional)

Connection

Object detection photoelectric sensor signal		
Wire color	Terminal	Connection
Black	X2 IO LINK MASTER	4 DI1
Brown	X2 IO LINK MASTER	1 24 V
Blue	X2 IO LINK MASTER	2 GND

Tab. 13: Connection of the photoelectric sensor for the object detection photoelectric sensor (optional)

5.9 Connecting the customer interface




Fig. 90: Connection to the customer network

Data cable

The measuring and reading data is issued to the customer system in one of the following data issue formats:

- Ethernet
- Fieldbus
- RS-232 / RS-422

Connection

	Terminal / Port	Connection
1	X11 ETH1, X12, ETH 2, X13 ETH3	Ethernet
2	X9 FIELDBUS P1, X10 FIELDBUS P12	Fieldbus
3	X6 SERIAL A/X7 SERIAL B	RS-232 / RS-422

NOTE! If a reading station has been integrated, the image information processed by the camera systems can be transmitted to a customer server via a separate Ethernet or Gbit interface.

6 Commissioning

Commissioning may only be performed by qualified persons.

- Qualified persons have the specialist training, skills, experience and knowledge of the relevant regulations and standards needed to be able to perform work assigned to them and to identify and avoid any potential dangers independently.
- Electricians have the professional training, skills, experience and knowledge of the relevant standards and provisions needed to work on electrical systems and to detect and avoid any potential dangers independently.

Notes

- Initial commissioning of the multi-dimensional measurement system is performed by the manufacturer.
- All of the system functions are set up by configuring the measuring conditions on-site.
- Initial commissioning by the manufacturer is not covered in these supplementary operating instructions.

6.1 Switching on the system

- ▶ Establish the supply of voltage to the devices via the power supply units in the TTC100-2.

All system components automatically start up.

Internal check for operational readiness

- Self-diagnosis is performed to check the operational readiness of the devices.
- During the power-up cycle, the status indicators show the device status.

NOTE! The system in which the multi-dimensional measurement system is integrated is put into operation via the higher-level control.

6.2 Configuring the system with SOPAS



The measurement system is adjusted by configuring the measuring conditions on site. This enables measurement, analysis, and output properties to be parameterized as required.

The SOPAS ET configuration software (included) allows interactive configuration. You can use the software to parameterize and test the properties, analysis behavior, and output properties of the system as required.

6.2.1 Installing SOPAS ET

The SOPAS configuration software is installed on a computer, which is connected to a free port on an Ethernet switch of the TTC100-2 via an Ethernet cable.

The configuration software is available for download from the SICK home page.



Fig. 91: Establishing the configuration PC - SIM2000-2 Prime controller connection

- ▶ Using an Ethernet cable, connect the configuration PC to a free Ethernet port on an Ethernet switch of the TTC100-2.

6.2.2 Installing SOPAS

- ▶ Download the latest version of SOPAS ET from www.sick.com and install it on the configuration PC.
- ▶ Start the installation by double-clicking the **setup.exe** file.



- ▶ Click on **Installation**.
- ▶ Click **OK** to select a user language for the wizard. The setup wizard opens.



- ✓ Perform the installation.

6.2.3 Assigning IP addresses

Overview IP addresses in the delivery state:

Component	Default IP address
SIM2000-2 Prime controller	192.168.0.1
LMS4x21 master	192.168.0.1
LMS4x21 slave	192.168.0.1

Tab. 14: Default IP addresses of device components

Recommended CAN and IP address assignments:

Component	CAN	TCP/IP
SIM2000-2 Prime controller	32	192.168.0.32
LMS4x21 master	25	192.168.0.25
LMS4x21 slave	26	192.168.0.26

Tab. 15: Recommended addresses of device components

Procedure As the IP addresses are the same, the IP addresses must be assigned for each device individually.





Fig. 92: Procedure for assigning IP addresses

- ▶ Make sure that the 2D LiDAR sensors are mounted correctly and electrically connected.
- ▶ Detach all Ethernet connections from the LFT Ethernet switch so that only one 2D LiDAR sensor is connected to the LFT Ethernet switch.
- ▶ Connect the configuration PC to a free port on the LFT Ethernet switch.
- ▶ Make sure that the configuration PC is in the number range of the connected device components.
- ✓ If it is not, change the IP address of the configuration PC accordingly.


Launching SOPAS

- ▶ Start SOPAS using the desktop icon or the Windows Start menu.
A new **project** is automatically created in SOPAS ET. One or more devices are combined and edited in a single project.




Adjusting the IP address of the first LMS4x21 Starting the device search

- ▶ Change the IP address of the configuration PC to the address range of the connected LiDAR sensors.
- ▶ Click on the **Search settings** button. The Connection Wizard helps you establish a connection to a connected device.
- ▶ Select the **Search using device family** option and click **Next** to confirm.




- Limit the list to the LMS4000 family and click **Next** to confirm.



- ▶ Click **Next** to confirm each of the configured search settings, and click **Finish** to complete.

If the number ranges for the configuration PC and the device correspond, then the connected LiDAR sensor is detected and displayed in the device list on the right-hand side.




NOTE! The LiDAR sensor uses two ports (like all SICK devices). Ports are part of the network address and can be used to establish various connections between the devices. Port **2112** is freely parameterizable but port **2111** is a fixed port for outputting data. It is used for device configuration.

Transferring a device to a SOPAS project


- ▶ Select the device with port number **2111**.
- ▶ Click on **Add**. The transferred device is displayed in the left-hand window as a **tile** along with its default IP address.

NOTE! Where applicable, a message window will appear indicating that the device driver for the LiDAR sensor is not yet known in the SOPAS project.




Loading device drivers into the SOPAS project

- ▶ Confirm the message with **OK**.
- ▶ Click **Install device driver** in the tile.
- ▶ To install the device driver, select the **Upload from device** option.




- ✓ Click **OK** to confirm. The device drivers are installed. The LiDAR sensor will now be detected by the configuration PC.



Changing the IP address

- ▶ In the device tile, click the pen icon next to the IP address.
- ▶ In the **TCP/IP settings** window, select the **Use the following IP settings** option and define the IP address that is to be used to access the LiDAR sensor in the sensor network.



- ✓ Click **OK** to confirm the entry. The altered IP address is displayed in the device tile.
- NOTE!** If the configuration PC and the LiDAR sensor are still in the same number range, the connection to the altered IP address of the LiDAR sensor can be established directly.

Procedure in the event of deviating address ranges


- ▶ Change the IP address of the configuration PC to the altered address range of the relevant device.
- ▶ In the title bar of the device tile, click on the icon with the three dots and select **Remove device entry**.
- ▶ ▶ Perform a new device search in SOPAS. The device is found with its new IP address and displayed in the device list.
- ▶ Add the device with port 2111 to the SOPAS project.

Configuring the IP address of the second LMS4x21

- ▶ Connect the second LMS4x21 to a free port on the LFT Ethernet switch.
 - NOTE!** As the default IP address for the first LiDAR sensor was changed, this device can remain connected via Ethernet.
- ▶ Perform a device search and change the default IP address as described.
 - NOTE!** It is not necessary to install the device driver for the LMS4x21. This was already completed when the first LiDAR sensor was added.

Changing the IP address of the SIM2000-2 Prime controller


- ▶ Change the IP address of the configuration PC to the address range of the SIM2000-2 Prime controller.
- ▶ Perform a device search and change the default IP address as described.
- ✓ The SIM2000-2 Prime controller and LMS, along with their device tiles, are now included in the SOPAS project.




6.2.4 Opening the configuration interface

Bringing the device online

- ▶ Click the **Offline** button in the tile (opens the LMS4x21 in this example).
- ▶ Synchronize the LiDAR sensor's device data with the device data of the SOPAS project. To do this, click on **Read parameters**.




- ▶ The standard parameters are transmitted from the LiDAR sensor into the SOPAS project. These parameters are then adapted to the requirements of the LiDAR sensor in SOPAS.
- ✓ **Online** appears in the tile. The LED lights up green.



Configuration interface


- ▶ Double-click on the device tile.
All configurable parameters of the LiDAR sensor are compiled together in a corresponding device description for the SOPAS configuration software.
- ▶ Use the tabs to open the functional areas of the configuration.



6.2.5 Logging on to device



- ▶ In the SOPAS toolbar, click on the icon with the three dots and select **Device** → **Login**.



- ▶ Select the **Authorized client** user level and enter the default password **client**.
- ✓ Click **LOGIN** to confirm.
The parameters that were previously grayed out on the tabs are now accessible.

6.2.6 Saving the parameters permanently

All parameters entered in SOPAS are transmitted to and executed on the connected SIM200-2 Prime controller with the **Immediate download** option. However, the data is only saved **temporarily** in the SIM200-2 Prime controller.

Saving the configuration in the non-volatile memory



- ▶ Click on the **Save parameters permanently** icon in the SOPAS toolbar.

The configuration is transferred to the SIM200-2 Prime controller and saved there permanently. This configuration is loaded whenever the SIM200-2 Prime controller is restarted.

Saving the configuration on the computer



- ▶ Click on the **Save project** button in the project window SOPAS toolbar.

- ▶ Choose a directory and file name and then confirm.

The settings are saved on the computer in a configuration file with the format ***.spr**.

NOTE! The settings within this file can be loaded subsequently (if required) and transmitted to the SIM200-2 Prime controller.

7 Maintenance and repair

Maintenance and repair measures may only be carried out by qualified persons.

- Qualified persons have the specialist training, skills, experience and knowledge of the relevant regulations and standards needed to be able to perform work assigned to them and to identify and avoid any potential dangers independently.
- Electricians have the professional training, skills, experience and knowledge of the relevant standards and provisions needed to work on electrical systems and to detect and avoid any potential dangers independently.

Device	Maintenance task	Interval*	Type
LMS4x21	Cleaning the front screen	1x/month	Trained personnel
Photoelectric sensors	Cleaning the light emission and reflector Visually inspect the object detection photoelectric sensor and reflector for rotation that may have occurred as a result of touching or the like	4x/year	Trained personnel
Cabinet	Cleaning the air inlets and outlets Replacing the filter mat in the air inlets and outlets	4x/year	Trained personnel
General information	Visual monitoring for contamination	Daily	Trained personnel
	Optical monitoring of conveying equipment for foreign bodies/damage	Daily	Trained personnel
	Control measurements with test objects to check the measurement accuracy of the multi-dimensional measurement system	Whenever the system is started	Trained personnel
	Visual electrical cabling check and as well as visual inspection of wiring for damage	1x/year	Trained personnel
	Maintenance of the individual components	2x/year	Service technicians
	Checking the complete system including measurement system/reading performance/image quality/reading range	1x/year	Service technicians
* The intervals depend on the ambient conditions and degree of contamination. In addition, the intervals must be defined according to how important they are for the customer process.			

Tab. 16: Maintenance intervals

7.1 Monitoring and cleaning work

7.1.1 Control measurements

- ▶ Ensure proper functioning of the multi-dimensional measurement system by means of regular controls.
- ▶ To do so, check the measurement accuracy of the multi-dimensional measurement system using defined test objects.
- ▶ If any unexpected deviations are found, check the multi-dimensional measurement system for mechanical damage.
- ▶ Should the multi-dimensional measurement system show signs of mechanical damage, contact SICK Service.

Operational check of the volume measurement

- ▶ Place the reference object **in a centered position** on a conveyor element.
NOTE! The LiDAR sensors need to be able to detect the entire reference object when it passes the laser line.
- ▶ Make sure that the reference object does not change its spatial position when passing the laser line.

7.1.2 Visual inspection

Visual inspection of the conveying equipment

- ▶ Regularly check the conveying equipment for damage or contamination.
- ▶ Replace any damaged belt elements immediately.

Visual inspection of the cables

- ▶ Check the electrical installation regularly.
- ▶ Make sure that all cable connections are secure.
- ▶ Replace any damaged connecting cables immediately.

7.1.3 Cleaning the LiDAR sensors

Contamination on the optical boundary surface of the LiDAR sensor can impair the measuring behavior of the device.

Cleaning the front screen



Fig. 93: Cleaning the front screen of the LiDAR sensor

- ▶ Switch off the device during cleaning.
- ▶ Remove dust from the front screen using a soft, clean brush.
- ▶ Then wipe the front screen with a clean, damp, lint-free cloth. Use a mild, anti-static lens cleaning fluid if necessary.

⚠ WARNING!

HAZARDOUS LASER RADIATION

The 2D LiDAR sensors of the VMS4200-x/ 5200-x MID use a class 2 laser. The human eye is not at risk when briefly exposed to the radiation for up to 0.25 seconds. Exposure to the laser beam for longer periods of time may cause damage to the retina. The laser radiation is harmless to human skin.

- ▶ Never look directly into the laser beam.
- ▶ Never point the laser beam at people's eyes.
- ▶ During commissioning or maintenance work, suitable eye protection must be worn.
- ▶ Avoid laser beam reflection caused by reflective surfaces. In particular during mounting and alignment work.
- ▶ Do not open the housing.
- ▶ Current national regulations regarding laser protection must be observed.

⚠ CAUTION!

REDUCED READING PERFORMANCE DUE TO SCRATCHES OR STREAKS ON THE OPTICAL BOUNDARY SURFACE

The optical output is weakened by scratches and streaks on the optical boundary surface.

- ▶ Do not use aggressive cleaning agents.
 - ▶ Do not use abrasive cleaning agents.
 - ▶ Avoid any movements that could cause scratches or abrasions on the front screen.
-

7.1.4 Cleaning the deflector mirror

In system setups with deflector mirror, we suggest the following cleaning:

- The external deflector mirror is a front surface mirror. That means that cleaning it affects the optical effective area itself.
- Only touch the reflector surface if absolutely necessary, and then only partially, if possible.

⚠ WARNING!

DAMAGE TO THE OPTICAL EFFECTIVE AREA OF THE DEFLECTOR MIRROR

Using the wrong cleaning technique or aggressive cleaning agents can damage the deflector mirror, thus impairing the reading performance of the camera system.

- ▶ That is why you should not clean the deflector mirror unless it is necessary.
 - ▶ Only touch the reflective surface when this is absolutely necessary (e.g., if it is very contaminated).
 - ▶ Never touch the entire reflective surface.
 - ▶ Do not use oily compressed air from a can.
 - ▶ Do not wipe the mirror with a towel as this could cause irreversible scratches.
-

Removing dust and loose particles

- ▶ Carefully blow away dust and loose dirt particles with clean, oil-free air.

Removing solid particles

- ▶ Carefully remove any solid particles using a camel-hair brush previously degreased with acetone. Do not apply any acetone directly to the mirror surface.

The camel-hair brush must have the following properties:

- Camel-hair brush for photographic purposes.
- Natural hair to prevent static charge.
- Suitability for cleaning optical surfaces, lenses, negatives.

Intensively cleaning the deflector mirror

- ▶ Fill a clean plastic spray bottle with distilled water.
- ▶ Spray the mirror surface uniformly with distilled water. Hold the mirror at an angle so the distilled water can drip off.
- ▶ Let the mirror dry. Do not wipe the mirror dry!

Removing grease deposits

- ▶ Spray the affected areas with a household glass cleaner.
- ▶ Carefully wipe paper tissue (recommendation: "Kleenex") over the affected area. Only apply light pressure to the mirror. Do not scour!
- ▶ Let the mirror dry. Do not wipe the mirror dry!

7.1.5 Cleaning the photoelectric sensors

Contamination on the photoelectric sensors can cause faulty switching behavior.

- ▶ Remove contamination from the optically active surfaces of the sensors.



Fig. 94: Cleaning the optical surfaces of the photoelectric sensor array

- ▶ Check that the photoelectric sensor and reflector are aligned correctly at regular intervals.

7.1.6 Cleaning the cabinet

The cabinet features an integrated fan to ensure that cabinet components are adequately cooled.

Cleaning

- ▶ Air inlets and outlets on the cabinet should be cleaned regularly with a brush.

⚠ WARNING!

RISK OF DAMAGE TO ELECTRONIC DEVICES

- ▶ Never use compressed air for cleaning!
 - ▶ Only knock the dirt off the ventilation grilles or clean them with a brush.
 - ▶ Never wet-clean the grilles.
-

Replacing filter mats




Fig. 95: Replacing the filters at the air inlets and outlets of the cabinet

- ▶ Regularly check and, if necessary, replace the filter mats behind the covers for the air inlets and outlets.
- ▶ Remove the covers from the air inlets and outlets. To do so, insert your finger into the semi-circular recess in the cover.
- ▶ Carefully remove the cover from the front.
- ▶ Remove old filter mats and replace them with new ones.
- ✓ Reattach the covers the right way up and press them down until they click into place.

7.2 Replacing components

7.2.1 Replacing the LiDAR sensor

Replacement device

Part no.	Meaning
1086802	LMS4521R-16000 LiDAR sensor with pre-installed laser protective cover

⚠ WARNING

Loss of MID conformity after replacing a component

The LiDAR sensors are part of the legal for trade system.

Due to the replacement of a component, the VMS5200-x MID will no longer be verified as legal for trade.

- ▶ After replacing a component, contact the manufacturer.
- ▶ The manufacturer will arrange for the system to be reverified after the replacement of a component.

⚠ WARNING!

HAZARDOUS LASER RADIATION

The 2D LiDAR sensors of the VMS4200-x/ 5200-x MID use a class 2 laser.

The human eye is not at risk when briefly exposed to the radiation for up to 0.25 seconds. Exposure to the laser beam for longer periods of time may cause damage to the retina. The laser radiation is harmless to human skin.

- ▶ Never look directly into the laser beam.
- ▶ Never point the laser beam at people's eyes.
- ▶ During commissioning or maintenance work, suitable eye protection must be worn.
- ▶ Avoid laser beam reflection caused by reflective surfaces. In particular during mounting and alignment work.
- ▶ Do not open the housing.
- ▶ Current national regulations regarding laser protection must be observed.

Removing a defective device




Fig. 96: Removing the LiDAR sensors from the mounting plates

- ▶ Undo and remove the three M6 fixing screws at the rear of the mounting plate.

NOTE! When loosening the last screw, press the LiDAR sensor against the bracket with one hand to hold the device in place.

- ▶ Remove the defective LiDAR sensor from the bracket. The mounting plate remains mounted on the telescopic tube.

Mounting the replacement device




Fig. 97: Dowel pins and locating holes

- ▶ Press the device into place with one hand and screw the device to the mounting plate.
- ▶ Make sure that the device is securely screwed on.
- ▶ Screw the connecting cables back on.
- ▶ Switch the voltage supply back on.
- ▶ Check that the status LED lights up green after approximately 40 seconds.

Test run

- ▶ Conduct a test run and check whether the multi-dimensional measurement system is providing plausible measurement results.

NOTE! It may be necessary to recalibrate the exchanged LiDAR sensor using SOPAS.

Restoring MID conformity

- ▶ After replacing a component, contact the manufacturer.
- ▶ The manufacturer will arrange for the system to be reverified after the replacement of a component.

7.2.2 Replacing the deflector mirror

NOTE! Do not remove protective foil of the deflector mirror until mounting is complete.

⚠ WARNING

Loss of MID conformity after replacing a component

The deflector mirror is part of the legal for trade system.

When a component is replaced, the VMS5200 loses its legal-for-trade approval.

- ▶ After replacing a component, contact the manufacturer.
 - ▶ The manufacturer will arrange for the system to be reverified after the replacement of a component.
-

Removing a defective deflector mirror




Fig. 98: Deflector mirror removal

- ▶ Mark the installed position of the deflector mirror in the mounted state (e.g., using the hole pattern).
- ▶ Undo and remove the two fixing screws on the two 180° mounting brackets.
NOTE! For this, the deflector mirror needs to be held and secured against falling by a second person.
- ✓ Remove the deflector mirror from the bracket.

Mounting a new deflector mirror

- ▶ Insert the new deflector mirror into the 180° mounting bracket.
- ▶ Fasten the deflector mirror onto the bracket with the two fixing screws.
- ▶ Remove the protective film from the new deflector mirror.
- ✓ Check that the deflector mirror is aligned correctly.

7.2.3 Replacing photoelectric sensor array components

⚠ WARNING

The system will no longer be verified as legal for trade after replacing a component

The photoelectric sensors of the photoelectric sensor array are part of the legal for trade system.

Due to the replacement of a component, the VMS5200-x MID will no longer be verified as legal for trade.

- ▶ After replacing a component, contact the manufacturer.
- ▶ The manufacturer will repair and adjust the system after the replacement of a component.

NOTE! In the case of MID-compliant systems, the operating entity must report the reverification to the local weights and measures authority.

Replacing the component




Fig. 99: Removing the photoelectric sensor of the photoelectric sensor array

- ▶ Unscrew the M12 plug connection from the male connector on the photoelectric retro-reflective sensor.
- ▶ Loosen and remove the fixing screws.
 - NOTE!** Hold the photoelectric retro-reflective sensor firmly with one hand during the procedure.
- ▶ Remove the defective photoelectric sensor from the mounting bracket.
- ▶ Screw the replacement device onto the mounting bracket.
- ▶ Screw the M12 plug connection onto the male connector on the photoelectric retro-reflective sensor.
- ▶ Align the photoelectric sensor correctly on the reflector. The reflector must be in line with the beam path of the photoelectric retro-reflective sensor.
- ✓ Check that the photoelectric retro-reflective sensor is operating correctly.

Restoring MID conformity

- ▶ After replacing a component, contact the manufacturer.
- ▶ The manufacturer will arrange for the system to be reverified after the replacement of a component.

7.2.4 Replacing the object detection photoelectric sensor

Replacing the component




Fig. 100: Removing the object detection photoelectric sensor

- ▶ Unscrew the M12 plug connection from the male connector on the object detection photoelectric sensor.
- ▶ Remove the clinch stud.
- ▶ Unscrew the hexagon screws.
NOTE! Hold the object detection photoelectric sensor firmly with one hand during the procedure.
- ▶ Remove the defective photoelectric sensor from the mounting bracket.
- ▶ Screw the replacement device onto the mounting bracket.
- ▶ Secure the replacement device using the clinch stud.
- ▶ Screw the M12 plug connection onto the male connector on the object detection photoelectric sensor.
- ▶ Align the photoelectric sensor correctly on the reflector. The reflector must be positioned within the beam path of the object detection photoelectric sensor.
- ✓ Check that the object detection photoelectric sensor is operating correctly.

7.2.5 Replacing the battery in the SIM2000-2 Prime controller

A battery powers the real-time clock of the SIM2000-2 Prime controller. The battery must be replaced when drained.

⚠ WARNING!

RISK OF INJURY FROM HOT SURFACES

Risk of burns due to hot surfaces on the controllers during operation.

- ▶ Do not touch hot surfaces.
 - ▶ Wear suitable safety gloves.
-



Fig. 101: Position of the battery in the controller

- ▶ Remove the black plastic cover on the SIM2000-2 Prime controller.
- ▶ Remove the battery from the bracket and replace it with a new **CR 1632** type battery.
- ▶ Put the black plastic cover back in place.
- ▶ Dispose of the old battery as hazardous waste as per the ROHS directives (Europe).

8 Fault diagnosis

8.1 Fault indications of the components

8.1.1 Fault indication on the LMS4x21




Fig. 102: Status indicators on the LMS4x21

Fault indication The Status LED does not light up.	
Fault cause	Possible solution to the problem
Fuse is defective.	▶ Check the fuse block in the cabinet of the SIM2000-2 Prime controller and replace the defective fuse if necessary.

Fault indication The Status LED lights up red. □ The LiDAR sensor independently monitors beam generation and automatically shuts it down in the event of irregularities. The scanner will no longer send any measured values.	
Fault cause	Remedy
<ul style="list-style-type: none"> • Error during initialization or self-test. • LMS4x21 is not in measuring mode or is in measuring mode, but errors have occurred. 	<ul style="list-style-type: none"> ▶ Check the voltage supply. ▶ Interrupt the voltage supply to the LMS4x21. ▶ Restore the voltage supply. <p>If the fault persists or occurs again after the voltage supply has been restored:</p> <ul style="list-style-type: none"> ▶ Check the device status using SOPAS (see below). ▶ If errors are listed there, contact SICK Service.

Tab. 17: Fault indication on the 2D LiDAR sensor

8.1.2 SIM2000 fault indication




Fig. 103: Fault situation: Checking normal operation SIM200-2 Prime controller

Fault indication	
The Dev RDY LED does not light up.	
Fault cause	Possible solution to the problem
Fuse is defective.	▶ Check the fuse block and replace the defective fuse if necessary.
Voltage is not switched on.	▶ Establish the correct voltage supply.
SIM2000-2 Prime controller defective.	▶ Exchange SIM2000-2 Prime controller.

If all of the connected sensors are configured and working properly, the **Sys RDY** LED lights up on the SIM2000-2 Prime controller. This means that the SIM200-2 Prime controller has received a positive feedback signal from all the components and that the devices are communicating with one another.

Fault indication	
The Dev RDY LED does not light up.	
Fault cause	Possible solution to the problem
CAN cable is attached incorrectly.	▶ Check the CAN cabling and establish connections in accordance with the electrical diagram.
Defective Ethernet connection to sensor components.	▶ Check the Ethernet connections.
Ethernet cable is defective.	▶ Replace the Ethernet cable.
LMS4x21 is defective.	▶ Replace the sensor component.

Tab. 18: Fault indication on SIM2000-2 Prime controller

8 FAULT DIAGNOSIS

8.1.3 Fault indication on the object detection photoelectric sensor

Fault indication LED receive indicator is permanently off.	
Fault cause	Possible solution to the problem
Reflector is not positioned in the beam path of the photoelectric sensor.	▶ Readjust the photoelectric sensor, clean it, or check the application conditions.

Fault indication LED receive indicator is flashing.	
Fault cause	Possible solution to the problem
Reflector is being detected in the fringe range.	▶ Readjust the photoelectric sensor, clean it, or check the application conditions.

Fault indication LED receive indicator lights up or flashes even when an object is present in the path of the beam.	
Fault cause	Possible solution to the problem
Reflector is being detected in the fringe range.	▶ Readjust the photoelectric sensor, clean it, or check the application conditions.

Tab. 19: Fault indication on the object detection photoelectric sensor

8.1.4 Fault indication on the photoelectric sensor array

Fault indication Green LED does not light up or flickers.	
Fault cause	Possible solution to the problem
Sensor is still ready for operation, but the operating conditions are not ideal (operating reserve factor between 0.9 and 1.1)	<ul style="list-style-type: none"> ▶ Check the operating conditions. ▶ Fully align the light beam (light spot) with the reflector. ▶ Clean the optical surfaces (sensor and reflector). ▶ Readjust the sensitivity (potentiometer)

Fault indication Green LED does not light up.	
Fault cause	Possible solution to the problem
No voltage or voltage below the limit values	<ul style="list-style-type: none"> ▶ Check the voltage supply, check all electrical connections (cables and plug connections). ▶ Establish a stable voltage supply. ▶ Sensor is defective. Replace the sensor.

Tab. 20: LED display in the event of a fault with the photoelectric sensor of the array

8.2 Detailed fault analysis

The SIM2000-2 Prime controller outputs faults in a staggered manner in messages. This means that a more detailed analysis is always possible.

- Communication errors can, for example, occur when transmitting telegrams to the SIM2000-2 Prime controller. The SIM2000-2 Prime controller then returns a fault code.
- For faults that occur during measuring or reading, fault codes are written to a **status log**.

Message types

The status log distinguishes between four message types:

- Information
- Warning
- Error
- Critical fault

The system saves only the last five entries for each message type.

Information and *Warning* messages are deleted after a restart.

Calling up the status log



- ▶ Call up the status log using the SOPAS configuration software.
- ▶ To do this, install SOPAS on a computer and connect the computer to the SIM2000-2 Prime controller via Ethernet.

NOTE! Please contact SICK Support for a more detailed analysis of the fault situation.

9 Technical data

9.1 Data sheet

Type	VMS4200-x	VMS5200-x MID
Type	Two-scanner solution	
Laser output aperture	On the front	
Laser diode (wavelength)	Visible light ($\lambda = 650 \text{ nm}$)	
Laser power	Max. 13 mW	
Laser class of the device	2	
Usable aperture angle	Max. 70°	
Detectable object shape	Cubic and irregularly shaped objects The objects must be at least $50 \text{ mm} \times 50 \text{ mm} \times 50 \text{ mm}$ in size	
<u>Singulated mode</u> (single cross belt, double belt)		
Min. object size (L x W x H) (operating condition 1) Certified scale value d At $v = 0.5 \text{ m/s}$ to $\leq 4 \text{ m/s}$	$50 \text{ mm} \times 50 \text{ mm} \times 50 \text{ mm} / 2.0" \times 2.0" \times 2.0"$ $5 \text{ mm} \times 5 \text{ mm} \times 5 \text{ mm} / 0.2" \times 0.2" \times 0.2"$	
Min. object size (L x W x H) (operating condition 2) Certified scale value d At $v = 0.5 \text{ m/s}$ to $\leq 4 \text{ m/s}$	$100 \text{ mm} \times 50 \text{ mm} \times 50 \text{ mm} / 4.0" \times 2.0" \times 2.0"$ $10 \text{ mm} \times 5 \text{ mm} \times 5 \text{ mm} / 0.4" \times 0.2" \times 0.2"$	
Min. object size (L x W x H) (operating condition 3) Certified scale value d At $v = 0.5 \text{ m/s}$ to $\leq 4 \text{ m/s}$	$100 \text{ mm} \times 100 \text{ mm} \times 50 \text{ mm} / 4.0" \times 4.0" \times 2.0"$ $10 \text{ mm} \times 10 \text{ mm} \times 5 \text{ mm} / 0.4" \times 0.4" \times 0.2"$	
Min. object size (L x W x H) (operating condition 4) Certified scale value d At $v = 0.5 \text{ m/s}$ to $\leq 4 \text{ m/s}$	$100 \text{ mm} \times 100 \text{ mm} \times 100 \text{ mm} / 4.0" \times 4.0" \times 4.0"$ $10 \text{ mm} \times 10 \text{ mm} \times 10 \text{ mm} / 0.4" \times 0.4" \times 0.4"$	
<u>Synchronized mode</u> (double belt) (operating condition 5) Min. object size (L x W x H) Certified scale value d At $v = 0.5 \text{ m/s}$ to $\leq 4 \text{ m/s}$	$150 \text{ mm} \times 150 \text{ mm} \times 100 \text{ mm} / 6.0" \times 6.0" \times 4.0"$ (or L, W: 3 x belt gap) $10 \text{ mm} \times 10 \text{ mm} \times 10 \text{ mm} / 0.4" \times 0.4" \times 0.4"$	
Remission factor	2% to 200%	
Max. conveyor speed	$\leq 4 \text{ m/s}$	

9 TECHNICAL DATA

Optical displays	4 LEDs on the LMS4x21
Host interface	Ethernet-based fieldbuses or serial RS-232, 422, 485
Output data	Maximum dimensions (length, width, height)
Supply voltage/power consumption	24 V DC \pm 10% /
Supply voltages	230 V AC, 100 V AC ... 264 V AC
Housing	Aluminum die cast
Enclosure rating/protection class	IP 20 (in accordance with DIN 40050); with IP 65 male connector cover
EMC test	In accordance with EN 61000-6-2:2001, EN 61000-6-4:2001
Vibration/shock check	In accordance with EN 60068-2-6, -27, -29, -64
Weight	Approx. 2.4 kg per LMS4x21 without laser protective cover Approx. 3.7 kg per LMS4x21 with laser protective cover
Temperature (operation/storage)	-10 °C ... +50 °C / -20 °C ... +70 °C

Tab. 21: Technical data of the VMS4200-x / 5200-x MID

9.2 Dimensional drawings

9.2.1 Dimensional drawings for the LiDAR sensor




Fig. 104: LMS4x21 dimensional drawing with laser protective cover

9.2.2 Dimensional drawings for the cabinet




Fig. 105: TTC100-2 dimensional drawings

9.3 Compliance with EU directives

EU declaration of conformity (extract)

The undersigned, who represents the manufacturer below, hereby declares that the product complies with the regulations of the EU directive(s) below (including all relevant changes), and that it is based on the relevant standards and/or technical specifications.

Complete EU declaration of conformity available for downloading

You can access the EU declaration of conformity and the current operating instructions for the protective device by entering the part number in the search field at www.sick.com (part number: see the type label entry in the **Ident. no.** field).

After a successful conformity assessment, the declaration of conformity for the system is declared according to the following directive:

- Measuring Instruments Directive: 2014/32 / EU (2016-04-20)

NOTE! After the successful conformity assessment, a certificate is issued to the customer/operating entity and must be archived in a readily retrievable manner for market monitoring purposes.

10 Disposal

NOTE

The applicable local and statutory environmental regulations and guidelines for the disposal of industrial and electrical waste must be observed.

NOTE

Disposal of batteries, electrical and electronic devices.

- ▶ In accordance with international directives and regulations, batteries, accumulators, and electrical or electronic devices must not be disposed of with household waste.
- ▶ The owner is obligated to dispose of the devices at the end of their service life via the appropriate public disposal points.
- ▶ This icon on the product, packaging, or in this document indicates that a product is covered by these provisions.



The following assemblies may contain substances that need to be disposed of separately:

- **Electronics:**
Capacitors, accumulators, batteries.
- **Displays:**
Liquid in the LC displays.

Australia

Phone +61 (3) 9457 0600
1800 33 48 02 – tollfree
E-Mail sales@sick.com.au

Austria

Phone +43 (0) 2236 62288-0
E-Mail office@sick.at

Belgium/Luxembourg

Phone +32 (0) 2 466 55 66
E-Mail info@sick.be

Brazil

Phone +55 11 3215-4900
E-Mail comercial@sick.com.br

Canada

Phone +1 905.771.1444
E-Mail cs.canada@sick.com

Czech Republic

Phone +420 234 719 500
E-Mail sick@sick.cz

Chile

Phone +56 (2) 2274 7430
E-Mail chile@sick.com

China

Phone +86 20 2882 3600
E-Mail info.china@sick.net.cn

Denmark

Phone +45 45 82 64 00
E-Mail sick@sick.dk

Finland

Phone +358-9-25 15 800
E-Mail sick@sick.fi

France

Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Germany

Phone +49 (0) 2 11 53 010
E-Mail info@sick.de

Greece

Phone +30 210 6825100
E-Mail office@sick.com.gr

Hong Kong

Phone +852 2153 6300
E-Mail ghk@sick.com.hk

Hungary

Phone +36 1 371 2680
E-Mail ertesites@sick.hu

India

Phone +91-22-6119 8900
E-Mail info@sick-india.com

Israel

Phone +972 97110 11
E-Mail info@sick-sensors.com

Italy

Phone +39 02 27 43 41
E-Mail info@sick.it

Japan

Phone +81 3 5309 2112
E-Mail support@sick.jp

Malaysia

Phone +603-8080 7425
E-Mail enquiry.my@sick.com

Mexico

Phone +52 (472) 748 9451
E-Mail mexico@sick.com

Netherlands

Phone +31 (0) 30 204 40 00
E-Mail info@sick.nl

New Zealand

Phone +64 9 415 0459
0800 222 278 – tollfree
E-Mail sales@sick.co.nz

Norway

Phone +47 67 81 50 00
E-Mail sick@sick.no

Poland

Phone +48 22 539 41 00
E-Mail info@sick.pl

Romania

Phone +40 356-17 11 20
E-Mail office@sick.ro

Singapore

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Slovakia

Phone +421 482 901 201
E-Mail mail@sick-sk.sk

Slovenia

Phone +386 591 78849
E-Mail office@sick.si

South Africa

Phone +27 10 060 0550
E-Mail info@sickautomation.co.za

South Korea

Phone +82 2 786 6321/4
E-Mail infokorea@sick.com

Spain

Phone +34 93 480 31 00
E-Mail info@sick.es

Sweden

Phone +46 10 110 10 00
E-Mail info@sick.se

Switzerland

Phone +41 41 619 29 39
E-Mail contact@sick.ch

Taiwan

Phone +886-2-2375-6288
E-Mail sales@sick.com.tw

Thailand

Phone +66 2 645 0009
E-Mail marcom.th@sick.com

Turkey

Phone +90 (216) 528 50 00
E-Mail info@sick.com.tr

United Arab Emirates

Phone +971 (0) 4 88 65 878
E-Mail contact@sick.ae

United Kingdom

Phone +44 (0)17278 31121
E-Mail info@sick.co.uk

USA

Phone +1 800.325.7425
E-Mail info@sick.com

Vietnam

Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Detailed addresses and further locations at www.sick.com