


Industrial Vision Camera IVC-2D

A high performance 2D smart camera



ISM Radio Frequency Classification - EN55011 –

Group1, Class A

Warning: Class A equipment is intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic compatibility in other environments, due to conducted as well as radiated disturbances.

Explanations:

Group1 – ISM equipment (ISM = Industrial, Scientific and Medical)

Group 1 contains all ISM equipment in which there is intentionally generated and/or used conductively coupled radio-frequency energy which is necessary for the internal functioning of the equipment itself.

Class A equipment is equipment suitable for use in all establishments other than domestic and those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

Class A equipment shall meet class A limits.

Note: Although class A limits have been derived for industrial and commercial establishments, administrations may allow, with whatever additional measures are necessary, the installation and use of class A ISM equipment in a domestic establishment or in an establishment connected directly to domestic electricity power supplies.

Disclaimer

SICK uses standard IP technology for its products, e.g. IO Link, industrial PCs. The focus here is on providing availability of products and services.

SICK always assumes that the integrity and confidentiality of data and rights involved in the use of the above-mentioned products are ensured by customers themselves. In all cases, the appropriate security measures, e.g. network separation, firewalls, antivirus protection, patch management, etc., are always implemented by customers themselves, according to the situation.

© SICK AG 2013-09-09

All rights reserved

8010924

Subject to change without prior notice.

German versions of the Operating Instructions and Reference manual are available on the CD.

Eine deutsche Version der Bedienungsanleitung und des Referenzhandbuchs finden Sie auf der beigelegten CD.

Contents

1	Introduction.....	6
2	Installation Guide	7
2.1	Preparing the IVC System.....	7
2.2	System requirements.....	9
2.3	Installing IVC Studio.....	10
2.4	Receiving an Image from the Device	10
3	Functional Overview.....	14
3.1	The Camera	14
3.2	IVC Studio	15
3.3	Handling Multiple Products	19
4	Getting Started	21
4.1	Creating a product.....	22
4.2	About Writing Programs.....	26
4.3	Adding Program Steps.....	29
4.4	Setting Parameter Values.....	32
4.5	Testing and Running the Program	42
4.6	Saving the Program.....	43
4.7	What's Next?	45
5	Hardware Description.....	47
5.1	Electrical Connections.....	47
5.2	Technical Data	51
5.3	Dimensional Drawings	53

IVC-2D

1 Introduction

The IVC-2D is a Smart Camera that combines image acquisition and analysis into one camera housing. The camera performs inspection, location or measurement of objects in order to enhance production yield, control production or perform quality control.

The IVC-2D is a configurable camera that can be programmed to perform many different applications. The program is set up through a graphical user interface called IVC Studio.

The product package contains:

- IVC-2D with about 120 image processing tools grouped in 13 different categories
- IVC Studio, which is the PC software to configure the camera and make application programs
- IVC Emulator, which is a software program behaving like an IVC camera. The Emulator makes it possible to develop application programs without being connected to an IVC camera.

The system can hold up to 100 different programs which are easily switched by I/O signals or Ethernet connection.

This document contains installation information, which explains how to get the first live image from the camera, a getting started chapter guiding the user through the first step program, a functional overview, and hardware specifications. For information about how to use the Emulator, please refer to the IVC-2D Reference Manual.

IVC-2D

2 Installation Guide

2.1 Preparing the IVC System

The IVC System consists of one or more devices and the development environment IVC Studio. Make sure that all ordered parts are delivered.

The following parts must be present in a functioning system:


- A device, in this case a camera
- IVC Studio development environment
- A lens
- A power I/O cable
- An Ethernet cable

2.1.1 Preparing the Power I/O Cable

The orange power I/O cable is open in one end. It contains eight wires. The blue is ground and the brown is +24 volts DC. Apply appropriate connector but do not connect it at this point.

2.1.2 Preparing the Device

The figure below shows the position of the connectors on the back of the device.



Follow the steps below to prepare the device for operation.

1. Remove the protection caps covering the connection for the lens and the cable sockets that you want to use.
2. Remove the protection caps from both ends of the lens and connect it to the device.
Be careful not to touch the glass of the lens.
3. Connect the Ethernet cable to the socket marked Ethernet on the device.
4. Connect the power I/O cable to the socket marked Power on the device.

If special illumination arrangements are made an illumination cable is required.

5. Connect a T-junction to the socket marked Power on the device.
6. Connect the illumination cable and the power I/O cable to the T-junction.

IVC-2D

2.2 System requirements

In order to run the IVC Studio software, the following prerequisites must be fulfilled.

2.2.1 PC requirements

The following specifications are required for the PC:

- Fast Ethernet connection (100 Mbits/s)
- Minimum of 550 MHz CPU, 128 MB RAM
- CD-ROM or DVD-ROM
- Windows XP Service Pack 3, Windows Vista Business Edition (32 bit) or Windows 7

2.2.2 Screen requirements

- Minimum of 1024x768 pixel resolution

2.2.3 Connection requirements

Either of the following communication connections is required for the camera to PC connection:

- Camera directly to a PC equipped with a network interface card (NIC) that automatically applies an internal crossover
- Camera directly to a PC via Ethernet crossover cable or switch

Note: The PC must be connected to the device either through a switch or directly with a crossover cable. The IVC devices do not support wireless connections or connections through a hub.

2.2.4 PC Access permission

- Windows administrator account

2.3 Installing IVC Studio

To install IVC Studio, insert the CD in the PC and go through the Setup Wizard.

The serial number that is preset in the installer should be used by most customers. If you have received a custom serial you should enter that instead. The serial and language choice can be changed in IVC Studio after the installation.

During the installation you may have to restart the PC.

After the installation the studio will be operating in Administrator mode. There is also an operator mode, which limits the available studio functionality. You can change to operator mode by selecting **Options → Disconnect Administrator** and entering a user name and password from the list below.

User name	Password
Administrator	admin
Operator	operator

2.4 Receiving an Image from the Device

The device must have an IP address in order to communicate with the PC over Ethernet. The way to provide the IP address depends on how the device is connected to the PC. The three typical options are:

- The device is connected through a switch to a network with a DHCP server. This gives the device a dynamic IP address.
- The device is connected through a switch to a network without a DHCP server. In this case a network technician provides an unoccupied IP address.
- The device is connected directly to the PC either through a switch or a cross-over Ethernet cable. In this case the IP address of the device should use the same sub-net as the PC. The PC IP address is shown in the device configuration window as local IP address.

Note: The PC must be connected to the device either through a switch or directly with a crossover cable. The IVC devices do not support wireless connections or connections through a hub.

IVC-2D

At delivery the IP parameters of the Device is configured as follows:

IP	192.168.0.110
Netmask	255.255.255.0
Gateway	0.0.0.0
DNS	0.0.0.0
WINS	0.0.0.0
Timeserver	0.0.0.0
DHCP	1
DHCP wait save	5
DHCP IPAutoConfiguration	1

Follow the steps below to receive an image from the device.

7. Make sure the PC is connected to a server or a switch and connect the Ethernet cable from the device to the same network server or switch as the PC. If you connect the device directly to the PC make sure you use a twisted Ethernet cable.
8. Connect the power I/O cable to +24 volts and GND.
9. Start IVC Studio.
Usually the device is in the program running mode the first time it is used.
10. Choose File → Open Product, select Empty and click OK.
11. Right-click the device in the right pane and choose Stop Program.
12. Choose Options → Configuration from The IVC Studio menu bar.
13. Select Ethernet Devices from the pop-up window and click the Ethernet Devices Configuration button.
A list of connected devices appears.
14. Select device.
All available settings appear in the right pane.
15. Make necessary settings.

Connection method	Parameter	Value
Through a switch to a network with a DHCP server	ID	Set to the customer serial number or another number that is unique in the network.

IVC-2D

Connection method	Parameter	Value
Through a switch to a network without a DHCP server	IP	An unoccupied IP address, provided by a network technician.
	ID	Set to the customer serial number or another number that is unique in the network.
	Netmask	Your network's netmask, provided by a network technician.
	Gateway	If there are subnets in the network, the IP address of your network's gateway. This should be provided by a network technician.
	DHCP	Set to 0 (zero).
	DHCP IPAutoConfiguration	Set to 0 (zero).
Directly to the PC either through a switch or a twisted Ethernet cable	IP ID Netmask DHCP DHCP IPAutoConfiguration	All settings are the same as for a network without DHCP server (above). The IP address of the device should use the same sub-net as the PC.


See Appendix B of the IVC-2D Reference Manual for detailed information on all the parameters.

16. Save the settings and close all dialogs.
17. Press **F5** until the device appears in the device list.
F5 searches the network for available devices.
18. Aim the device at a suitable target for a first shot.
19. Double-click the device in the right pane.
An interactive camera image appears.
20. Adjust focus and aperture on the lens.

3 Functional Overview

3.1 The Camera

The camera contains a powerful microprocessor that is tailored for image analysis. The processor can perform a number of commands – or *tools* – that are used for example for capturing an image, finding an edge in an image or setting one of the camera's output signals.



The camera also has a working memory, which contains the following:

- *Active program*, which is a sequence of commands that are used for analyzing the images.
- *Active table*, which is used for reading and storing values that are used during the analysis.
- A number of *image banks*, which each contains an image captured and processed by the camera.
- *Data blocks*, which are used by some tools for storing or reading additional data. For example, some pattern recognition tools (Teach tools) create and save data in a data block, which can later be used by other tools (Match tools).

IVC-2D


In addition, the camera has a flash memory, which is used for additional storage. The flash memory contains the following:

- *Program banks*, which are used for storing programs and tables that can be loaded into the camera's working memory. A program bank always contains both one program and one table.
- *Saved images*, which can be used for example as a basis when teaching the camera patterns to recognize.
- *Saved data blocks*, containing for example pattern recognition data to be used by Match tools, so that the pattern does not have to be taught before running a program.

3.2 IVC Studio

IVC Studio is used for developing the programs that are used by the cameras when performing *inspections* – that is, analyzing images. IVC Studio can handle both 2D and 3D cameras.

When you develop a program in IVC Studio, you work with a *product*. A product in IVC Studio is a great help for handling all the *devices* (usually cameras), programs and tables that are needed for a certain inspection.



The product contains a list of the used devices, and copies of all programs and tables that are used by the devices. Normally, each device has one program and one table associated to it, which is also the program and table that are currently in the working memory.

IVC-2D

To be able to work with a program in IVC Studio, it must be associated with a device. The device can be either a hardware camera or the Emulator, see below. A program is always executed on a device – and never on the computer. The computer is mainly used for building and modifying the programs on the devices, and to display the results sent from the devices.


3.2.1 IVC Emulator

The Emulator is a software behaving like an IVC Camera, and can be used instead of an IVC Camera. The Emulator is available in the IVC Studio development environment, and it makes it possible to develop programs when there is no IVC camera available. The Emulator can emulate both 2D and 3D cameras. The main difference between the Emulator and a camera is that the former uses a predefined set of images stored in an image folder on the PC, whereas the latter views live images.

3.2.2 Programs in Development and Production

During development, you build the program in IVC Studio but the program is automatically downloaded to the associated device.


When a program (or program step) is executed it is executed in the camera, and the results are sent back to IVC Studio where they are displayed.



IVC-2D


When the development of a program is finished and it is ready to be used, the program (and table) is downloaded to the device and started.

After this it is not necessary to use IVC Studio any more. It may be used to display the results from the program, for example to signal when faults occur. But the device can also be used as a stand-alone unit, where other equipment is used for controlling the device and displaying the output. For example, you could set up a web page on the camera and then monitor the camera from a web browser on any computer on the network.



3.2.3 Saving Programs

When you save a product in IVC Studio, the included programs and tables are saved with the product on the computer. Nothing is saved on the device when you save the product. This is not a problem since the program associated with the device is automatically loaded into the device as soon as the program is started or edited in IVC Studio.



The programs and tables may be stored manually on the device as well. The flash memory in the device contains a number of program banks, each of which can contain a program and a table.

When you store a program in the flash memory, you always store the active program and table, which are currently in the working memory of the device.


A program stored in program bank 0 will automatically be started when the device is powered up.

IVC-2D

3.3 Handling Multiple Products

A device may be used in several products, using different programs and tables depending on the product. This makes it easy to use the same camera for performing different inspections. Just create one product for each inspection, and in each product associate the program and table to be used for the specific inspection.

For example, there are three cameras set up by a production line, and we are producing two different items on this production line – a transparent bottle and an opaque jar. For the bottle we can use IVC-2D cameras to inspect both the label on the front and the fill level, but for the jar we need to use an IVC-3D camera to inspect the fill level.



To achieve this we create two products in IVC Studio with the following contents:

Product: Bottle

Device	Program	Table
1	Label	Bottle_Label_Table
2	Bottle_FillLevel	Bottle_FillLevel_Table

Product: Jar

Device	Program	Table
1	Label	Jar_Label_Table
3	Jar_FillLevel	Jar_FillLevel_Table

When switching between producing the two products, we can simply open the product in IVC Studio to load the corresponding programs and tables into the devices. If we would change the design of the label for the bottle, we can just change the values in the table Bottle_Label_Table to suit the new design. If necessary we could also make a copy of the program Label, modify it, and associate the modified program with device 1.

IVC-2D**4****Getting Started**

In this chapter we will introduce the basics in IVC Studio, and learn how to:

- Set up IVC Studio to write a program
- How to write the program - that is adding program steps and setting parameters
- How to test and debug the program

As an example we will build a simple program that checks whether or not a label has been placed correctly on a bottle, that is if it is tilted or not.



A simple way of checking this is to:

- Capture an image of the bottle
- Search the image along two lines to find the edge of the label in two locations
- Calculate the angle between the two locations

If this angle is too large then the label is tilted, and the program changes the state of an output. In a real application this output could for example control a lever that pushes the faulty bottle to the side.



When writing a program in IVC Studio you can use either a hardware camera or, if no such is available, the Emulator.

In the following sections it is assumed that a hardware camera is used, and that both the camera and IVC Studio are installed and are working properly. How to install the camera and IVC Studio is described in the installation instruction.

How to use the Emulator is described in section Using IVC Studio in the IVC-2D Reference Manual.

4.1 Creating a product


Before starting to write the program that performs the inspection, you need the following:

- A *product* to work in
- A *device* to use in the product (in this case a camera)
- A *program* written for the device
- A *table* used for the program in the device

A *product* in IVC Studio is a collection of *devices* (usually cameras) that are used for performing an inspection, for example of bottles on a production line. Each device contains one or more *programs* that instruct the device how to perform the inspection.

IVC-2D

A *program* is a list of commands, or *tools*, that the device executes one by one, in order to capture images, analyze them and draw conclusions from. To its help, the program has a *table* that it can read values from and store results to.



4.1.1 Create a Product


The first step is to create the product to work in:

1. Start IVC Studio and log in.
If you just installed IVC Studio, the default user and password can be found in the installation instruction.
2. Choose File → New Product from the IVC Studio menu bar.
A new empty product named New Product is opened.

The main window shows the contents of the currently open product. The left pane shows the different types of objects that the product may contain, that is; programs and tables.

IVC-2D

Clicking on one of the categories will display the objects contained in the product. Since the product was just created, all the categories are empty, with the exception of Devices, which displays all available devices.



There is also a fourth type that we haven't mentioned yet - *macros*. Macros are basically small programs that you can call from within regular programs. They can be useful for reusing blocks of program steps when writing advanced programs.

4.1.2 Select a Device

The next step is to select the device used for the inspection:

3. Click Devices in the left pane of the main window.
The camera is displayed in the right pane. If there are more devices that can be used by IVC Studio in your network, those will also be displayed in the right pane.
4. Select a device by clicking in the checkbox in front of it in the right pane.

IVC-2D

You should always select the devices that you intend to use in your product. IVC Studio periodically updates the information in the device list by polling the devices that are selected in the list.

If no device is selected in the list, IVC Studio will poll every device it can find for information. This slows down IVC Studio may affect the performance of devices used by other users.

4.1.3 Create a Program

Now we are ready to create the program that we intend to build and associate it with a device.

The reason for associating the program with a device before building it is that the program is always run in a device and not on the computer. What you see in IVC Studio when running a program are just the results, which are sent from the device. If you didn't associate the program with a device, you would not be able to see any result of the program or even test the program.

5. Right-click Programs in the left pane in the main window, and choose New Program from the pop-up menu.
6. Fill in a name for the program in the dialog box, and click OK.
7. Click Devices in the left pane of the main window.
8. Right-click the device in the right pane that is selected for the product, and choose Select Program from the pop-up menu.
9. Select the program in the list in the dialog box, and click OK.

4.1.4 Create a Table

There must also be a table associated with the device, so before starting to build the program we must create a table and associate it with the device:

10. Right-click Tables in the left pane in the main window, and choose New Table from the pop-up menu
11. Fill in a name for the table in the dialog box, and click OK.
12. Click Devices in the left pane of the main window.
13. Right-click the device in the right pane that is selected for the product and chose Select Table from the pop-up menu.
14. Select the table in the list in the dialog box, and click OK.
15. Finally, save your changes to the product on the PC by choosing File → Save Product.

4.2 About Writing Programs


Before starting to write the program, we will take a look at what a program consists of and the programming environment.

4.2.1 Tools

A program is a list of commands – or *tools* – that are performed by the camera. When the program runs, the commands are carried out one by one in the order that they appear in the program list. So when you build a program in IVC Studio, you work with this list of commands.

Most of the tools have a number of input parameters that can be set. For example when starting to take a snapshot from a camera, you may specify the exposure time and which input that should trigger the capture.

IVC-2D




Many tools also produce results that are available as output parameters. These parameters can be stored in the table or be used directly by other steps in your program.

4.2.2 Programming Window

When you write a program, the main window contains a few additional parts:

- Toolbar – contains the tools that can be used with the device.
- Program List – shows the tools used in the program and the parameters for each tool.
- Table – shows the contents of the device's table
- Image Banks – shows thumbnails of the images currently in the image banks of the device (if any)
- Preview – shows the result of the program step when applied to an image.



IVC-2D

The *toolbar* actually contains several toolbars on which the tools are grouped into categories. You switch between the categories by clicking the tabs at the bottom of the toolbar.

The *program list* shows each step in the programs as a table. Each step contains:

- The input parameters that can be set for the tool
- The execution time for the tool when executed
- The result (return values) from the tool

There are four columns in the program list, which are used for specifying parameter values; **Value**, **Table**, **Step** and **Result**. Which column to use depends on what type of parameter value you want to use; constant values, values stored in the table, or results from previous steps.

Image banks are used for storing images, just like the table is used for storing values. This can be very useful, for example if you want to modify the image, but need to use the original image later on in the program. Note that the images are stored in the camera, and that the images in the image banks remain there until they are removed or overwritten by other images.

The *preview window* is used by some tools to visualize the result of the tool. This preview is useful when you develop your program, but is not generated when the program is running. The preview window may also be used for setting parameters for certain tools. This is further described later on in this chapter.


4.3 Adding Program Steps

Now we are ready to start writing our program for inspecting the label on the bottles.

Start by adding the first program step to the program, which should grab an image from the camera:

1. Click on the name of your program in the left pane in the main window.

A toolbar is displayed at the top of the window, which contains a number of tools that can be used with the device. Below the toolbar there is a row of tabs, which are used for switching between different categories.




2. Click the Grab tool in the Image category on the toolbar to add the first step to the program.



The Grab tool is added to the program's folder in the left pane, and the Image Banks, Program List and Previews are displayed in the right pane.

3. Double-click the blue field at the top of the program step, and type a description for the step, for example "Retrieve an image".

	Description	Value	Table	Previous result	
				Step	Result
Retrieve an image					
	0 - Grab				
	01 - Destination bank	0	-----	-----	---
	Time of execution (µs)	0			


The command is now added to our program, but in order to see the effect of the command, it has to be executed by the camera.

4. Click the Grab step in the program list to select the step.
5. Press F1 to open up the Reference manual for the Grab step.
6. Close the manual again and remember to use the F1 button whenever you want to learn more about a tool.
7. Choose **Debug** → **Execute Step** from the IVC Studio menu, or press the F5 key on the keyboard.
An image is now retrieved from the camera and stored in image bank 0.

IVC-2D

To search the image for the edge we need two tools:

- A ROI Rectangle that creates a Region of Interest, which defines where in the image we expect to find the edge of the label.
- A Find Column Edge that looks for the upper edge of the label on the left side of the image.



We also need a step that finds the upper edge on the right side, but we will add that step after we have set the necessary parameters.

8. Click the ROI rectangle tool on the ROI toolbar.
9. In the dialog box that is displayed, choose ...after current step and click OK.
The ROI Rectangle step is added to the program list.
10. Add a description to the step, such as "Set ROI to the top of the label"
11. In a similar manner, add a Find column edge tool (from the Edge toolbar) to the program and give it the description "Find left edge".


4.4 Setting Parameter Values

The input parameters can be set in a number of different ways:

- By manually entering a constant value
- By using interactive setup to set constant values
- By retrieving a value from the table
- By using the result from a previous step
- By writing an expression that may combine the methods above

In this section we will look at different ways of setting constant parameter values. Using tables, results from previous steps and expressions will be shown in the following sections.

One important thing when specifying coordinates in images – coordinates are always measured from the top, left corner of the image.



IVC-2D

4.4.1 Setting Constant Parameter Values


Both the ROI rectangle and the Find column edge tools need a number of parameters to be set:

- | | |
|------------------|---|
| ROI rectangle | • The rectangle that is our region of interest. |
| Find column edge | • An image bank containing the image to scan.
• A Region of Interest (ROI), which is specified by entering the number of the program step in which we defined the ROI that we want to use.
• The line along which the image should be scanned and the direction to scan in. Since this tool always scans along vertical lines, the line can be specified by entering the x coordinate for the line.
• The range of grayscale values in which we expect to find the edge that we are searching for. |

To set a *constant value manually* is really straight-forward – just enter the value in the Value column for the parameter:

12. Select the Find column edge step.
13. Double-click the Value column for the parameter 06=ROI definition step, and enter the program step in which you specified the ROI.
14. Set the scan direction by double-clicking the Value column for the parameter 03=Analysis direction, and choose Up→Down from the menu.

Interactive setup windows are also used for entering constant values, but in this case captured images are used to provide feedback for the settings. Parameters can be set interactively in three different ways:


- In the Preview window
- By clicking the button with three dots (), that is displayed when a parameter is double-clicked
- By double-clicking the Setup field that is displayed at the bottom left corner of certain program steps

For example, when defining a ROI it is usually much easier to mark it directly in the image in a preview window than entering coordinates for the rectangle in the Value column:

15. Select the ROI rectangle step.

A rectangle is shown in the upper preview window. This is the default ROI that is set for a new ROI rectangle.

16. Move and resize the rectangle in the preview, so that it marks the area where you can see a part of the upper edge of the label.



17. Select the Find column edge step
18. Set the line to scan along by moving it in the preview window.

The line must be inside the ROI, which is also displayed in the preview window. By default, the line is placed at the left edge of the preview window.

If you need a larger window to work in, you can double-click a preview to open it in a separate window. In this window you can fine-tune the parameters settings, for example if there are small details in the image.

IVC-2D

Some parameters can be set in special interactive setup windows. These windows are similar to the preview windows, but contain additional controls that are used for setting the parameter values.

19. Double-click the Value column for the parameter 04=Gray low, and click the button with the three dots.




A preview of the image is displayed in a separate window, which also shows the ROI, the line along which the image is searched (yellow), and the edge that is detected using the current parameter values (red/green).



20. Click on the H (Gray High) or L (Gray Low) button, and adjust the upper or lower gray value with the slider, so that the edge of the label is clearly visible within the ROI.

IVC-2D

Certain tools have interactive setup windows in which you can set all parameters. These tools have a **Setup** field in the bottom left corner of the program step in the program list. To open the setup window, double-click the **Setup** field.



When all parameters have been set for the Find Column Edge step, we can duplicate the step and use the copy to find the edge on the right side – just change the line to search along.


21. Select the Find column edge and choose Edit → Copy from the main menu.
22. Choose Edit → Paste.
23. Set the line to scan along in the new Find column edge step by moving it in the preview window.
24. Change the description of the program step to “Find right edge”.

IVC-2D

4.4.2 Using Tables and Results from Other Steps

We will need the x coordinates for the lines when we calculate the angle of the top edge of the label. Therefore it is useful to store these values in the table instead of having to set them manually for each step in which they are used:

25. Select the “Find left edge” step, and copy the value of the parameter 02=Column.
This value is the x coordinate for the left point of the label.
26. Paste the value into an empty row in the **Value on Device** column in the table.
The row is now highlighted in the table, indicating that the value on the device differs from the value in the database.
You may also enter a description for the row, describing what the value is used for.



Index	DB Value	Value on Device	Description
0	310	310	eccordinate left side
1	340	340	eccordinate right side
2	0	0	Gray low
3	230	230	Gray high
4	0	230	0 Allowed angle
5	0	0	
6	0	0	
7	0	0	
8	0	0	
9	0	0	
10	0	0	
11	0	0	
12	0	0	


27. In the table, right-click the value in the **Value on Device** column, and choose **Copy Device Value to DB** to synchronize the value on the PC with the value in the device.
28. Select the “Find left edge” step again, and double-click in the **Table** column for the parameter 02=Column.
29. Fill in the number of the table row in which you pasted the value of the x coordinate.
30. In a similar way, copy the value of the parameter 02=Column in the “Find right edge” step to the table, and replace the value in the program step with a reference to the table row.

Now we are ready to add a step that calculates the angle of the top edge of the label.

The tool we are going to add takes the x and y coordinates of two points as parameters. We just stored the x coordinates in the table, and the y coordinates are the results (output parameters) of the two Find Column Edge steps in the program.

31. Add a Distance and angle tool (from the Measure toolbar) to the program.
32. Set the parameters 01=Start point X and 03=End point X to refer to the table rows where you stored the x coordinates of the left and the right point on the label edge.
33. Double-click the Step column of the parameter 02=Start point Y.

A Previous result dialog box is displayed, in which you can select which result from which program step number to use as parameter value.



34. Choose the step number of the first **Find column edge** step and then the first result from that step (there is only one result to choose from), and click **OK**.

The numbers of the step and the result are entered in the Step and Result columns of the 02=Start point Y parameter and the current value is displayed in the Value column.

35. In a similar way, set the parameter 04=End point Y to the result of the second Find Column Edge step.


IVC-2D

4.4.3 Using Conditions and Jumps

The angle of the label should now be tested to see whether or not it falls within the valid range of angles, and accept or reject the bottle according to the result. This is done by adding the following steps:

- In range, which tests if a value lies within a range specified by the upper and lower limit of the range, and returns 1 if the value is within the range or 0 if it is not within the range.
- If then goto, which jumps to a specified program step if a value is not zero.

The Distance and angle tool returns an angle between 0 and 360 degrees, but we would like to specify an angle between for example -5 to +5 degrees as being a valid angle. One way to get around this is to state that angles between 5 and 355 degrees are not accepted, and any other angle is accepted.



IVC-2D

To make it even more flexible, we will store the highest angle that is accepted in the table, and calculate the range directly in the program step.

36. Add an In range tool (from the Calculation toolbar).
37. Set the parameter 01=Value to the angle that was calculated by the previous step by referring to the result of that step.
38. Enter the highest acceptable angle, for example 5 degrees, in a row in the table.
39. Set the parameter 02=Min value allowed to refer to the table row in which the angle is stored.
40. Set the parameter 03=Max value allowed to the following value:

$$=360-V<\text{table row}>$$
 where <table row> is replaced with the number of the row where the angle is stored.
41. Add an If then goto tool (from the Program toolbar).
42. Set the parameter 01=Control expression to the result of the In range step.
 Do not set the parameter 02=Goto step yet, since we are going to jump to a program step that we have not added to the program.

The value of the parameter 03=Max value allowed is an expression that calculates a value each time this step is performed. An expression always begins with an equal sign (=), and may contain:

- Constant values 360, 4/7, etc.
- Table values V_n for the value in row n
- Results from other steps $S_m R_n$ for result n of step m
- Parameters (arguments) in other steps $S_m A_n$ input parameter n of step m
- Functions $\sin()$, $\text{abs}()$, etc.

Instead of writing an expression, we could have used a **Mathematical operation** tool. Which to choose depends on the complexity of the calculation – the more complex a calculation the more efficient is the Mathematical Expression.

IVC-2D

Finally, we add program steps that set one of the outputs of the camera to high or low, depending on the result of the analysis. This can be used for example to control a lever that pushes the faulty bottle to the side.

-
43. Add a Set output tool (from the Communication toolbar), and set the following parameters:

01=Output number 0
02=Signal value Low

Name the step "Angle within range"

44. Add a Goto tool (from the Program toolbar) and set the parameters so that this step jumps to step 0.

45. Add another Set output tool, and set the following parameters:

01=Output number 0
02= Signal value High

Name the step "Angle out of range"

46. Add a Goto tool and make sure that this step jumps to step 0.

47. Select the If then goto step, and set the parameter 02=Goto step to the step number of the "Angle out of range" step.

It is not necessary to add the last Goto step, since the program automatically jumps to step 0 when it comes to the end. It is however a good practice to make sure that the program jumps to the right place at the end. For example, you may add steps at the beginning of the program that initialize the program, and that we only intend to run when the program starts.

4.5 Testing and Running the Program

Now the program is written, but how do we know that it is working properly?

One way is to step through the program using Debug → Execute Step and Debug → Step by Step. The result of each step is shown in the preview window and the Value column of each parameter.

-
48. Use Debug → Execute Step and Debug → Step by Step to step through the program and make sure that it gives the correct result. Move the bottle (or what you are using) to get both accepted and rejected labels.
-

Another way is to add some program steps that show the result of the analysis, and run the program.

49. Add a Copy image bank tool after the first Grab step.

We add this step in order to have a copy of the image to draw in. If we draw in the original image the analysis is affected by our drawings.

50. Add a Draw ROI tool after the ROI rectangle step.

This step draws the region of interest in the image. Make sure to draw in the image bank with the copy of the image.

51. Add a Add text tool after the “Angle within range” step. Set the following parameters:

04=String	‘OK
06=String color	Choose a green color
08=Size	2

You should also specify the location of the text to be displayed with the parameters 01=X origin and 02=Y origin. Make sure to draw in the correct image bank.

52. Add a Display tool after the Add text step, and set the parameter so that it displays image bank 1.
53. Copy the Add text and the Display steps to after the “Angle within range” step. Change the text to be displayed to “Failed” and coloured red.


IVC-2D

54. Choose Debug → Run and watch the result in the Display window.

4.6 Saving the Program

To save the program we have written, use File → Save Product. This will save the program on the PC (along with all other programs and tables in the product), but not on the device. The program is present on the device as well, since it is downloaded to the device as you build it.

But if the power to the device is cut, your program will be lost from the device and has to be downloaded again from the PC. To prevent this from happening, you may save the program in the flash memory on the device.



To download a program to a device without saving it in the flash memory:

55. Open the product containing the program.
56. Make sure the program is associated with the device, and that a table is associated as well.

IVC-2D

57. Right-click the device in the list of devices, and choose **Start Program** from the pop-up menu.

The program is downloaded to the device and started. The status of the device is changed from STOP to RUN.

When you save the program in the flash memory on the device, you choose the program bank in which the program is saved. You always save the program that is currently in the working memory of the device, and the table that is active is also saved with the program.

To save the program on the flash memory of the device:

-
58. Right-click the device in the list of devices and choose **Flash → Write Program in Flash**.

59. Select the program bank in which to save the program, and click OK.

The program is now saved in the selected program bank.

If you save a program in program bank 0, this program will start when the device is powered up. If you want the device to run a different program, you can load that program using a PC, either by using an existing product (containing the program to be used), or by downloading the program from the device's flash memory.

IVC-2D

4.7 What's Next?

In this chapter we have looked at the basics of how to handle IVC Studio, such as setting up a product and writing a simple program. However, there are many features in IVC Studio and the camera that we have not looked at, and that makes it possible to write advanced programs for inspections and automation of production. Some of the features are:

- Using the camera as a stand-alone unit
- Using several devices in a product
- Using several programs on a single device

Using Cameras Stand-alone

Once the program is developed it can be downloaded to the device and started. Now the program will run in the device until it is stopped, and it is no longer necessary to use IVC Studio. If the program is also saved in program bank 0 on the flash memory, the program will be started when the device is powered up.


If you want to interact with the device, you can write a program that for example communicates with other equipment via the RS485 port, or uses the inputs and outputs of the device to communicate with a simple control panel.

Using Several Devices

A product may use several devices that each performs a certain inspection. It is also possible to use the same device in several products, and running different programs in the device depending on in which products it is used.

To use several devices in the product, simply select the devices by clicking the checkbox in front of them in the main window.

When the development is finished you can easily download the programs and tables to all included devices at once by right-clicking Devices in the left pane of the main window and choosing Product Transmission. This will also start the programs in the devices.



Using Several Programs


While there can be only one program in the working memory, additional programs can be stored in the flash memory of the device. These programs can either be loaded manually into the working memory, or they can be called from the active program.

- To load a program manually, use IVC Studio to associate the program with the device and then start the program. This requires that the program is available in the product that is open in IVC Studio.
If the program is not available on the PC, you can retrieve it from the device by right-clicking the device in the list of devices and choosing **Flash → Import Program from Flash**.
- To call a program stored in flash from the active program, please refer to the Tools section of this manual for information on which tool to use.

Note that calling a program stored in flash will load both a program and a table into the working memory of the device, replacing the previous program and table there.


IVC-2D**5****Hardware Description****5.1 Electrical Connections**

All electrical connections are done via M12 plug-connectors. There are three connectors on the backside of the IVC-2D:

**Trigger devices**

To trigger the IVC-2D the easiest way is to use as standard photoelectric switch with a pnp output. The switch can either switch on dark or bright as the trigger input can be set working on falling or rising edges of the trigger signal. In order not to loose too much time between event and trigger signal, please use only photoelectric switches with a switching frequency of at least 1 kHz / response time of $\leq 500\mu\text{s}$.

Power connector (male)



Pin	Color	Signal	remark
1	White	Trigger In / In 0	HIGH = 10V 28.8V
2	Brown	DC 24 V	• 20%
3	Green	Out 0	Sum of Out 0, Out 1 and Out 2 < 100 mA
4	Yellow	Out 1	Sum of Out 0, Out 1 and Out 2 < 100 mA
5	Gray	In 1	max = U_s (Supply voltage)
6	Pink	In 2	max = U_s (Supply voltage)
7	Blue	GND	
8	Red	Trigger Out	TTL (active low)

Note: The shielding of the power connector cable should be connected to ground.

IVC-2D

RS485 connector + secondary outputs (female)



Pin	Color	Signal	remark
1	White	TRA	
2	Brown	Reserved	
3	Green	Out 2	Sum of Out 0, Out 1 and Out 2 < 100 mA
4	Yellow	Reserved	
5	Gray	GND	Gnd for signals, current < 100 mA
6	Pink	GND	Gnd for RS485, current < 100 mA
7	Blue	TRB	
8	Red	In 3	

IVC-2D

Ethernet Connector



Pin	Color	Signal	remark
1		TX+	
2		RX+	
3		TX -	
4		RX -	

IVC-2D**5.2 Technical Data**

	IVC-2D R	IVC-2D Standard	IVC-2D HiRes	IVC-2D UXGA
Type	IVC-2DR1111	IVC-2DM1111	IVC-2DM1121	IVC-2DM1131
Performance	150 MHz	800 MHz	800 MHz	800 MHz
Memory	64 MB RAM, 16 MB Flash	128 MB RAM, 16 MB Flash	128 MB RAM, 16 MB Flash	128 MB RAM, 16 MB Flash
Imager	1/3" CCD (VGA and XGA) and 1/1.8" CCD (UXGA)			
Lens adaptation	CS-mount and C-mount ⁽¹⁾			
Pixel resolution	640 x 480	640 x 480	1024 x 768	1600 x 1200
Spectral response	Approx. 400 nm ... 750 nm			
Exposure time	64 • s to 500 ms			
Power supply	DC 24 V • 20%			
Current consumption ⁽²⁾	< 400 mA			
Ripple	< 5 V _{pp}			
Connectors	Power I/O: Ethernet: RS485 I/O:	M12 8-pin, male M12 4-pin, D-coded female M12 8-pin, female		
Digital inputs	HIGH = 10 V ... 28.8 V			
Digital outputs	B - types; < 100 mA ⁽³⁾			

IVC-2D


	IVC-2D R	IVC-2D Standard	IVC-2D HiRes	IVC-2D UXGA
Serial Interfaces	RS485 Ethernet: 100Mbit/s			
Operating temperature	0 °C ... 50 °C			
Storage temperature	-20 °C ... 70 °C			
Shock load	15g, 3 x 6 directions			
Vibration load	5 g, 58 ... 150 Hz			
Weight	Approx. 505 g			
Dimensions (L x H x D)	161 mm x 55 mm x 60 mm			
Enclosure rating	IP 65 (with hood)			
Housing material	Aluminum, anodized Connectors = nickel plated brass Front window of hood available in PMMA or glass			

- (1) For CS-mount, an adaptor ring should be removed
- (2) Without load and lighting
- (3) 100 mA = total current of all digital outputs


IVC-2D

5.3 Dimensional Drawings

Camera IVC-2D without adapter plate for ring light



Camera IVC-2D with adapter plate for ring light



Australia

Phone +61 3 9457 0600
1800 334 802 – tollfree

Belgium/Luxembourg

Phone +32 (0)2 466 55 66

Brasil

Phone +55 11 3215-4900

Canada

Phone +1 905 771 14 44

Česká Republika

Phone +420 2 57 91 18 50

China

Phone +86 4000 121 000
+852- 2153 6300

Danmark

Phone +45 45 82 64 00

Deutschland

Phone +49 211 5301-301

España

Phone +34 93 480 31 00

France

Phone +33 1 64 62 35 00

Great Britain

Phone +44 (0)1727 831121

India

Phone +91-22-4033 8333

Israel

Phone +972-4-6881000

Italia

Phone +39 02 27 43 41

Japan

Phone +81 (0)3 3358 1341

Magyarország

Phone +36 1 371 2680

Nederlands

Phone +31 (0)30 229 25 44

Norge

Phone +47 67 81 50 00

Österreich

Phone +43 (0)22 36 62 28 8-0

Polska

Phone +48 22 837 40 50

România

Phone +40 356 171 120

Russia

Phone +7-495-775-05-30

Schweiz

Phone +41 41 619 29 39

Singapore

Phone +65 6744 3732

Slovenija

Phone +386 (0)1-47 69 990

South Africa

Phone +27 11 472 3733

South Korea

Phone +82 2 786 6321/4

Suomi

Phone +358-9-25 15 800

Sverige

Phone +46 10 110 10 00

Taiwan

Phone +886-2-2375-6288

Türkiye

Phone +90 (216) 528 50 00

United Arab Emirates

Phone +971 (0) 4 8865 878

USA/México

Phone +1(952) 941-6780
1800-325-7425 – tollfree

Detailed addresses and
additional representatives and
agencies at www.sick.com

SICK

Sensor Intelligence.