


# AFS/AFM60 EtherCAT®

Absolute Encoder

**SICK**  
Sensor Intelligence.



---

**Described product**

AFS/AFM60 EtherCAT®

**Manufacturer**

SICK AG  
Erwin-Sick-Str. 1  
79183 Waldkirch  
Germany

**Legal information**


This work is protected by copyright. Any rights derived from the copyright shall be reserved for SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Any modification, abridgment or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks stated in this document are the property of their respective owner.

© SICK AG. All rights reserved.

**Original document**

This document is an original document of SICK AG.



## Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>About this document.....</b>                       | <b>5</b>  |
| 1.1      | Scope.....  | 5         |
| 1.2      | Purpose of this document.....                         | 5         |
| 1.3      | Target group.....                                     | 5         |
| 1.4      | Information depth.....                                | 5         |
| 1.5      | Symbols used.....                                     | 6         |
| 1.6      | Abbreviations used.....                               | 6         |
| <b>2</b> | <b>Safety information.....</b>                        | <b>8</b>  |
| 2.1      | General notes.....                                    | 8         |
| 2.2      | Intended use.....                                     | 8         |
| 2.3      | Requirements for the qualification of personnel.....  | 9         |
| 2.4      | Environmental protection.....                         | 9         |
| <b>3</b> | <b>Product description.....</b>                       | <b>10</b> |
| 3.1      | Specific features.....                                | 10        |
| 3.2      | Operating principle of the encoder.....               | 11        |
| 3.2.1    | Scalable resolution.....                              | 11        |
| 3.2.2    | Preset function.....                                  | 11        |
| 3.2.3    | Round axis functionality.....                         | 12        |
| 3.2.4    | Electronic cam mechanism.....                         | 14        |
| 3.3      | Integration in EtherCAT®.....                         | 15        |
| 3.3.1    | EtherCAT® topology.....                               | 15        |
| 3.3.2    | EtherCAT® telegram in the Ethernet frame.....         | 16        |
| 3.3.3    | CANopen over EtherCAT® (CoE).....                     | 17        |
| 3.3.4    | ESI file.....   | 18        |
| 3.4      | Configurable functions.....                           | 19        |
| 3.4.1    | Scaling parameters.....                               | 20        |
| 3.4.2    | Preset function.....                                  | 23        |
| 3.4.3    | Cyclic process data.....                              | 24        |
| 3.4.4    | Synchronization.....                                  | 25        |
| 3.4.5    | Speed measurement.....                                | 26        |
| 3.4.6    | Round axis functionality.....                         | 27        |
| 3.4.7    | Electronic cam mechanism.....                         | 27        |
| 3.5      | Operating modes and synchronization.....              | 28        |
| 3.5.1    | EtherCAT® State Machine.....                          | 28        |
| 3.5.2    | Synchronous operating modes.....                      | 29        |
| 3.5.3    | Cycle times.....                                      | 29        |
| 3.6      | Object library.....                                   | 30        |
| 3.6.1    | Nomenclature.....                                     | 31        |
| 3.6.2    | Overview of the standard objects.....                 | 31        |
| 3.6.3    | Detailed information on the standard objects.....     | 32        |
| 3.6.4    | PDO mapping objects.....                              | 35        |
| 3.6.5    | Overview of the encoder profile-specific objects..... | 39        |

|          |  |           |
|----------|--|-----------|
| 3.6.6    | Detailed information on the encoder parameters.....                  | 40        |
| 3.6.7    | Detailed information on the electronic cam mechanism (CAM).....      | 42        |
| 3.6.8    | Detailed information on the diagnostics.....                         | 45        |
| 3.6.9    | Overview of the manufacturer-specific objects.....                   | 49        |
| 3.6.10   | Detailed information on objects for encoder configuration..          | 50        |
| 3.6.11   | Detailed information on objects that provide status information..... | 53        |
| 3.7      | Controls and status indicators.....                                  | 61        |
| <b>4</b> | <b>Commissioning.....</b>  | <b>62</b> |
| 4.1      | Electrical installation.....   | 62        |
| 4.1.1    | Connections of the AFS60/AFM60 EtherCAT®.....                        | 62        |
| 4.2      | Settings on the hardware.....  | 63        |
| 4.3      | Configuration.....   | 65        |
| 4.3.1    | Default delivery status.....   | 65        |
| 4.3.2    | System configuration.....  | 65        |
| 4.4      | Test notes.....  | 70        |
| <b>5</b> | <b>Troubleshooting.....</b>  | <b>71</b> |
| 5.1      | Response to errors.....  | 71        |
| 5.2      | Support.....   | 71        |
| 5.3      | Error and status indications on the LEDs.....                        | 71        |
| 5.3.1    | Identification of the encoder.....                                   | 71        |
| 5.3.2    | NMOD, STAT and Encoder status LEDs.....                              | 71        |
| 5.3.3    | Ethernet Link LEDs L/A1 and L/A2.....                                | 72        |
| 5.4      | Diagnostics via EtherCAT®.....                                       | 73        |
| 5.4.1    | Error types.....   | 73        |
| 5.4.2    | Encoder specific errors.....   | 73        |
| 5.4.3    | CoE specific errors.....   | 73        |
| 5.4.4    | EtherCAT® specific errors.....                                       | 74        |
| 5.4.5    | Error messages.....  | 78        |
| <b>6</b> | <b>Annex.....</b>  | <b>81</b> |
| 6.1      | Conformities and certificates.....                                   | 81        |
| 6.1.1    | EU declaration of conformity.....                                    | 81        |
| 6.1.2    | UK declaration of conformity.....                                    | 81        |

# 1 About this document

Please read this chapter carefully before working with this documentation and the AFS60/AFM60 EtherCAT® Absolute Encoder.

## 1.1 Scope



### NOTE

These operating instructions apply to the AFS60/AFM60 EtherCAT® Absolute Encoder with the following type codes:

- Singleturn Encoder Advanced = AFS60A-xxEx262144
- Multiturn Encoder Advanced = AFM60A-xxEx018x10

## 1.2 Purpose of this document

These operating instructions instruct the technical personnel of the machine manufacturer or machine operator in:

- Electrical installation
- Commissioning
- Parameterization
- Operation
- Maintenance

These operating instructions must be made available to all persons who work with the encoder.

The official and legal regulations for operating the encoder must always be complied with.

## 1.3 Target group

These operating instructions are intended for planning engineers, developers, and operators of plants and systems into which one or more AFS/AFM60 EtherCAT® Absolute Encoder are to be integrated. They are also intended for people who put the encoder into operation for the first time or who are in charge of maintenance.

These instructions are written for trained persons who are responsible for the installation, mounting and operation of the encoder in an industrial environment.

Only trained electricians are permitted to carry out work on the electrical system or electrical assemblies.



### NOTICE

- ▶ Read the operating instructions carefully and ensure that you have understood the contents completely before you work with the encoder.

## 1.4 Information depth

These operating instructions contain information on the AFS60/AFM60 EtherCAT® Absolute Encoder on the following subjects:

- product features
- electrical installation
- commissioning and configuration
- fault diagnosis and troubleshooting
- conformity

These operating instructions do not contain any information on the mounting of the AFS60/AFM60 EtherCAT®. You will find this information in the mounting instructions included with the device.

They also do not contain any information on technical specifications, dimensional drawings, ordering information or accessories. You will find this information in the data sheet for the AFS60/AFM60 EtherCAT®.

Planning and using measurement systems such as the AFS60/AFM60 EtherCAT® also requires specific technical skills beyond the information in the operating instructions and mounting instructions. The information required to acquire these specific skills is not contained in this document.

When operating the AFS60/AFM60 EtherCAT®, the national, local and statutory rules and regulations must be observed.

#### Additional information

- [www.ethercat.org](http://www.ethercat.org)
- ETG.1000, 2 ... 6: Layer protocol & service definitions
- ETG.1020, EtherCAT® Guidelines and Protocol Enhancements
- ETG.1300, EtherCAT® Indicator & Labeling specification (as per IEC 61784-2)
- ETG.2000, EtherCAT® Slave Information
- ETG.2200, EtherCAT® Slave Implementation Guide
- CiA DS-406, Profile Encoder for CANopen
- CiA DS-301, CANopen communication profile
- ET1810/1812, Slave Controller IP Core for Altera FPGA

## 1.5 Symbols used



### NOTE

Refer to notes for special features of the device.

---

LED symbols describe the state of a diagnostics LED. Examples:

- **Red** The red LED is illuminated constantly.
- ◉ **Yellow** The yellow LED is flashing.
- **Green** The green LED is off.

► Take action ...

Instructions for taking action are shown by an arrow. Read carefully and follow the instructions for action.

---



### WARNING

A warning notice indicates an actual or potential risk or health hazard. They are designed to help you to prevent accidents.

Read carefully and follow the warning notices.

---

## 1.6 Abbreviations used

- CMR** Counts per Measuring Range
- CNR\_D** Customized Number of Revolutions, Divisor = divisor of the customized number of revolutions
- CNR\_N** Customized Number of Revolutions, Nominator = nominator of the customized number of revolutions
- CoE** CANopen over EtherCAT®

|                  |  |
|------------------|--|
| <b>CPR</b>       | Counts Per Revolution  |
| <b>DC</b>        | Distributed Clocks   |
| <b>EEPROM</b>    | Electrically Erasable Programmable Read-only Memory  |
| <b>EoE</b>       | Ethernet over EtherCAT   |
| <b>ESC</b>       | EtherCAT® Slave Controller   |
| <b>ESI</b>       | EtherCAT® Slave Information = electronic data sheet based on XML   |
| <b>ESM</b>       | EtherCAT® State Machine = controls the status of the EtherCAT slave                                      |
| <b>ETG</b>       | EtherCAT® Technology Group   |
| <b>EtherCAT®</b> | EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany |
| <b>PDO</b>       | Process Data Object  |
| <b>PLC</b>       | Programmable Logic Controller  |
| <b>PMR</b>       | Physical Measuring Range   |
| <b>PRS</b>       | Physical Resolution Span (per revolution)  |
| <b>SDO</b>       | Service Data Object  |

## 2 Safety information

This section concerns your own safety and the safety of the system operator.

- ▶ Please read this section carefully before working with the AFS60/AFM60 EtherCAT® or the machine or system on which the AFS60/AFM60 EtherCAT® is used.

### 2.1 General notes

---



#### **DANGER**

Observe the following to ensure the safe use of the AFS/AFM60 EtherCAT® as intended.

The encoder must be installed and maintained by trained, qualified personnel with knowledge of electronics, precision engineering, and controller programming. The relevant technical safety standards must be observed.

All persons entrusted with the installation, operation, or maintenance of the devices must follow the safety guidelines:

- The operating instructions must always be available and must be followed.
  - Unqualified personnel must stay away from the system during installation and maintenance.
  - The system must be installed in accordance with the applicable safety regulations and mounting instructions.
  - The work safety regulations of the employers' liability insurance associations and trade associations in the respective country must be observed during installation.
  - Failure to observe the relevant work safety regulations may lead to physical injury or cause damage to the system.
  - The current and voltage sources in the encoder are designed in accordance with the applicable technical guidelines.
- 

### 2.2 Intended use

The Absolute Encoder AFS/AFM60 EtherCAT® is a measuring device which is manufactured according to the recognized industrial regulations and which meets the quality requirements stipulated in ISO 9001:2008 as well as those relating to environmental management systems as defined in ISO 14001:2009.

An encoder is designed for mounting and can only be operated according to its intended function. For this reason, the encoder is not equipped with direct safety devices.

The system designer must provide measures to ensure the safety of persons and systems in accordance with the legal guidelines.

Due to its design, the AFS/AFM60 EtherCAT® may only be operated within an EtherCAT network. It is necessary to comply with the EtherCAT specifications and guidelines for setting up a EtherCAT network.

In the event of any other usage or modification to the AFS/AFM60 EtherCAT® (e.g., due to opening the housing during mounting and electrical installation) or in the event of changes made to the SICK software, any claims against SICK AG under the warranty will be rendered void.



## 2.3 Requirements for the qualification of personnel

The encoder must only be mounted, commissioned, and maintained by authorized personnel.



### NOTE

Repair work on the encoder may only be performed by qualified and authorized service personnel from SICK AG.

The following qualifications are necessary for the various tasks:

Table 1: Authorized personnel

| Task   | Qualification  |
|--|--|
| Mounting (see mounting instructions)           | <ul style="list-style-type: none"> <li>Basic practical technical training</li> <li>Knowledge of the current safety regulations in the workplace</li> </ul>   |
| Electrical installation and device replacement | <ul style="list-style-type: none"> <li>Practical electrical training</li> <li>Knowledge of current electrical safety regulations</li> <li>Knowledge of the operation and control of the devices in their particular application (e.g., industrial robots, storage and conveyor systems)</li> </ul> |
| Commissioning, operation, and configuration    | <ul style="list-style-type: none"> <li>Knowledge of the current safety regulations and of the operation and control of the devices in their particular application</li> <li>Knowledge of automation systems</li> <li>Knowledge of EtherCAT®</li> <li>Knowledge of automation software</li> </ul>   |

## 2.4 Environmental protection

Please note the following information on disposal.

Table 2: Disposal of the assemblies

| Assembly              | Material           | Disposal         |
|-----------------------|--------------------|------------------|
| Packaging             | Cardboard          | Waste paper      |
| Shaft                 | Stainless steel    | Scrap metal      |
| Flange                | Aluminium          | Scrap metal      |
| Housing               | Aluminium die cast | Scrap metal      |
| Electronic assemblies | Various            | Electronic waste |

### 3 Product description

This chapter provides information on the special features of the Absolute Encoder AFS60/AFM60 EtherCAT®. It describes the construction and the operating principle of the device.

- ▶ Please read this chapter before mounting, installing and commissioning the device.

#### 3.1 Specific features

Table 3: Special features of the encoder variants

| Features   | Singleturn encoder | Multiturn encoder |
|--|--------------------|-------------------|
| Absolute encoder in 60 mm design                       | ■                  | ■                 |
| Rugged nickel code disk for harsh ambient conditions   | ■                  | ■                 |
| High accuracy and availability                         | ■                  | ■                 |
| Large ball bearing distance of 30 mm                   | ■                  | ■                 |
| High vibration resistance                              | ■                  | ■                 |
| Optimum concentricity                                  | ■                  | ■                 |
| Compact design   | ■                  | ■                 |
| Face mount flange, servo flange and blind hollow shaft | ■                  | ■                 |
| 18 bit singleturn resolution (1 to 262,144 steps)      | ■                  | ■                 |
| 30 bit total resolution                                |                    | ■                 |
| 12-bit multiturn resolution (1 to 4,096 revolutions)   |                    | ■                 |
| Round axis functionality                               |                    | ■                 |
| Interface (according to IEC 61784-1)                   | ■                  | ■                 |
| Supports the encoder profile CiA DS-406                | ■                  | ■                 |

### 3.2 Operating principle of the encoder

Die Sensorik des Absolut-Encoders AFS60/AFM60 EtherCAT beruht auf absoluter Umdrehungserfassung ohne externe Versorgung und ohne Batterie. Dadurch kann der Encoder nach dem Ausschalten und anschließenden Wiedereinschalten sofort seine absolute Position ausgeben.

The Absolute Encoder detects the position and speed of rotary axes and outputs the position in the form of a unique digital numerical value. Optical detection takes place via an internal code disk.

#### The AFS60 is a singleturn encoder

Singleturn encoders are used when one shaft revolution must be detected absolutely.

#### The AFM60 is a multiturn encoder

Multiturn encoders are used when more than one shaft revolution must be detected absolutely.

#### 3.2.1 Scalable resolution

The steps per revolution or the total resolution can be scaled and adapted to the respective application.

The steps per revolution are scalable from 1 ... 262,144 in whole numbers. The total resolution of the AFM60 must be  $2^n$ -fold the steps per revolution. This restriction is not relevant if the round axis functionality is activated.

#### 3.2.2 Preset function

A preset value can be used to set the position value of the encoder. I. e. the encoder can be set to any position within the measuring range. This allows, for example, the zero position of the encoder to be aligned with the machine zero point.




Figure 1: Setting a preset value

- ① Setting a preset value
- ② When switching on again
- ③ Actual position value
- ④ Offset
- ⑤ Position value after preset
- ⑥ Position value after switching on again

When the encoder is switched off, the offset – the delta between the real position value and the value specified by preset – is saved. When switching on again, the new calculated position value is formed from the new real position value and the offset. Even if the encoder was turned further during the switched-off state, the correct position value is output as a result.

#### 3.2.3 Round axis functionality

The encoder supports the gear function for round axes. Here, the steps per revolution are set as a fraction (see "Round axis functionality", page 27). This allows a number that is not  $2^n$ -fold the steps per revolution or/and a decimal number (e.g. 12.5) to be configured as the total resolution.



#### NOTE

The output position value is calculated with a zero point correction, the set code sequence and the entered gear parameters.

#### Example with transmission ratio

A rotating table for filling bottles is to be controlled. The steps per revolution are specified by the number of fillers. There are nine fillers available. 1000 steps are required for precise measurement of the distance between two fillers.




Figure 2: Example of position measurement on a rotating table with transmission ratio

- ① Rotating table with nine fillers
- ② Diameter of round table: 125 cm
- ③ Encoder mounted on an axis together with the drive wheel.
- ④ Diameter of drive wheel: 10 cm

The number of revolutions is given by the transmission ratio of the rotating table drive ( $125/10 = 12.5$ ).

The total resolution is thus  $9 \times 1000 = 9000$  steps, to be realized in 12.5 revolutions of the encoder. This ratio cannot be realized via the steps per revolution and the total resolution, since the total resolution is not  $2^n$ -fold the steps per revolution.

The problem of the application can be solved with the round axis functionality. Here, the steps per revolution are disregarded. The total resolution and numerator and denominator of the number of revolutions are configured.

9000 steps are configured as the total resolution. The numerator of the number of revolutions is configured as 125, the denominator as 10 ( $125/10 = 12.5$ ).

After 12.5 revolutions (i.e. after one complete revolution of the rotating table), the encoder reaches the total resolution of 9000.

### Example without transmission ratio




Figure 3: Example of position measurement on a rotating table without transmission ratio

- ① Rotating table with nine fillers
- ② 1000 steps
- ③ Encoder

The encoder is mounted directly on the shaft of the rotating table. The transmission ratio is 1:1.

The rotating table has 9 fillers. The encoder is to be configured so that it starts counting with 0 at a filler position and counts up to 999 until the next filler position.

1000 steps are configured as the total resolution.

1 is configured as the numerator of the number of revolutions, 9 as the denominator (1/9 revolutions = 1000).

After 1/9 revolutions of the encoder shaft there are 1000 steps, then the encoder starts counting again at 0.

#### 3.2.4 Electronic cam mechanism

An electronic cam mechanism can be configured using the encoder. Two so-called CAM channels with up to eight cam switching positions are supported (①). This is a limit switch for the position.




Figure 4: Example electronic cam mechanism

Among other parameters, each cam has parameters for the lower switching point (②) and the upper switching point (③), which can be configured via EtherCAT (see ["Electronic cam mechanism", page 27](#)).

### 3.3 Integration in EtherCAT®

#### 3.3.1 EtherCAT® topology

EtherCAT supports a large variety of topologies such as line, tree, ring, star and their combinations.




Figure 5: EtherCAT topology

For this reason the AFS60/AFM60 EtherCAT® has two Ethernet interfaces for integration in an EtherCAT topology.




Figure 6: Two Ethernet interfaces on the encoder

An EtherCAT connection comprises to a large extent standardized Ethernet components. The slaves (e.g. the AFS60/AFM60 EtherCAT®) have an **EtherCAT® Slave Controller** for the communication with the master.

The EtherCAT® Slave Controller in the AFS60/AFM60 EtherCAT® reads the output data for the encoder and writes the input data for the PLC while the telegram is passing through. The process is implemented in hardware in the EtherCAT® Slave Controller and is therefore independent of the software cycle times of the protocol stack or the processor's performance.




Figure 7: Passage of the EtherCAT telegram

The last EtherCAT slave in the segment sends back the already completely processed telegram so that it is sent to the controller – as a quasi reply telegram.




Figure 8: Returning the EtherCAT telegram

### 3.3.2 EtherCAT® telegram in the Ethernet frame

EtherCAT is based on the standard Ethernet frame. This contains the Ethernet header, the Ethernet data and the Ethernet trailer. The EtherCAT telegram is transported directly in the Ethernet data using a specially standardized EtherCAT frame.




Figure 9: EtherCAT frame in the Ethernet frame

Data in the form of process data are exchanged between the master and slaves in the Ethernet frame. Each telegram has an address that refers to a specific slave or several slaves. The combination of data and address form an EtherCAT telegram.

- An Ethernet frame can contain several EtherCAT telegrams.
- Several Ethernet frames may be necessary for all the EtherCAT telegrams for a control cycle.

Each bus user has an addressable memory area of 64 kbyte in the telegram; data can be read, written or read and written simultaneously.



### 3.3.3 CANopen over EtherCAT® (CoE)

EtherCAT only defines a new protocol for the transport layer. It does not define its own user or device protocol. EtherCAT is able to transmit various already existing, tried and tested user protocols and device protocols via the EtherCAT protocol (tunneling).

For drive technology, e.g. CANopen over EtherCAT® (CoE) is relevant. This protocol is supported by the AFS60/AFM60 EtherCAT®. The CoE protocol makes it possible to use all CANopen profiles – and as a consequence also to utilize the encoder profile DS-406. You can see which objects of the encoder profile are implemented in the AFS60/AFM60 EtherCAT® (see ["Overview of the encoder profile-specific objects", page 39](#)).




Figure 10: CANopen over EtherCAT®

The EtherCAT protocol provides two different transfer rates for the transmission. These two transfer rates are the mailbox telegram protocol for acyclic data and the process data protocol for the transmission of cyclic data.

- Mailbox telegram protocol  
This transfer type is used to transmit the service data objects (SDO) defined under CANopen. The objects are transmitted in EtherCAT in SDO frames. The service data objects form the communication channel for the transmission of device parameters (e.g. programming the encoder resolution). These parameters are transmitted acyclically (e.g. only once on starting the network).
- Process data telegram protocol  
This type of transfer is used to transmit the process data objects (PDO) defined under CANopen that are used to exchange cyclic data. The objects are transmitted in EtherCAT in PDO frames. The process data objects are used for the quick and efficient exchange of real time data (e.g. I/O data, set or actual values).

#### 3.3.4 ESI file

To be able to simply interface EtherCAT slave devices to an EtherCAT master, an ESI file must be available for each EtherCAT slave device. This file is in XML format and contains information on the following features of the AFS60/AFM60 EtherCAT®.

- information on the manufacturer of the device
- name, type and version number of the device
- type and version number of the protocol used for this device
- default parameters of the AFS60/AFM60 EtherCAT® and default configuration of the process data




Figure 11: Integration via ESI file

- Copy the ESI file **SICK-AFx\_vX-xxx** in the TwinCAT® folder to the folder **TwinCAT\3.1\Config\Io\EtherCAT**.
- Restart the TwinCAT® system manager.
- Add the encoder in the device tree as a box.
- Then place the TwinCAT® system manager in the configuration mode.



#### NOTE

A detailed description of the configuration see ["System configuration"](#), page 65.

### 3.4 Configurable functions

The AFS60/AFM60 EtherCAT® is configured in the configuration tool TwinCAT® using various objects. The most important objects for the configuration of the functions are listed in the following. A complete list of the objects see "Object library", page 30.



**CAUTION**

**When parameterizing the encoder, make sure that there are no persons in the hazardous area of a system!**

All parameter changes directly affect the operation of the encoder. The position value can therefore change during parameterization, e.g., if a preset is executed or the scaling is changed. This could cause an unexpected movement that could endanger people or damage the system or other objects.



**NOTE**

The parameterization carried out is only written to the volatile memory in the encoder and is therefore not permanently saved. After a restart, the default settings stored in the encoder EEPROM are loaded. There are 2 options for permanently adopting the parameterization:

1. Expand the startup list to include the parameters to be changed.
2. Execute a Save command in the encoder to write the changed parameters to the encoder EEPROM.

**Startup list**

Recommended procedure:

If the parameters to be changed are added to the startup list, the corresponding entries are written to the encoder when the encoder is restarted. The advantage of this is that when an encoder is replaced, the individual settings are written directly to the new encoder and therefore no new encoder parameterization is required.

Example of default startup list (the existing 4 entries must not be deleted):




Figure 12: Example of default startup list

Example of startup list with changed scaling:




Figure 13: Example of startup list with changed scaling

**Save command (object 1010h)**

After parameterizing the encoder, it must be set to "Pre-Operational" mode via the control unit. The Save command must then be executed [see "Object 1010h – Save Parameter", page 32](#)

As the parameter changes are written directly to the encoder EEPROM, the settings are lost after an encoder replacement. A new encoder must then be parameterized again and a Save command must be sent.

**3.4.1 Scaling parameters**

The scaling parameters are configured using objects 6000h, 6001h and 6002h.




Figure 14: Objects 6000h, 6001h and 6002h in TwinCAT®

**6000h – Operating parameters**

Object **6000h** (see [table 31, page 40](#)) is used to configure the parameters **Support additional error code**, **scaling** and **Code sequence**. The object is parameterized via a 16-bit wide bit sequence.

**Example:**

Bit 0 = Code sequence ccw = 1

Bit 2 = Scaling on = 1

Table 4: Example of binary code

| Bit   | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-------|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Value | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 |

The binary value must be converted into a hexadecimal value and entered in the configuration dialog.

101b = 5h




Figure 15: Example of parameterization of object 6000h

### Scaling

Scaling allows the resolution per revolution or the total resolution to be scaled.



#### NOTE

The values entered for the resolution or total resolution are only adopted if the **Scaling** parameter is configured to **1**.

### Code sequence

The code sequence determines at which direction of rotation, starting from a viewing direction on the shaft, the position value increases.

- Clockwise (cw) = increasing position value when the shaft rotates clockwise
- Counterclockwise (ccw) = increasing position value when the shaft rotates counterclockwise

### 6001h – Counts Per Revolution (CPR)

Object 6001h (see table 33, page 41) is used to configure the resolution per revolution.



#### NOTE

The parameter is not used if the round axis functionality is activated.




Figure 16: Example of parameterization of object 6001h

The resolution of the AFS60/AFM60 EtherCAT® Advanced is max. 262,144 increments per revolution. The resolution is scalable on an integer basis from 1 ... 262,144.

**6002h – Total Measuring Range (CMR)**

Object **6002h** (see table 34, page 41) is used to configure the overall resolution.




Figure 17: Example of parameterization of object 6002h

The total resolution, i.e. the measuring range of the AFS60 EtherCAT®, is max. 262,144 increments. The total resolution of the AFM60 EtherCAT® is max. 1,073,741,824 increments.

The total resolution must be 2<sup>n</sup> times the resolution per revolution.



**NOTE**

This restriction is not relevant if the round axis functionality is activated.

Table 5: Examples for total resolution

| Resolution per revolution | n  | Total resolution |
|---------------------------|----|------------------|
| 1,000                     | 3  | 8,000            |
| 8,179                     | 5  | 261,728          |
| 2,048                     | 11 | 4,194,304        |

### 3.4.2 Preset function

The position value for an encoder can be set with the aid of the preset function. I.e. the encoder can be set to any position within the measuring range.



**NOTE**

- Only set a preset value when the encoder is at standstill.
- The preset value must lie within the measuring range configured.



**CAUTION**

**Before triggering the preset function, check whether there is a hazard from the machine or system in which the encoder is integrated!**

The preset function results in a change in the position value output by the encoder. This change could cause an unexpected movement that may result in a hazard for persons or damage to the system or other items.

The preset value can be set with the aid of the following methods:

- Using acyclic communication (SDO) with the object 6003h.
- Using cyclic communication (PDO) with the object 2000h. The value from object 2005h is used.
- Via the Preset pushbutton (see "Settings on the hardware", page 63). The value from object 2005h is used.

**Acyclic communication (SDO)**

The preset value is transferred directly to the encoder using the object **6003h – Preset Value** (see table 35, page 41). The encoder immediately adopts the preset value that is written to the object as the new position value.

The function is available if the EtherCAT® state machine is in the Operational or Preoperational status.




Figure 18: Example for the parameterization of object 6003h

**Cyclic communication (PDO)**

The preset value is initially transferred to the encoder using the object **2005h – Configuration Preset Value** (see table 73, page 52).




Figure 19: 0001 1000 0000 0000 bExample for the parameterization of object 2005h

The function is triggered using the object **2000h – Control Word 1** (see table 67, page 50).

The function is available if the EtherCAT® state machine is in the Operational status.

The object is configured using a bit sequence 16 bits wide.

**Example:**

Bit 12 = Preset is set = 1

Bit 11 = Preset-Modus Shift Positive = 1

Table 6: Example for binary code

| Bit  | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|
| Wert | 0  | 0  | 0  | 1  | 1  | 0  | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

The binary value must be converted into a hexadecimal value and entered in the configuration dialog box.

0001 1000 0000 0000 b = 1800h

**3.4.3 Cyclic process data**

The cyclic process data are defined using the process data objects **1A00h** and **1A01h** (see "PDO mapping objects", page 35). Nine objects can be mapped in nine subindices.






Figure 20: Default parameterization of object 1A00h




Figure 21: Example for the parameterization of subindex 1A00.01h

The object to be integrated is entered with its object number, the subindex and the data length (see table 25, page 36).

**Example:**

60040020h  
 Object = 6004h  
 Subindex = 00h  
 Data length = 20h (32 bit)

**3.4.4 Synchronization**

The default setting for the synchronization is synchronization using SM events; the setting can be changed to synchronization using DC sync events for high accuracy applications. This setting is made using the objects **1C32h** or **1C33h – SM-2/-3 Output Parameter** (see table 29, page 38).

- ▶ Select the required operating mode (SM or DC) in your control system.

#### 3.4.5 Speed measurement

The speed measurement is configured using the object **2002h – Speed Calculation Configuration** (see table 70, page 51).




Figure 22: Subindices of object 2002h




Figure 23: Example for the parameterization of subindex 2002.02h

Using the subindex **2002.02h – Format: Measuring Units** you can define the units in which the speed is transmitted.

Possible units are:

- cps
- cp10ms
- cp100ms
- rpm
- rps

The factory setting is 3h = rpm.

Using the other Subindices you can configure the refresh time as well as the maximum and minimum speed (see table 70, page 51).

### 3.4.6 Round axis functionality

The Round axis functionality removes the restriction that the total resolution must be 2<sup>n</sup> times the resolution per revolution. The shaft is considered as an **endless shaft**.

The resolution per revolution is not configured directly, instead the nominator and divisor for the number of revolutions are defined.

The Round axis functionality is configured using the object **2001h – Endless-Shaft Configuration** (see table 69, page 50).




Figure 24: Subindices of object 2001h

The total measuring range can be scaled from 1 ... 1,073,741,824 as an integer.

The nominator (2001.02h – Number of Revolutions, Nominator) can be scaled from 1 ... 2,048 as an integer. The default factory setting for the nominator is 2,048.

The divisor (2001.03h – Number of Revolutions, Divisor) can be scaled from 1 ... 2,048 as an integer. The default factory setting for the divisor is 1.




Figure 25: Example for the parameterization of subindex 2001.03h

### 3.4.7 Electronic cam mechanism

An electronic cam mechanism can be configured using the encoder. Two so-called CAM channels with up to eight cam switching positions are supported. This is a limit switch for the position.

The electronic cam mechanism is configured using several objects (see "Detailed information on the electronic cam mechanism (CAM)", page 42).

The cams are enabled using the object **6301h –CAM Enable Register**, the polarity is defined using the object **6302h – CAM Polarity Register**.

Each position parameter is defined by its minimum switching point (objects 6310h to 6317h), its maximum switching point (objects 6320h to 6327h) and its switching hysteresis (objects 6330h to 6337h).




Figure 26: Objects for the electronic cam mechanism

### 3.5 Operating modes and synchronization

#### 3.5.1 EtherCAT® State Machine

As in every EtherCAT slave, an EtherCAT® state machine is implemented in the AFS60/AFM60 EtherCAT®. This assumes the following status:

Table 7: Status of the EtherCAT® State Machine

| Status           | STAT status LED               | Description  |
|------------------|-------------------------------|--|
| Initializing     | Off                           | Initialization starts, saved values are loaded.  |
| Pre-Operational  | Flashing green (200 ms)       | The encoder is ready for parameterization, acyclical communication via SDO can take place. |
| Safe operational | Flashing green (200/1,000 ms) | The EtherCAT master reads the position values from the encoder via PDO and SDO.            |
| Operational      | Green                         | The EtherCAT master and encoder exchange data via PDO and SDO in real time.                |

The PLC usually carries out the start-up in the following sequence:

Initializing, Pre-Operational, Safe-Operational, Operational.

If the TwinCAT® software from Beckhoff Automation GmbH is used, these steps can be carried out automatically in the system manager or individually if required. If a control program is started in the TwinCAT®PLC, the start-up is executed automatically.

- The status of the EtherCAT® State Machine is displayed by the STAT status LED (see "NMOD, STAT and Encoder status LEDs", page 71).
- Errors during the transition between the states of the EtherCAT® state machine are transmitted to the master via so-called emergency messages (see "EtherCAT® specific errors", page 74).

### 3.5.2 Synchronous operating modes

In the **Operational** status the position is always determined in synchronism with the PSDI cycle for the bus communication. The default setting for the synchronization is synchronization using SM events; the setting can be changed to synchronization using DC sync events for high accuracy applications.



#### NOTE

- At cycle times in the range from 125 µs ... 480 µs the encoder status LED flashes green.
- If the system cycle time is outside the encoder's range limits (125 µs ... 100,000 µs), the encoder signals a bus communication error and the STAT status LED illuminates red (see "NMOD, STAT and Encoder status LEDs", page 71).

### 3.5.3 Cycle times

The AFS60/AFM60 EtherCAT® supports the following data exchange modes:

- standard data exchange
- fast data exchange

#### Standard data exchangeFast data exchange

In the standard data exchange the encoder supports process data cycle times of  $\geq 480$  µs.

A new position value is determined every 480 µs for the standard data exchange. This time is required to convert the measured value acquired optically by the sensor, to scale the value and to process it for EtherCAT.

If shorter cycle times are necessary, although the encoder can be used with this cycle, a newly calculated position can only be provided every 2nd, 3rd or 4th cycle. The position value calculated previously is sent for the other cycles.




Figure 27: Standard data exchange

- ① process data cycle of the master
- ② cycle of the encoder



**NOTE**

**Data exchange via SDOs not possible in the Operational status!**

In the fast data exchange the encoder’s EtherCAT® state machine must be switched back to the Pre-Operational status to be able to process SDOs.

In fast data exchange the encoder supports process data cycle times of  $\geq 240 \mu\text{s}$ .




Figure 28: Fast data exchange

- ① process data cycle of the master
- ② cycle of the encoder

Using the object **6000h** (see table 31, page 40) the parameter **Fast Data Exchange Mode** is configured.

### 3.6 Object library

The AFS60/AFM60 EtherCAT® contains various types of objects:

- standard objects with 1000 series object numbers
- manufacturer-specific objects with 2000 series object numbers
- encoder profile-specific objects with 6000 series object numbers

### 3.6.1 Nomenclature

Table 8: Nomenclature of the access types and data types

| Abbreviation | Meaning  |
|--------------|--|
| R            | Read = read only   |
| R/W          | Read/Write = read and write access   |
| STRG         | String = character string of variable length   |
| BOOL         | Boolean = logical value 0 or 1   |
| INT          | Integer value (negative/positive)<br>(e.g. INT-8 = -128 ... +127)                                  |
| UINT         | Unsigned Integer = integer value<br>(e.g. UINT-32 = 0 ... 4.294.967.295)                           |
| Array        | Series of data of one data type<br>(e.g. Array [UINT-8] = character string of data type<br>UINT-8) |
| Record       | Series of data with different data types<br>(e.g. UINT-8, UINT-32, INT-16)                         |

### 3.6.2 Overview of the standard objects

Table 9: Implemented standard objects

| ObjectSub-index     | Access | Data type        | Designation                                 |
|---------------------|--------|------------------|---|
| 1000h               | R      | UINT-32          | Device Type                                 |
| 1008h               | R      | STRG             | Device Name                                 |
| 1009h               | R      | STRG             | Hardware Version Number                     |
| 100Ah               | R      | STRG             | Software Version Number                     |
| 1010h<br>.0 ... .1  | R/W    | Array<br>UINT-32 | Save Parameters                             |
| 1011h<br>.0 ... .1  | R/W    | Array<br>UINT-32 | Load/Restore Parameter                      |
| 1018h<br>.0 ... .4  | R      | Record           | Identity                                    |
| 10F3h .0 ...<br>.25 | R/W    | Record           | Diagnosis History                           |
| 1600h<br>.0 and .1  | R/W    | Record           | 1 <sup>st</sup> Receive (Rx) PDO mapping    |
| 1A00h<br>.0 ... .9  | R/W    | Record           | 1 <sup>st</sup> Transmit (Tx) PDO mapping   |
| 1A01h<br>.0 ... .9  | R/W    | Record           | 2 <sup>nd</sup> Transmit (Tx) PDO mapping   |
| 1C00h<br>.0 ... .4  | R      | Array UINT-8     | Sync Manager Communication Type             |
| 1C12h<br>.0 ... .2  | R      | Record           | Sync Manager PDO Mapping for Sync channel 2 |
| 1C13h<br>.0 ... .2  | R      | Record           | Sync Manager PDO Mapping for Sync channel 3 |
| 1C32h<br>.0 ... .15 | R      | Record           | Sync Manager parameter                      |
| 1C33h<br>.0 ... .15 | R      | Record           | Sync Manager parameter                      |

#### 3.6.3 Detailed information on the standard objects



##### NOTE

In the following only those objects are described in detail for which the content is not clear from the overview (see table 9, page 31).

##### Objekt 1000h – Device Type

This object specifies the device type and the device profile implemented.

Table 10: Object 1000h

| Object | Access | Data type | Designation | Data values           |
|--------|--------|-----------|-------------|-----------------------|
| 1000h  | R      | UINT-32   | Device Type | see table 11, page 32 |

Table 11: Object 1000h – details

| Bit                 | Description   | Data values                            |
|---------------------|---|--|
| 31 ...<br>24        | The device type is output in the bits 31 ... 16.            | <b>01h</b> Singleturn encoder          |
| 23 ...<br>16        |   | <b>02h</b> Multiturn encoder           |
| 15 ... 8<br>7 ... 0 | The device profile supported is output in the bit 15 ... 0. | <b>01.96h</b> Device profile = Encoder |

##### Object 1008h – Manufacturer Device Name

The object contains the device name dependent on the encoder type.

Table 12: Object 1008h

| Object | Access | Data type       | Designation              | Data values                          |
|--------|--------|-----------------|--------------------------|--------------------------------------|
| 1008h  | R      | STRG<br>16 byte | Manufacturer Device Name | AFM60A-**E*18x12<br>AFS60A-**E*18x00 |

##### Object 1009h – Manufacturer Hardware Version

Table 13: Object 1009h

| Object | Access | Data type      | Designation                   | Datenwerte                                  |
|--------|--------|----------------|-------------------------------|---|
| 1009h  | R      | STRG<br>8 byte | Manufacturer Hardware Version | E.g. HW_01.01<br>(depending on the release) |

##### Object 100Ah – Manufacturer Software Version

Table 14: Object 100Ah

| Object | Access | Data type      | Designation                   | Data values                                 |
|--------|--------|----------------|-------------------------------|---|
| 100Ah  | R      | STRG<br>8 byte | Manufacturer Software Version | E.g. UP1_1.03<br>(depending on the release) |

##### Object 1010h – Save Parameter

Using this object the parameters are written to the EEPROM with the aid of the data value 65766173h = “save”.





**CAUTION**

**Check whether the parameters have actually been written to the EEPROM!**

The data are only written to the EEPROM in the ESM status Pre-Operational. The command is not executed in any other status, but it is also not identified as denied.

- ▶ Check whether the parameters have been saved using the object **2010h – Sensor Status S\_STAT-C** (see table 78, page 55).

If the data are not saved in the EEPROM, the encoder loads the data last saved the next time the encoder is switched on. This situation can result in hazards for persons or damage to the system!

Table 15: Object 1010h

| Object Subindex | Access | Data type | Designation Description   | Data values                           |
|-----------------|--------|-----------|---|---------------------------------------|
| <b>1010h</b>    | R/W    | Record    | Save Parameter  | -                                     |
| .0              | R/W    | UINT-8    | Number of entries   | 1                                     |
| .1              | R/W    | UINT-32   | Total Class Parameters<br>The parameters for all object types (1000h ..., 2000h ... and 6000h ...) are saved. | <a href="#">see table 16, page 33</a> |

Table 16: Object 1010h – details

| Bit       | Designation | Data values |
|-----------|-------------|-------------|
| 31 ... 24 | Byte 3      | 65h = e     |
| 23 ... 16 | Byte 2      | 76h = v     |
| 15 ... 8  | Byte 1      | 61h = a     |
| 7 ... 0   | Byte 0      | 73h = s     |

**Object 1011h – Load/Restore Parameter**

Using this object the parameters are reset to the factory settings with the aid of the data value 64616F6Ch = “load”.



**NOTE**

- The data are only reset to the factory settings in the Pre-operational status. The command is not executed in any other status, but it is also not identified as denied.
- Then the data must be saved in the EEPROM using the object **1010h – Save Parameter**, otherwise the encoder will load the data saved in the EEPROM the next time it is switched on.

Table 17: Object 1011h

| Object Subindex | Access | Data type | Designation Description  | Data values                           |
|-----------------|--------|-----------|--|---------------------------------------|
| <b>1011h</b>    | R/W    | Record    | Load/Restore Parameter   | -                                     |
| .0              | R/W    | UINT-8    | Number of entries  | 1                                     |
| .1              |        | UINT-32   | Total Class Parameters<br>The parameters for all object types (1000h ..., 2000h ... and 6000h ...) are loaded. | <a href="#">see table 18, page 34</a> |

Table 18: Object 1011h – details

| Bit       | Designation | Data values |
|-----------|-------------|-------------|
| 31 ... 24 | Byte 3      | 64h = d     |
| 23 ... 16 | Byte 2      | 61h = a     |
| 15 ... 8  | Byte 1      | 6Fh = o     |
| 7 ... 0   | Byte 0      | 6Ch = l     |

#### Object 1018h – Identity Object

Table 19: Object 1018h

| Object Subindex | Access | Data type | Designation Description                                    | Data values                                   |
|-----------------|--------|-----------|--|---|
| <b>1018h</b>    | R      | Record    | Identity Object  | -   |
| .0              | R      | UINT-8    | Number of entries  | 4   |
| .1              | R      | UINT-32   | Vendor ID  | 01000056h = SICK                              |
| .2              | R      | UINT-32   | Product Code   | 00007711h = AFS60<br>00007712h = AFM60        |
| .3              | R      | UINT-32   | Revision Number  | 00010001 = 1.01<br>(depending on the release) |
| .4              | R      | UINT-32   | Serial Number<br>JJWWxxxx<br>(year/week/sequential number) | Serial number                                 |

#### Object 10F1h – Diagnosis Error Reaction

Table 20: Object 10F1h

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| <b>10F1h</b>    | R/W    | Record    | Diagnosis Error Reaction  | -           |
| .0              | R      | UINT-8    | Number of entries   | 2           |
| .1              | R      | UINT-32   | Defines error handling  | 0           |
| .2              | R      | UINT-32   | Sync Error Count Limit<br>Limit of the counter for synchronization errors | 0           |

#### Object 10F3h – Diagnosis History

Table 21: Object 10F3h

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| <b>10F3h</b>    | R/W    | Record    | Diagnosis History   | -           |
| .0              | R      | UINT-8    | Number of entries   | 25          |
| .1              | R      | UINT-8    | Maximum Messages<br>Number of entries in subindex .6 ... .25            | 20          |
| .2              | R      | UINT-8    | Newest Message<br>Subindex of the newest entry                          | 6 ... 25    |
| .3              | R      | UINT-8    | Newest Acknowledged Message<br>Subindex for the last entry acknowledged | 6 ... 25    |

| Object Subindex | Access | Data type | Designation Description   | Data values                       |
|-----------------|--------|-----------|---|-----------------------------------|
| .4              | R/W    | BOOL      | New Message Available<br>Shows that a new entry is available                | 0 = No new entry<br>1 = New entry |
| .5              | R      | UINT-16   | Flags<br>Flags for the indication of the transmission and storage of errors | 0                                 |
| .6 ... .25      | R/W    | OCTETSTR  | Diagnostics message, defined as octet character string                      | see "Error messages", page 78     |

### 3.6.4 PDO mapping objects

The PDO mapping objects are used to “map” other objects in the subindices and to transmit these to the controller or to receive them from the controller.

- Data are received cyclically from the PLC by the encoder using the Receive (Rx) PDO.
- Data are transmitted cyclically to the PLC by the encoder using the Transmit (Tx) PDO.



**NOTE**

Parameter changes to the PDO mapping objects are only executed in the ESM status Pre-Operational.

#### Object 1600h – 1<sup>st</sup> Receive (Rx) PDO mapping



**NOTE**

It is only possible to map the object **2000h – Control Word 1** to the object 1600h.

Table 22: Object 1600h

| Object Subindex | Access | Data type | Designation Description                              | Data values |
|-----------------|--------|-----------|--|-------------|
| <b>1600h</b>    | R/W    | RECORD    | 1 <sup>st</sup> Receive (Rx) PDO mapping             | -           |
| .0              | R      | UINT-8    | Anzahl der Einträge                                  | 1           |
| .1              | R/W    | UINT-32   | Control Word 1<br>see table 67, page 50 auf Seite 55 | 20.00.00.10 |

#### Object 1A00h – 1<sup>st</sup> Transmit (Tx) PDO mapping

Table 23: Object 1A00h – default subindices

| Object Subindex | Access | Data type | Designation                                   |
|-----------------|--------|-----------|---|
| <b>1A00h</b>    | R/W    | RECORD    | 1 <sup>st</sup> Transmit (Tx) PDO mapping     |
| .0              | R/W    | UINT-8    | Number of entries                             |
| .1              | R/W    | UINT-32   | 6004h Position Value                          |
| .2              | R/W    | UINT-32   | 6503h Alarm Status                            |
| .3              | R/W    | UINT-32   | 6505h Warning Status                          |
| .4              | R/W    | UINT-32   | 2010.01h STW-1 – Device Status Word, S_STAT-A |
| .5              | R/W    | UINT-32   | 2018.02h Time Stamp Sec                       |

| Object Subindex | Access | Data type | Designation              |
|-----------------|--------|-----------|--------------------------|
| .6              | R/W    | UINT-32   | 2018.01h Time Stamp MSec |
| .7              | R/W    | UINT-32   | 2015h Temperature Value  |
| .8              | R/W    | UINT-32   | 2019h Process Cycle Time |
| .9              | R/W    | UINT-32   | 6030h Speed Value 16-Bit |

#### Object 1A01h – 2<sup>nd</sup> Transmit (Tx) PDO mapping

Table 24: Object 1A01h – default subindices

| Object Subindex | Access | Data type | Designation                                   |
|-----------------|--------|-----------|---|
| <b>1A01h</b>    | R/W    | RECORD    | 2 <sup>nd</sup> Transmit (Tx) PDO mapping     |
| .0              | R/W    | UINT-8    | Number of entries                             |
| .1              | R/W    | UINT-32   | 10F3.04h Diagnosis History, Diagnosis Flag    |
| .2              | R/W    | UINT-32   | 2017h Speed Value 32-Bit                      |
| .3              | R/W    | UINT-32   | 2016h Position Value, Raw                     |
| .4              | R/W    | UINT-32   | 2010.02h STW-1 – Device Status Word, S_STAT-B |
| .5              | R/W    | UINT-32   | 2010.03h STW-1 – Device Status Word, S_STAT-C |
| .6              | R/W    | UINT-32   | 6300.01h CAM State Register, Channel 1        |
| .7              | R/W    | UINT-32   | 6300.02h CAM State Register, Channel 2        |
| .8              | R/W    | UINT-32   | 2014h Time Stamp Counter                      |
| .9              | -      | -         | -   |

#### Objects and subindices that can be mapped to the objects 1A00h and 1A01h

Table 25: Objects and subindices that can be mapped

| Object Subindex                | Length [Bit]   | Designation  | Data values                         | Details see                           |
|--------------------------------|----------------|--|-------------------------------------|---------------------------------------|
| <b>6004h</b>                   | 32             | Position Value   | 60040020h                           | <a href="#">see table 36, page 42</a> |
| <b>6030h</b><br>.1             | 16             | Speed Value  | 60300110h                           | <a href="#">see table 37, page 42</a> |
| <b>6503h</b>                   | 16             | Alarm Status   | 65030010h                           | <a href="#">see table 51, page 46</a> |
| <b>6505h</b>                   | 16             | Warning Status   | 65050010h                           | <a href="#">see table 55, page 47</a> |
| <b>6300h</b><br>.1<br>.2       | 8<br>8         | CAM State Register<br>Channel 1<br>Channel 2                   | 63000108h<br>63000208h              | <a href="#">see table 38, page 42</a> |
| <b>2010h</b><br>.1<br>.2<br>.3 | 16<br>16<br>16 | STW-1 – Device Status Word<br>S_STAT-A<br>S_STAT-B<br>S_STAT-C | 20100110h<br>20100210h<br>20100310h | <a href="#">see table 75, page 53</a> |
| <b>10F3h</b><br>.4             | 8              | Diagnosis History<br>Diagnosis Flag                            | 10F30408h                           | <a href="#">see table 21, page 34</a> |
| <b>2014h</b>                   | 32             | Time Stamp Counter   | 20140020h                           | <a href="#">see table 82, page 58</a> |
| <b>2015h</b>                   | 16             | Temperature Value  | 20150010h                           | <a href="#">see table 83, page 58</a> |

| Object Subindex   | Length [Bit] | Designation   | Data values            | Details see                           |
|-------------------|--------------|---|------------------------|---------------------------------------|
| 2016h             | 32           | Position Value, Raw                                     | 20160020h              | <a href="#">see table 84, page 59</a> |
| 2017h             | 32           | Speed Value 32-Bit                                      | 20170020h              | <a href="#">see table 85, page 59</a> |
| 2018h<br>.1<br>.2 | 16<br>16     | Time Stamp Signals<br>Time Stamp MSec<br>Time Stamp Sec | 20180110h<br>20180210h | <a href="#">see table 86, page 59</a> |
| 2019h             | 32           | Process Cycle Time                                      | 20190020h              | <a href="#">see table 87, page 59</a> |

**Object 1C00h – Sync Manager (SM) Communication Type**

The number of communication channels and the type of communication are defined using this object.

The entries are read-only. The communication channels are configured automatically on starting the EtherCAT master.

Table 26: Object 1C00h

| Object Subindex | Access | Data type | Designation Description   | Data values                          |
|-----------------|--------|-----------|---|--------------------------------------|
| 1C00h           | R      | Array     | Sync Manager (SM) Communication Type                                      | -                                    |
| .0              | R      | UINT-8    | Number of entries   | 4                                    |
| .1              | R      | UINT-8    | Communication type sync manager 0<br>Communication type of Sync Manager 0 | 1: Receive mailbox (master to slave) |
| .2              | R      | UINT-8    | Communication type sync manager 1<br>Communication type of Sync Manager 1 | 2: Send mailbox (slave to master)    |
| .3              | R      | UINT-8    | Communication type sync manager 2<br>Communication type of Sync Manager 2 | 3: Receive (Rx) PDO                  |
| .4              | R      | UINT-8    | Communication type sync manager 3<br>Communication type of Sync Manager 3 | 4: Transmit (Tx) PDO                 |

**Object 1C12h – SM RxPDO assign**

This object is used to allocate sync channel 2 to a PDO (channel 2 is reserved for Receive PDOs).

Table 27: Object 1C12h

| Object Subindex | Access | Data type | Designation       | Data values |
|-----------------|--------|-----------|-------------------|-------------|
| 1C12h           | R      | Record    | SM RxPDO assign   | -           |
| .0              | R      | UINT-8    | Number of entries | 1           |

| Object Subindex | Access | Data type | Designation  | Data values |
|-----------------|--------|-----------|--|-------------|
| .1              | R      | UINT-16   | PDO mapping object index of assigned RxPDO<br>Index des RxPDOs | 1600h       |

#### Object 1C13h – SM TxPDO assign

This object is used to allocate sync channel 3 to a PDO (channel 3 is reserved for Transmit PDOs).

Table 28: Object 1C13h

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| <b>1C13h</b>    | R      | Record    | SM TxPDO assign   | -           |
| .0              | R      | UINT-8    | Number of entries   | 2           |
| .1              | R      | UINT-16   | PDO mapping object index of assigned TxPDO 1<br>Index of the 1. TxPDO | 1A00h       |
| .2              | R      | UINT-16   | PDO mapping object index of assigned TxPDO 2<br>Index of the 2. TxPDO | 1A01h       |

#### Objects 1C32h and 1C33h – SM-2/-3 Output Parameter

Table 29: Objects 1C32h and 1C33h

| Object Subindex         | Access     | Data type | Designation Description  | Data values |
|-------------------------|------------|-----------|--|-------------|
| <b>1C32h/<br/>1C33h</b> | R          | Record    | SM-2/-3 Output Parameter   | -           |
| .0                      | R          | UINT-8    | Number of entries  | 32          |
| .1                      | R/W        | UINT-16   | Sync Mode<br><br><b>00h</b> Free Run (no synchronization)<br><b>01h</b> Synchronous with SM-3 event<br><b>22h</b> Synchronous with SM-2 event<br><b>02h</b> DC mode, synchronous with Sync0 event                | -           |
| .2                      | R oder R/W | UINT-32   | Cycle time<br>Dependent of the sync mode<br>Value in ns  | -           |
| .3                      | R          | UINT-32   | Shift Time   | -           |
| .4                      | R          | UINT-16   | Sync modes supported<br>Supported synchronization types<br><br>Bit 0: Free Run<br>Bit 1: Sync SM event<br>Bit 4 ... 2: Sync mode <sup>1)</sup><br>Bit 6 ... 5: Shift mode <sup>2)</sup><br>Bit 15 ... 7:Reserved | -           |
| .5                      | R          | UINT-32   | Minimum Cycle Time<br>Minimum cycle time (in ns)   | -           |

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| .6              | R      | UINT-32   | Calc and Copy Time<br>Time between reading the inputs and the availability of the inputs for the master (in ns, DC mode only)                           | -           |
| .7              |        | -         | -   | -           |
| .8              | R/W    | UINT-16   | Get Cycle Time  | -           |
| .9              | R      | UINT-32   | Delay Time<br>Time between Sync1 event and reading the inputs (in ns, DC mode only)   | -           |
| .10             | R      | UINT-32   | Sync0 Cycle Time  | -           |
| .11             | R      | UINT-16   | Cycle Time Too Small<br>Number of cycle time infringements in the Operational status (cycle was not completed on time or the next cycle came too early) | -           |
| .12             | R      | UINT-16   | SM Event Missed<br>Number of failed SM events in the Operational status (DC mode only)  | -           |
| .13             | R      | UINT-16   | Shift Time Too Short<br>Number of excessively short spaces between Sync0 and Sync1 events (DC mode only)  | -           |
| .14             | R      | UINT-16   | RxPDO Toggle Failed   | -           |
| .15 ... .31     |        | -         | Reserved  | -           |
| .32             | R      | -         | Sync Error  | -           |

- 1 For Bit 4 ... 2 only the value 001 = Sync0 event is supported.
- 2 For Bit 6 ... 5 only the value 00 = no shift is supported.

### 3.6.5 Overview of the encoder profile-specific objects

Table 30: Implemented encoder profile specific objects

| Object Subindex    | Access | Data type           | Designation                      |
|--------------------|--------|---------------------|----------------------------------|
| 6000h              | R/W    | UINT-16             | Operating Parameter              |
| 6001h              | R/W    | UINT-32             | Counts Per Revolution (CPR)      |
| 6002h              | R/W    | UINT-32             | Counts per Measuring Range (CMR) |
| 6003h              | R/W    | UINT-32             | Preset Value                     |
| 6004h              | R      | UINT-32             | Position Value                   |
| 6030h<br>.0 ... .1 | R      | Array of<br>UINT-16 | Velocity/Speed Value             |
| 6300h<br>.0 ... .2 | R      | Array of<br>UINT-8  | CAM State Register               |
| 6301h<br>.0 ... .2 | R/W    | Array of<br>UINT-8  | CAM Enable Register              |
| 6302h<br>.0 ... .2 | R/W    | Array of<br>UINT-8  | CAM Polarity Register            |

| Object Subindex                 | Access | Data type        | Designation  |
|---------------------------------|--------|------------------|--|
| 6310h ...<br>6317h<br>.0 ... .2 | R/W    | Array of UINT-32 | CAM-1 ... 8 - Lower Limit setting                        |
| 6320h ...<br>6327h<br>.0 ... .2 | R/W    | Array of UINT-32 | CAM-1 ... 8 - Upper Limit setting                        |
| 6330h ...<br>6337h<br>.0 ... .2 | R/W    | Array of UINT-16 | CAM-1 ... 8 - Hysteresis setting                         |
| 6500h                           | R      | UINT-16          | Operating Status   |
| 6501h                           | R      | UINT-32          | Physical Resolution Span (PRS)<br>Single Turn Resolution |
| 6502h                           | R      | UINT-16          | Number of Revolutions                                    |
| 6503h                           | R      | UINT-16          | Alarms   |
| 6504h                           | R      | UINT-16          | Supported Alarms   |
| 6505h                           | R      | UINT-16          | Warnings   |
| 6506h                           | R      | UINT-16          | Supported Warnings                                       |
| 6507h                           | R      | UINT-32          | Version Of Profile & Software                            |
| 6508h                           | R      | UINT-32          | Operating Time   |
| 6509h                           | R      | INT-32           | Offset Value   |
| 650Ah<br>.0 ... .3              | R      | Array of UINT-32 | Module Identification                                    |
| 650Bh                           | R      | UINT-32          | Serial Number  |

#### 3.6.6 Detailed information on the encoder parameters

##### Object 6000h – Operating parameters

Table 31: Object 6000h

| Object | Access | Data type | Designation          | Data values                           |
|--------|--------|-----------|----------------------|---------------------------------------|
| 6000h  | R/W    | UINT-16   | Operating parameters | <a href="#">see table 32, page 40</a> |

Table 32: Object 6000h – Details

| Bit       | Designation Description  | Data values   |
|-----------|--|---------------|
| 15        | Fast Data Exchange Mode  | 0 No<br>1 Yes |
| 14 ... 13 | Reserved   | -             |
| 12        | Activation of object 2022h Absolute Diagnosis Service Parameter<br>To activate object 2022h, the following steps must be carried out:<br><br>1. Object 6000h Set bit 12 to 1<br>2. Execute the "Save Parameter" operation (object 1010h)<br>3. Performing a reset or restart<br><br>Object 2022h then becomes visible in the object library. | 0 No<br>1 Yes |
| 11 ... 3  | Reserved   | -             |



| Bit | Designation Description  | Data values |            |
|-----|--|-------------|------------|
| 2   | Scaling<br>The bit enables scaling with objects 6001h and 6002h.   | 0           | Not active |
|     |  | 1           | Active     |
| 1   | Commissioning Diagnostic Control is not supported  | -           |            |
| 0   | Code sequence (cw, ccw)<br>The code sequence determines at which direction of rotation, starting from a viewing direction on the shaft, the position value increases. <ul style="list-style-type: none"> <li>• Clockwise = Increasing position value when shaft is rotated clockwise</li> <li>• Counterclockwise = Increasing position value when shaft is rotated counterclockwise</li> </ul> | 0           | cw         |
|     |  | 1           | ccw        |

### Object 6001h – Counts Per Revolution (CPR)

This parameter is used to configure the resolution per revolution.



#### NOTE

The parameter is not used if the round axis functionality is activated.

Table 33: Object 6001h

| Object | Access | Data type | Designation Description  | Data values (default value)           |
|--------|--------|-----------|--|---------------------------------------|
| 6001h  | R      | UINT-32   | Counts Per Revolution (CPR)<br>Number of increments per revolution | 00000001h<br>00040000h<br>(00040000h) |

### Object 6002h – Total Measuring Range (CMR)

Table 34: Object 6002h

| Object | Access | Data type | Designation Description                         | Data values     |
|--------|--------|-----------|---|-----------------|
| 6002h  | R      | UINT-32   | Total Measuring Range (CMR)<br>Total resolution | Depends on type |

### Object 6003h – Preset Value

This parameter is used to set the position value of the encoder to a preset value. This allows, for example, the zero position of the encoder to be aligned with the machine zero point.

Table 35: Object 6003h

| Object | Access | Data type | Designation Description      | Data values |
|--------|--------|-----------|------------------------------|-------------|
| 6003h  | R/W    | UINT-32   | Preset value<br>Preset value | -           |



#### NOTE

- When the value is written to the object, it is immediately adopted as the new position value.
- The preset value must be within the configured measuring range.

#### Object 6004h – Position Value

This object can be used to read out the current position value.

Table 36: Object 6004h

| Object | Access | Data type | Designation Description                  | Data values |
|--------|--------|-----------|--|-------------|
| 6004h  | R      | UINT-32   | Position Value<br>Current position value | -           |



#### NOTE

Instead of the position value, an error code (Err\_PosVal) can also be output (see table 76, page 53). The output of the Err\_PosVal must be configured with object 6000h (see table 31, page 40).

#### Object 6030h – Speed Value

This object can be used to read out the current speed.

Table 37: Object 6030h

| Object | Access | Data type    | Designation Description        | Data values        |
|--------|--------|--------------|--------------------------------|--------------------|
| 6030h  | R      | Array INT-16 | Speed Value                    | -                  |
| .0     | R      | INT-16       | Number of entries              | 1                  |
| .1     | R      | INT-16       | Speed Value<br>Speed in 16 bit | -32,768<br>+32,767 |

### 3.6.7 Detailed information on the electronic cam mechanism (CAM)

A so-called electronic cam mechanism can be configured using the encoder. One CAM channel with up to eight cam switching positions is supported. Each position parameter is defined by its minimum switching point (objects 6310h to 6317h), its maximum switching point (objects 6320h to 6327h) and its switching hysteresis (objects 6330h to 6337h).

#### Object 6300h – CAM State Register

The cam switching states are output using the object 6300h.

Table 38: Object 6300h

| Object Subindex | Access | Data type    | Designation        | Data values |
|-----------------|--------|--------------|--------------------|-------------|
| 6300h           | R      | Array UINT-8 | CAM State Register | -           |
| .0              | R      | UINT-8       | Number of entries  | 2           |
| .1              | R      | UINT-8       | Channel 1          | 00h<br>FFh  |
| .2              | R      | UINT-8       | Channel 2          | 00h<br>FFh  |

Table 39: Object 6300h – details

| Bit | Designation | Data values              |
|-----|-------------|--------------------------|
| 7   | Cam 8       | 0 Not active<br>1 Active |
| 6   | Cam 7       | 0 Not active<br>1 Active |
| 5   | Cam 6       | 0 Not active<br>1 Active |

| Bit | Designation | Data values |            |
|-----|-------------|-------------|------------|
| 4   | Cam 5       | 0           | Not active |
|     |             | 1           | Active     |
| 3   | Cam 4       | 0           | Not active |
|     |             | 1           | Active     |
| 2   | Cam 3       | 0           | Not active |
|     |             | 1           | Active     |
| 1   | Cam 2       | 0           | Not active |
|     |             | 1           | Active     |
| 0   | Cam 1       | 0           | Not active |
|     |             | 1           | Active     |

If, for instance, the value read is 01h (00000001b), then cam 1 is active. None of the other cams are active. If, for instance, the value read is 88h (10001000b), then cams 8 and 4 are active. None of the other cams are active.

**Object 6301h – CAM Enable Register**

Each cam switching position on the CAM channel must be enabled individually in the encoder. The individual cams are enabled by writing the appropriate value to the object 6301h, subindex .1 or subindex .2.

Every cam switching position that is to be used must be set to 1 in binary notation.

Table 40: Object 6301h

| Object Subindex | Access | Data type    | Designation         | Data values |
|-----------------|--------|--------------|---------------------|-------------|
| 6301h           | R/W    | Array UINT-8 | CAM Enable Register | -           |
| .0              | R      | UINT-8       | Number of entries   | 2           |
| .1              | R/W    | UINT-8       | Channel 1           | 00h<br>FFh  |
| .2              | R/W    | UINT-8       | Channel 2           | 00h<br>FFh  |

Table 41: Object 6301h – details

| Bit | Designation | Data values |          |
|-----|-------------|-------------|----------|
| 7   | Cam 8       | 0           | Not used |
|     |             | 1           | Used     |
| 6   | Cam 7       | 0           | Not used |
|     |             | 1           | Used     |
| 5   | Cam 6       | 0           | Not used |
|     |             | 1           | Used     |
| 4   | Cam 5       | 0           | Not used |
|     |             | 1           | Used     |
| 3   | Cam 4       | 0           | Not used |
|     |             | 1           | Used     |
| 2   | Cam 3       | 0           | Not used |
|     |             | 1           | Used     |
| 1   | Cam 2       | 0           | Not used |
|     |             | 1           | Used     |
| 0   | Cam 1       | 0           | Not used |
|     |             | 1           | Used     |

If, for instance 4Ah (01001010b) is transmitted in the subindex, the cams 2, 4 and 7 are used. All other cams are not used.

**Object 6302h – CAM Polarity Register**

Using the CAM Polarity Register it can be defined whether the cams are output as active high or active low. By default the cams are defined as active high. They therefore output 1 when the cam switching position is reached.

Table 42: Object 6302h

| Object Subindex | Access | Data type    | Designation           | Data values |
|-----------------|--------|--------------|-----------------------|-------------|
| <b>6302h</b>    | R/W    | Array UINT-8 | CAM Polarity Register | -           |
| .0              | R      | UINT-8       | Number of entries     | 2           |
| .1              | R/W    | UINT-8       | Channel 1             | 00h<br>FFh  |
| .2              | R/W    | UINT-8       | Channel 2             | 00h<br>FFh  |

Table 43: Object 6301h – details

| Bit | Designation | Data values                   |
|-----|-------------|-------------------------------|
| 7   | Cam 8       | 0 High active<br>1 Low active |
| 6   | Cam 7       | 0 High active<br>1 Low active |
| 5   | Cam 6       | 0 High active<br>1 Low active |
| 4   | Cam 5       | 0 High active<br>1 Low active |
| 3   | Cam 4       | 0 High active<br>1 Low active |
| 2   | Cam 3       | 0 High active<br>1 Low active |
| 1   | Cam 2       | 0 High active<br>1 Low active |
| 0   | Cam 1       | 0 High active<br>1 Low active |

**Objects 6310h ... 6317h – CAM-1 ... 8, Lower Limit**

The lower switching point of a cam switching position is defined using the Lower Limit. Each individual cam switching position (CAM 1 to CAM 8) has its own Lower Limit object (6310h = cam 1 ... 6317h = cam 8).



**NOTE**

- The Lower Limit can only be configured, i.e., its value changed, if the Upper Limit for the same CAM has already been set (see table 45, page 45).
- The value for the Lower Limit must be lower than the value for the Upper Limit.

Table 44: Object 6310h ... 6317h

| Object Subindex        | Access | Data type     | Designation              | Data values (default value)    |
|------------------------|--------|---------------|--------------------------|--------------------------------|
| <b>6310h ... 6317h</b> | R/W    | Array UINT-32 | CAM-1 ... 8, Lower Limit | -                              |
| .0                     | R      | UINT-32       | Number of entries        | 2                              |
| .1                     | R/W    | UINT-32       | Channel 1                | 0 ... PMR <sup>1</sup> – 1 (0) |

| Object Subindex | Access | Data type | Designation | Data values (default value)    |
|-----------------|--------|-----------|-------------|--------------------------------|
| .2              | R/W    | UINT-32   | Channel 2   | 0 ... PMR <sup>1</sup> - 1 (0) |

<sup>1</sup> Physical measuring range, depending on the encoder type.

### Objects 6320h ... 6327h – CAM-1 ... 8, Upper Limit

The upper switching point for a cam switching position is defined using the Upper Limit. Each individual cam switching position (CAM 1 to CAM 8) has its own Upper Limit object (6320h = cam 1 ... 6327h = cam 8).

Table 45: Object 6320h ... 6327h

| Object Subindex | Access | Data type        | Designation              | Data values (default value)             |
|-----------------|--------|------------------|--------------------------|---|
| 6320h ... 6327h | R/W    | Array<br>UINT-32 | CAM-1 ... 8, Upper Limit | -                                       |
| .0              | R      | UINT-32          | Number of entries        | 2                                       |
| .1              | R/W    | UINT-32          | Channel 1                | 0 ... PMR <sup>1</sup> - 1<br>(PMR - 1) |
| .2              | R/W    | UINT-32          | Channel 2                | 0 ... PMR <sup>1</sup> - 1<br>(PMR - 1) |

<sup>1</sup> Physical measuring range, depending on the encoder type.

### Objects 6330h ... 6337h – CAM-1 ... 8, Hysteresis

The width of the hysteresis of the switching points can be defined using the CAM hysteresis. For each individual cam switching position (CAM 1 to CAM 8) a dedicated CAM hysteresis can be set (6330h = cam 1 ... 6337h = cam 8).

Table 46: Object 6330h ... 6337h

| Object Subindex | Access | Data type        | Designation             | Data values    |
|-----------------|--------|------------------|-------------------------|----------------|
| 6330h ... 6337h | R/W    | Array<br>UINT-16 | CAM-1 ... 8, Hysteresis | -              |
| .0              | R      | UINT-16          | Number of entries       | 2              |
| .1              | R/W    | UINT-16          | Channel 1               | 0000h<br>FFFFh |
| .2              | R/W    | UINT-16          | Channel 2               | 0000h<br>FFFFh |

## 3.6.8 Detailed information on the diagnostics

### Object 6500h – Operating Status

Table 47: Object 6500h

| Object | Access | Data type | Designation      | Data values                           |
|--------|--------|-----------|------------------|---------------------------------------|
| 6500h  | R      | UINT-16   | Operating Status | <a href="#">see table 48, page 45</a> |

Table 48: Object 6500h – details

| Bit       | Designation                   | Data values   |
|-----------|-------------------------------|---------------|
| 15 ... 13 | Reserved                      | -             |
| 12        | Support additional error code | 0 No<br>1 Yes |
| 11 ... 3  | Reserved                      | -             |

| Bit | Designation                      | Data values |            |
|-----|----------------------------------|-------------|------------|
| 2   | Scaling                          | 0           | Not active |
|     |                                  | 1           | Active     |
| 1   | Commissioning diagnostic control | 0           | Not active |
|     |                                  | 1           | Active     |
| 0   | Code sequence (cw, ccw)          | 0           | cw         |
|     |                                  | 1           | ccw        |

#### Object 6501h – PRS, Single Turn Resolution

Table 49: Object 6501h

| Object | Access | Data type | Designation<br>Description                           | Data values |
|--------|--------|-----------|--|-------------|
| 6501h  | R      | UINT-32   | PRS, Single Turn Resolution<br>Singleturn resolution | 00040000h   |

#### Object 6502h – Number of Revolutions

Table 50: Object 6502h

| Object | Access | Data type | Designation<br>Description                    | Data values                |
|--------|--------|-----------|---|----------------------------|
| 6502h  | R      | UINT-16   | Number of Revolutions<br>Multiturn resolution | AFS = 0001h<br>AFM = 4.096 |

#### Object 6503h – Alarm Status

Table 51: Object 6503h

| Object | Access | Data type | Designation<br>Description  | Data values    |
|--------|--------|-----------|---|----------------|
| 6503h  | R      | UINT-16   | Alarm Status<br>Alarms in case of encoder errors that could result in an incorrect position value | 0000h<br>FFFFh |

Table 52: Object 6503h – details

| Bit       | Bezeichnung   | Datenwerte |            |
|-----------|---|------------|------------|
| 15 ... 13 | Reserved  | -          |            |
| 12        | EEPROM error<br>Dependent of Bit 15 and 7 of object 2010h .1 (see <a href="#">table 76, page 53</a> )             | 0          | Not active |
|           |   | 1          | Active     |
| 11 ... 1  | Reserved  | -          |            |
| 0         | Position error<br>Dependent of Bit 14, 12 ... 6 and 4 of object 2010h .1 (see <a href="#">table 76, page 53</a> ) | 0          | Not active |
|           |   | 1          | Active     |

#### Object 6504h – Supported Alarms

Table 53: Object 6504h

| Object | Access | Data type | Designation<br>Description                            | Data values |
|--------|--------|-----------|---|-------------|
| 6504h  | R      | UINT-16   | Supported Alarms<br>Alarms implemented in the encoder | 1001h       |

Table 54: Object 6504h – details

| Bit       | Bezeichnung               | Data values     |
|-----------|---------------------------|-----------------|
| 15 ... 13 | Manufacturer-specific     | 0 Not supported |
| 12        | EEPROM error              | 1 Supported     |
| 11 ... 2  | Reserved                  | -               |
| 1         | Commissioning diagnostics | 0 Not supported |
| 0         | 2<br>Position error       | 1 Supported     |

### Object 6505h – Warning Status

Table 55: Object 6505h

| Object | Access | Data type | Designation<br>Description   | Data values    |
|--------|--------|-----------|--|----------------|
| 6505h  | R      | UINT-16   | Warning Status<br>Warnings on deviation from<br>operating parameters | 0000h<br>FFFFh |

Table 56: Object 6505h – details

| Bit      | Description  | Data values              |
|----------|--|--------------------------|
| 15       | Supply voltage outside the permissible range                 | 0 Not active<br>1 Active |
| 14       | Reserved   | -                        |
| 13       | Operating temperature outside the permissible range          | 0 Not active<br>1 active |
| 12       | Frequency/rotational speed outside the range allowed         | 0 Not active<br>1 active |
| 11 ... 2 | Reserved   | -                        |
| 1        | Sensor LED current too high                                  | 0 Not active<br>1 Active |
| 0        | Maximum frequency/rotational speed outside the range allowed | 0 Not active<br>1 active |

### Object 6506h – Supported Warnings

Table 57: Object 6506h

| Object | Access | Data type | Designation<br>Description                                   | Data values |
|--------|--------|-----------|--|-------------|
| 6506h  | R      | UINT-16   | Supported Warnings<br>Warnings implemented in<br>the encoder | B003h       |

Table 58: Object 6506h – details

| Bit      | Description   | Data values     |
|----------|---|-----------------|
| 15       | Supply voltage outside the permissible range        | 1 Supported     |
| 14       | Reserved  | -               |
| 13       | Operating temperature outside the permissible range | 1 Supported     |
| 12       | Frequency outside the permissible range             | 1 Supported     |
| 11 ... 6 | Reserved  | -               |
| 5        | Reference point not reached                         | 0 Not supported |
| 4        | Battery voltage too low                             | 0 Not supported |

| Bit | Description   | Data values     |
|-----|---|-----------------|
| 3   | Max. operating time exceeded                        | 0 Not supported |
| 2   | CPU watchdog status                                 | 0 Not supported |
| 1   | Minimum internal LED current in the sensors reached | 1 Supported     |
| 0   | Maximum frequency exceeded                          | 1 Supported     |

#### Object 6507h – Version Of Profile & Software

Table 59: Object 6507h

| Objekt | Access | Data type | Designation Description   | Data values            |
|--------|--------|-----------|---|------------------------|
| 6507h  | R      | UINT-32   | Version Of Profile & Software<br>The first two bytes contain the software version, the next two the profile version.. <sup>1)</sup> | 00000000h<br>FFFFFFFFh |

<sup>1</sup> Internal manufacturer software version, can vary from the objects 100Ah and 1018h.

Table 60: Object 6507h – details

| Bit       | Description                        | Example values | Example |
|-----------|------------------------------------|----------------|---------|
| 31 ... 24 | First part of the software version | 03h            | 3.1     |
| 23 ... 16 | Last part of the software version  | 01h            |         |
| 15 ... 8  | First part of the profile version  | 01h            | 1.40    |
| 7 ... 0   | Last part of the profile version   | 40h            |         |

#### Object 6508h – Operating Time

Table 61: Object 6508h

| Object | Access | Data type | Designation Description                            | Data values            |
|--------|--------|-----------|--|------------------------|
| 6508h  | R      | UINT-32   | Operating Time<br>Operating time in units of 0.1 h | 00000000h<br>FFFFFFFFh |

#### Object 6509h – Internal Offset Value

Table 62: Object 6509h

| Object | Access | Data type | Designation Description   | Data values            |
|--------|--------|-----------|---|------------------------|
| 6509h  | R      | UINT-32   | Internal Offset Value<br>Offset value, calculated from the Preset function 6003h (see "Preset function", page 11) | 00000000h<br>FFFFFFFFh |

#### Object 650Ah – Module Identification

Table 63: Object 650Ah

| Object Subindex | Access | Data type | Designation Description | Data values (default value) |
|-----------------|--------|-----------|-------------------------|-----------------------------|
| 650Ah           | R      | Array     | Module Identification   |                             |
| .0              | R      | UINT-32   | Number of entries       | 3                           |



| Object Subindex | Access | Data type | Designation Description                                   | Data values (default value) |
|-----------------|--------|-----------|---|-----------------------------|
| .1              | R      | UINT-32   | Manufacturer Offset Value<br>Manufacturer-specific offset | (0)                         |
| .2              | R      | UINT-32   | Position Value Minimum<br>Lowest position value           | 0                           |
| .3              | R      | UINT-32   | Position Value Maximum<br>Highest position value          | PMR <sup>1</sup> – 1        |

<sup>1</sup> Physical measuring range, depending on the encoder type.

### Object 650Bh – Serial Number

Table 64: Object 650Bh

| Object Subindex | Access | Data type | Designation Description                                    | Data values   |
|-----------------|--------|-----------|--|---------------|
| 650Bh           | R      | UINT-32   | Serial Number<br>YYWWxxxx<br>(year/week/sequential number) | Serial number |

### 3.6.9 Overview of the manufacturer-specific objects

In the manufacturer-specific objects a differentiation is made between the following object types:

- objects for the encoder configuration
- objects that provide status information

Table 65: Implemented manufacturer-specific objects for the encoder configuration

| Object Subindex    | Access | Data type        | Designation                     |
|--------------------|--------|------------------|---------------------------------|
| 2000h              | R/W    | UINT-16          | Control Word 1                  |
| 2001h<br>.0 ... .3 | R/W    | Array<br>UINT-32 | Endless-Shaft Configuration     |
| 2002h<br>.0 ... .6 | R/W    | Array<br>UINT-16 | Speed Calculation Configuration |
| 2004h              | R/W    | UINT-32          | Configuration Install Service   |
| 2005h              | R/W    | UINT-32          | Configuration Preset Value      |
| 2006h<br>.0 ... .4 | R/W    | Record           | Physical Measuring Range Limits |

Table 66: Implemented manufacturer-specific objects that provide status information

| Object Subindex     | Access | Data type        | Designation                           |
|---------------------|--------|------------------|---------------------------------------|
| 2010h<br>.0 ... .3  | R      | Array<br>UINT-16 | Sensor Status (STW-1)                 |
| 2011h<br>.0 ... .8  | R      | Array<br>UINT-32 | Real Scaling Parameter Settings       |
| 2012h<br>.0 ... .15 | R      | Record           | Relative Diagnosis Service Parameters |
| 2013h<br>.0 ... .15 | R      | Record           | Diagnosis Error Logging Parameter     |
| 2014h               | R      | UINT-32          | Time Stamp                            |
| 2015h               | R      | UINT-16          | Temperature Value                     |

| Object Subindex     | Access | Data type        | Designation                           |
|---------------------|--------|------------------|---------------------------------------|
| 2016h               | R      | UINT-32          | Position Value Raw                    |
| 2017h               | R      | INT-32           | Speed Value 32-Bit                    |
| 2018h<br>.0 ... .2  | R      | Array<br>UINT-16 | Time Stamp Signals                    |
| 2019h               | R      | UINT-32          | Process Cycle Time                    |
| 2022h<br>.0 ... .15 | R      | Record           | Absolute Diagnosis Service Parameters |

#### 3.6.10 Detailed information on objects for encoder configuration

##### Object 2000h – Control Word 1

The object sets the encoder to a preset value if necessary.

Table 67: Object 2000h

| Object | Access | Data type | Designation    | Data values           |
|--------|--------|-----------|----------------|-----------------------|
| 2000h  | R/W    | UINT-16   | Control Word 1 | see table 68, page 50 |

Table 68: Object 2000h – Details

| Bit       | Designation Description  | Data values               |
|-----------|--|---------------------------|
| 15 ... 13 | Reserved   | -                         |
| 12        | Preset Function Request (PreReq)<br>Sets the preset value that is transferred with the 2005h object (see table 73, page 52). | 0 Deactivated<br>1 Active |
| 11        | Preset Mode = Shift Positive<br>The preset value is added to the current position value.                                     | 0 Deactivated<br>1 Active |
| 10        | Preset Mode = Shift Negative<br>The preset value is subtracted from the current position value.                              | 0 Deactivated<br>1 Active |
| 9 ... 1   | Reserved   | -                         |
| 0         | Preset Mode = Preset Zero<br>Sets the position value to 0  | 0 Deactivated<br>1 Active |



#### NOTE

- If no preset mode is specified with bit 11, 10 or 0, the preset value from object 2005h is adopted as the position value.
- Bits 11, 10 and 0 must be used exclusively. If several of these three bits have the value 1, the preset function is not executed.
- The preset function is triggered with the rising edge (transition bit 12 from 0 to 1). To set a preset value again, the bit must first be reset to 0.

##### Object 2001h – Endless-Shaft Configuration

Table 69: Object 2001h

| Object Subindex | Access | Data type        | Designation Description     | Data values (default value) |
|-----------------|--------|------------------|-----------------------------|-----------------------------|
| 2001h           | R/W    | Array<br>UINT-16 | Endless-Shaft Configuration | -                           |
| .0              | R/W    | UINT-16          | Number of entries           | 3                           |

| Object Subindex | Access | Data type | Designation Description  | Data values (default value)            |
|-----------------|--------|-----------|--|--|
| .1              | R/W    | UINT-16   | Control of Endless-Shaft Mode<br>Activates the round axis functionality              | <b>2</b> Active<br><b>1</b> Not active |
| .2              | R/W    | UINT-16   | Number of revolutions, nominator<br>Counter for the number of revolutions (CNR_N)    | 1 ... 2,048<br>(2,048)                 |
| .3              | R/W    | UINT-16   | Number of revolutions, divisor<br>Denominator for the number of revolutions (CNR_D). | 1 ... 2,048<br>(1)                     |



**NOTE**

The round axis functionality can only be used with the multiturn encoder. It is only executed if scaling has been switched on with object 6000h.

**Object 2002h – Speed Calculation Configuration**

Table 70: Object 2002h

| Object Subindex | Access | Data type        | Designation Description   | Data values (default value)   |
|-----------------|--------|------------------|---|---|
| <b>2002h</b>    | R/W    | Array<br>UINT-16 | Speed Calculation Configuration   | -   |
| .0              | R/W    | UINT-16          | Number of entries   | 6   |
| .1              | R/W    | UINT-16          | Operation Control<br>Controls the speed calculation mode                                | <b>0</b> Not active<br><b>1</b> Active  |
| .2              | R/W    | UINT-16          | Format Measuring Units<br>Speed measurement unit  | <b>0</b> cps<br><b>1</b> cp100ms<br><b>2</b> cp10ms<br><b>3</b> rpm<br><b>4</b> rps |
| .3              | R/W    | UINT-16          | T1 Update Time in MS<br>Update time in ms   | AFS60 = 2<br>AFM60 = 1 ... 50<br>(2)  |
| .4              | R/W    | UINT-16          | T2 Integration Time<br>Integration time dependent on T1                                 | 1 ... 200<br>(200)  |
| .5              | R/W    | UINT-16          | Upper Limit Warning in rpm<br>Maximum speed, a warning is issued if this is exceeded    | 1 ... 10,000<br>(6,000)   |
| .6              | R/W    | UINT-16          | Lower Limit Warning in rpm<br>Minimum speed, a warning is issued if this is not reached | 0 ... 9,000<br>(0)  |

The speed is calculated from the average of several measurements. The integration time T2 specifies the number of values from which the average is calculated. The update time T1 indicates the time interval between the individual measurements.

**Example:**

If T1 = 2 ms and T2 = 200, then the speed is calculated from the last 0.4 s.

#### Object 2004h – Configuration Install Service

Table 71: Object 2004h

| Object Subindex | Access | Data type | Designation                   | Data values           |
|-----------------|--------|-----------|-------------------------------|-----------------------|
| 2004h           | R/W    | UINT-32   | Configuration Install Service | see table 72, page 52 |

Table 72: Object 2004h – Service codes

| Data values | Description  |
|-------------|--|
| 70100100h   | Reset-0, simulates switching the encoder on/off (power on). Parameters are not saved   |
| 70100101h   | Reset-1, simulates switching the encoder on/off (power on). Parameters (offset, preset value and offset for rotary axis) are saved |
| 71001021h   | Resets the relative diagnostic data in object 2012h  |
| 78001001h   | Reactivates the synchronization mode in Operational Mode (Synchronous to SM-2/-3 event or DC Sync Mode)                            |
| 78001009h   | Stops the synchronization mode in Operational Mode (Synchronous to SM-2/-3 event or DC Sync Mode)                                  |

#### Object 2005h – Configuration Preset Value

This parameter is used to transfer a preset value to the encoder. This preset value must be set with object 2000h (see table 67, page 50) must be set.

Table 73: Object 2005h

| Object Subindex | Access | Data type | Designation                | Data values |
|-----------------|--------|-----------|----------------------------|-------------|
| 2005h           | R/W    | UINT-32   | Configuration Preset Value | 0 ... CMR-1 |



#### NOTE

The preset value must be within the configured measuring range.

#### Object 2006h – Physical Measuring Range Limits

Table 74: Object 2006h

| Object Subindex | Access | Data type | Designation Description   | Data values (default value) |
|-----------------|--------|-----------|---|-----------------------------|
| 2006h           | R/W    | Record    | Physical Measuring Range Limits   | -                           |
| .0              | R      | UINT-8    | Number of entries   | 4                           |
| .1              | R/W    | SINT-16   | Temperature Lower Limit<br>Defines the lower limit of the permitted operating temperature in °C | -40<br>+80<br>(-40)         |
| .2              | R/W    | SINT-16   | Temperature Upper Limit<br>Defines the upper limit of the permitted operating temperature in °C | -20<br>+120<br>(+100)       |
| .3              | R/W    | UINT-16   | Operating Voltage Lower Limit<br>Defines the lower limit of the permitted supply voltage in mV  | 9000<br>24000<br>(10,000)   |

| Object Subindex | Access | Data type | Designation Description  | Data values (default value)  |
|-----------------|--------|-----------|--|------------------------------|
| .4              | R/W    | UINT-16   | Operating Voltage Upper Limit<br>Defines the upper limit of the permitted supply voltage in mV | 10,000<br>30,000<br>(30,000) |

**3.6.11 Detailed information on objects that provide status information**

**Object 2010h – STW-1 – Device Status Word**

Table 75: Object 2010h

| Object Subindex | Access | Data type        | Designation                | Data values     |
|-----------------|--------|------------------|----------------------------|-----------------|
| 2010h           | R      | Array<br>UINT-16 | STW-1 – Device Status Word | -               |
| .0              | R      | UINT-16          | Number of entries          | 3               |
| .1              | R      | UINT-16          | S_STAT-A, Sensor State     | 0000h ... FFFFh |
| .2              | R      | UINT-16          | S_STAT-B, State Flag 2     | 0000h ... FFFFh |
| .3              | R      | UINT-16          | S_STAT-C, State Flag 3     | 0000h ... FFFFh |

Table 76: Object 2010h - Sensor status (S\_STAT-A)

| Bit | Description   | Position value (Err_PosVal) |
|-----|---|-----------------------------|
| 15  | Memory error (Memory):<br>Invalid EEPROM checksum during initialization   | -12                         |
| 14  | Position error:<br>Invalid communication to the I <sup>2</sup> C device <sup>1)</sup> in the sensor module  | -11                         |
| 13  | Reserved  | -                           |
| 12  | Position error:<br>Invalid EEPROM checksum<br>or<br>Invalid internal SSI communication (MFP4 signal <sup>2)</sup> )   | -9                          |
| 11  | Position error:<br>Invalid or no synchronization of MA sensor <sup>3)</sup> to LY singleturn position <sup>4)</sup>   | -8                          |
| 10  | Position error:<br>The error register in LY is activated (MFP5 signal <sup>2)</sup> ).<br>or<br>Invalid internal SSI communication (MFP4 signal <sup>2)</sup> ) | -7                          |
| 9   | Position error:<br>Error in the calculation of the vector length Sin <sup>2</sup> + Cos <sup>2</sup> of the multiturn stage                                     | -6                          |
| 8   | Position error:<br>Error in the calculation of the vector length Sin <sup>2</sup> + Cos <sup>2</sup> of the singleturn stage                                    | -5                          |
| 7   | Position and memory errors:<br>Invalid communication to the I <sup>2</sup> C device in the main module  | -4                          |
| 6   | Position error:<br>Error in the calculation of the amplitude values Sin + Cos of the singleturn stage   | -3                          |

| Bit | Description  | Position value (Err_PosVal) |
|-----|--|-----------------------------|
| 5   | Warning regarding speed:<br>Current measured value outside the minimum or maximum limit value              | -                           |
| 4   | Position error:<br>Error in the calculation of the amplitude values, Sin + Cos of the multiturn stage      | -2                          |
| 3   | Warning regarding the supply voltage:<br>Current measured value outside the minimum or maximum limit value | -                           |
| 2   | Warning, sensor LED current critical:<br>Current measured value outside the minimum or maximum limit value | -                           |
| 1   | Warning regarding the temperature:<br>Current measured value outside the minimum or maximum limit value    | -                           |
| 0   | Warning:<br>General start-up error when switching on   | -                           |

- 1 Internal interface between EEPROM and sensor of the encoder.
- 2 Output signal from the sensor of the encoder.
- 3 Internal hall sensor that determines the multiturn position by means of magnetic sensing.
- 4 LY = internal sensor for the singleturn position.



#### NOTE

- If several errors occur, the position value -16 is output.
- The Err\_PosVal is output instead of the position value and enables an error to be detected using the cyclical process data (see table 36, page 42).
- The output of the Err\_PosVal must be configured with object 6000h (see table 31, page 40).

Table 77: Object 2010h – Sensor status (S\_STAT-B)

| Bit | Description  |
|-----|--|
| 15  | Memory error due to an invalid checksum when reading the EEPROM during encoder initialization: <ul style="list-style-type: none"> <li>• In the sensor configuration data area</li> </ul> |
| 14  | <ul style="list-style-type: none"> <li>• In the device configuration data area</li> </ul>  |
| 13  | <ul style="list-style-type: none"> <li>• In the basic process data diagnostics area</li> </ul>   |
| 12  | <ul style="list-style-type: none"> <li>• In the service data diagnostics area</li> </ul>   |
| 11  | <ul style="list-style-type: none"> <li>• In the area of user configuration, communication mapping</li> </ul>   |
| 10  | Reserved   |
| 9   | <ul style="list-style-type: none"> <li>• In the user configuration area, parameters of the electronic cam controller (CAM)</li> </ul>  |
| 8   | <ul style="list-style-type: none"> <li>• In the user configuration area, basic parameters</li> </ul>   |
| 7   | Reserved   |
| 6   | Process data cycle times under 480 μs  |
| 5   | Warning, speed above the configured maximum value  |
| 4   | Warning, occurred when executing the preset function. The preset value is outside the measuring range (CMR).   |

| Bit | Description   |
|-----|---|
| 3   | Warning, occurred when changing or writing parameters: <ul style="list-style-type: none"> <li>In the area of manufacturer-specific objects</li> </ul> |
| 2   | <ul style="list-style-type: none"> <li>In the area of objects for the electronic camshaft</li> </ul>  |
| 1   | <ul style="list-style-type: none"> <li>In the area of encoder profile-specific objects</li> </ul>   |
| 0   | <ul style="list-style-type: none"> <li>In the PDO configuration area</li> </ul>   |

Table 78: Object 2010h – Sensor status (S\_STAT-C)

| Bit      | Description   |
|----------|---|
| 15       | Information:<br>Encoder in synchronous mode. Position formation <b>is synchronized</b> with the process data cycle of the master  |
| 14       | Information:<br>Encoder in Free Run mode. Position formation <b>is not synchronized</b> with the process data cycle of the master |
| 13       | Reserved  |
| 12       | Preset function was triggered by object 2000h (see table 67, page 50) and confirmed   |
| 11 ... 4 | Reserved  |
| 3        | Status information about saving internal diagnostic values:   |
| 2        | Bit 3 = 1 and bit 2 = 0: Memory operation completed<br>Bit 3 = 0 and bit 2 = 1: Memory operation requested and process running    |
| 1        | Saving the configuration data with the Save command (object 1010h, see table 15, page 33):  |
| 0        | Bit 1 = 1 and bit 0 = 0: Memory operation completed<br>Bit 1 = 0 and bit 0 = 1: Memory operation requested and process running    |

### Object 2011h – Real Scaling Parameter Settings

Table 79: Object 2011h

| Object Subindex | Access | Data type     | Designation Description  | Data values              |
|-----------------|--------|---------------|--|--------------------------|
| 2011h           | R      | Array UINT-32 | Real Scaling Parameter Settings  | -                        |
| .0              | R      | UINT-32       | Number of entries  | 8                        |
| .1              | R      | UINT-32       | Endless-Shaft Operation Mode   | 1 Not active<br>2 Active |
| .2              | R      | UINT-32       | Endless-Shaft Offset<br>Offset of the endless shaft function                       | 00000000h<br>40000000h   |
| .3              | R      | UINT-32       | Internal PMR Shift Value<br>Internal PMR shift value                               |                          |
| .4              | R      | UINT-32       | CNR_N, Number of Revolutions, Nominator<br>Numerator for the number of revolutions | 1 ... 2,048              |
| .5              | R      | UINT-32       | CNR_D, Number of Revolutions, Divisor<br>Denominator for the number of revolutions | 1 ... 2,048              |
| .6              | R      | UINT-32       | CMR, Counts per Measuring Range<br>Total resolution                                | 1 ... 40000000h          |

| Object Subindex | Access | Data type | Designation Description  | Data values             |
|-----------------|--------|-----------|--|-------------------------|
| .7              | R      | UINT-32   | CPR, Counts Per Revolution (Integer)<br>Number per revolution, number before the decimal point | Example: at 1.555 = 1   |
| .8              | R      | UINT-32   | CPR, Counts Per Revolution (Fract)<br>Number per revolution, number after the decimal point    | Example: at 1.555 = 555 |

#### Object 2012h – Relative Diagnosis Service Parameter

This diagnostic data can be reset via service code 71001021h in object 2004h.

Table 80: Object 2012h

| Object Subindex | Access | Data type        | Designation Description   | Data values |
|-----------------|--------|------------------|---|-------------|
| <b>2012h</b>    | R      | Array<br>UINT-32 | Diagnosis Service Parameter   | -           |
| .0              | R      | UINT-32          | Number of entries   | 15          |
| .1              | R      | UINT-32          | Number of Switch-On Power-on counter  | -           |
| .2              | R      | UINT-32          | Operating Time Moving<br>Operating time in s, the time in which the encoder has moved is output <sup>1)</sup> | -           |
| .3              | R      | UINT-32          | Max. Operating Speed<br>Maximum speed in rpm since the encoder has been in operation                          | -           |
| .4              | R      | UINT-32          | Starts with Direction Forward<br>Counter for movements of the encoder in forward rotation <sup>1)</sup>       | -           |
| .5              | R      | UINT-32          | Starts with Direction Backward counter for starting the encoder in backward rotation <sup>1)</sup>            | -           |
| .6              | R      | UINT-32          | Starts with Alternating Directions<br>Counter for starting the encoder in alternating rotation <sup>1)</sup>  | -           |
| .7              | R      | UINT-32          | Operating Hours Counter<br>Operating hours counter (× 0.1 h)  | -           |
| .8              | R      | UINT-16          | Min. Operating Temperature<br>Minimum operating temperature in °C   | -           |



| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| .9              | R      | UINT-16   | Max. Operating Temperature<br>Maximum operating temperature in °C               | -           |
| .10             | R      | UINT-16   | Min. Operating LED Current<br>Minimum internal LED current in µA                | -           |
| .11             | R      | UINT-16   | Max. Operating LED Current<br>Maximum internal LED current in µA                | -           |
| .12             | R      | UINT-16   | Min. Operating Voltage<br>Minimum supply voltage in mV                          | -           |
| .13             | R      | UINT-16   | Max. Operating Voltage<br>Maximum supply voltage in mV                          | -           |
| .14             | R      | UINT-32   | Internal FPGA Revision Number<br>FPGA revision number                           | -           |
| .15             | R      | UINT-32   | Counter of Diagnosis Storage<br>Counter for the storage processes in the EEPROM | -           |

1 From movements with a speed > 12 rpm.

**Object 2013h – Diagnosis Error Logging Parameter**

Table 81: Object 2013h

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| <b>2013h</b>    | R      | Record    | Diagnosis Error Logging Parameter   | -           |
| .0              | R      | UINT-8    | Number of entries   | 16          |
| .1              | R      | UINT-32   | Temperature out of range<br>Operating temperature outside the configured minimum or maximum limit value | -           |
| .2              | R      | UINT-32   | LED current out of range<br>Sensor LED current outside the configured minimum or maximum limit value    | -           |
| .3              | R      | UINT-32   | Voltage out of range<br>Supply voltage outside the configured minimum or maximum limit value            | -           |
| .4              | R      | UINT-32   | Amplitude multi<br>Error in the calculation of the amplitude values Sin + Cos of the multturn stage     | -           |

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| .5              | R      | UINT-32   | Frequency out of range<br>Speed outside the configured minimum or maximum limit value   | -           |
| .6              | R      | UINT-32   | Amplitude single<br>Error in the calculation of the amplitude values Sin + Cos of the singleturn stage                            | -           |
| .7              | R      | UINT-32   | Communication EEPROM - I <sup>2</sup> C<br>Invalid communication to the I2C device  | -           |
| .8              | R      | UINT-16   | Vector length single<br>Error in the calculation of the vector length Sin <sup>2</sup> + Cos <sup>2</sup> of the singleturn stage | -           |
| .9              | R      | UINT-16   | Vector length multi<br>Error in the calculation of the vector length Sin <sup>2</sup> + Cos <sup>2</sup> of the multiturn stage   | -           |
| .10             | R      | UINT-16   | Singleturn position<br>Calculation of the singleturn position incorrect   | -           |
| .11             | R      | UINT-16   | Invalid or no synchronization from MA Sensor to LY singleturn position  | -           |
| .12             | R      | UINT-16   | Invalid internal SSI communication (MFP4 signal)  | -           |
| .13             | R      | UINT-16   | Synchronization error multi-turn/singleturn stage   | -           |
| .14             | R      | UINT-32   | Invalid communication to the I <sup>2</sup> C device in the sensor module   | -           |
| .15             | R      | UINT-32   | Invalid EEPROM checksum during initialization   | -           |

#### Object 2014h – Time Stamp Counter

Table 82: Object 2014h

| Object Subindex | Access | Data type | Designation Description  | Data values            |
|-----------------|--------|-----------|--|------------------------|
| 2014h           | R      | UINT-32   | Time Stamp Counter<br>Time stamp in ms, total range 4,290,200 seconds or 136 years | 00000000h<br>FFB741C0h |

#### Object 2015h – Temperature Value

Table 83: Object 2015h

| Object Subindex | Access | Data type | Designation Description                          | Data values |
|-----------------|--------|-----------|--|-------------|
| 2015h           | R      | UINT-32   | Temperature value<br>Operating temperature in °C | -           |

### Object 2016h – Position Value, Raw

Table 84: Object 2016h

| Object Subindex | Access | Data type | Designation Description   | Data values  |
|-----------------|--------|-----------|---|--|
| 2016h           | R      | UINT-32   | Position Value, Raw<br>Position value independent of any preset value | AFS60 = 0 ... 0003FFFFh<br>AFM60 = 0 ... 3FFFFFFFh |

### Object 2017h – Speed Value 32-Bit

Table 85: Object 2017h

| Object Subindex | Access | Data type | Designation Description                     | Data values |
|-----------------|--------|-----------|---|-------------|
| 2017h           | R      | UINT-32   | Speed Value 32 Bit<br>Speed value in 32 bit | -           |

### Object 2018h – Time Stamp Signals

Table 86: Object 2018h

| Object Subindex | Access | Data type        | Designation Description                       | Data values    |
|-----------------|--------|------------------|---|----------------|
| 2018h           | R      | Array<br>UINT-16 | Time Stamp Signals                            |                |
| .0              | R      | UINT-16          | Number of entries                             | 2              |
| .1              | R      | UINT-16          | Time Stamp MSec<br>Time stamp in milliseconds | 0000h<br>FFFFh |
| .2              | R      | UINT-16          | Time Stamp Sec<br>Time stamp in seconds       | 0000h<br>FFFFh |

### Object 2019h – Process Cycle Time

This object is used to output either the internal or the external cycle time. The internal cycle time is determined by the encoder in Free Run mode and is always 500 µs. The external cycle time is determined by the master in **Synchronous to SM- 2/-3 event** or **DC Sync** mode and is between 125 µs and 100,000 µs.

Table 87: Object 2019h

| Object Subindex | Access | Data type | Designation Description                | Data values    |
|-----------------|--------|-----------|--|----------------|
| 2019h           | R      | UINT-32   | Process Cycle Time<br>Cycle time in µs | 125<br>100,000 |

### Object 2022h – Absolute Diagnosis Service Parameter

To activate object 2022h, the following steps must be carried out:

1. Object 6000h Set bit 12 to 1
2. Execute the "Save Parameter" operation (object 1010h)
3. Performing a reset or restart

Object 2022h then becomes visible in the object library .

The diagnostic data contained in object 2022h is recorded from the production of the encoder and cannot be reset.

Table 88: Object 2022h

| Object Subindex | Access | Data type     | Designation Description  | Data values |
|-----------------|--------|---------------|--|-------------|
| <b>2022h</b>    | R      | Array UINT-32 | Diagnosis Service Parameter  | -           |
| .0              | R      | UINT-32       | Number of entries  | 15          |
| .1              | R      | UINT-32       | Number of Switch-On Power-on counter   | -           |
| .2              | R      | UINT-32       | Operating Time Moving<br>Operating time in s, the time in which the encoder has moved is output <sup>1)</sup>  | -           |
| .3              | R      | UINT-32       | Max. Operating Speed<br>Maximum speed in rpm since the encoder has been in operation                           | -           |
| .4              | R      | UINT-32       | Starts with Direction Forward<br>Counter for movements of the encoder in forward rotation <sup>1)</sup>        | -           |
| .5              | R      | UINT-32       | Starts with Direction Backward<br>Backward counter for starting the encoder in backward rotation <sup>1)</sup> | -           |
| .6              | R      | UINT-32       | Starts with Alternating Directions<br>Counter for starting the encoder in alternating rotation <sup>1)</sup>   | -           |
| .7              | R      | UINT-32       | Operating Hours Counter<br>Operating hours counter (× 0.1 h)   | -           |
| .8              | R      | UINT-16       | Min. Operating Temperature<br>Minimum operating temperature in °C  | -           |
| .9              | R      | UINT-16       | Max. Operating Temperature<br>Maximum operating temperature in °C  | -           |
| .10             | R      | UINT-16       | Min. Operating LED Current<br>Minimum internal LED current in µA   | -           |
| .11             | R      | UINT-16       | Max. Operating LED Current<br>Maximum internal LED current in µA   | -           |
| .12             | R      | UINT-16       | Min. Operating Voltage<br>Minimum supply voltage in mV   | -           |
| .13             | R      | UINT-16       | Max. Operating Voltage<br>Maximum supply voltage in mV   | -           |

| Object Subindex | Access | Data type | Designation Description   | Data values |
|-----------------|--------|-----------|---|-------------|
| .14             | R      | UINT-32   | Internal FPGA Revision Number<br>FPGA revision number                           | -           |
| .15             | R      | UINT-32   | Counter of Diagnosis Storage<br>Counter for the storage processes in the EEPROM | -           |

### 3.7 Controls and status indicators

The AFS60/AFM60 EtherCAT® Absolute Encoder has five LEDs.

Three of the LEDs indicate the operational status (NMOD, STAT and Encoder), two the status of the Ethernet interface (L/A1 and L/A2).




Figure 29: Position der LEDs, der Codierschalter und des Preset-Tasters

The LEDs are multi-colored. [see table 91, page 71](#) [see table 92, page 72](#) show the meaning of the signals.

The preset push-button is under the screw cover.

## 4 Commissioning

This chapter provides information on the electrical installation, configuration and commissioning of the Absolute Encoder AFS60/AFM60 EtherCAT®.

- ▶ Please read this chapter before mounting, installing and commissioning the device.

### 4.1 Electrical installation



**DANGER**

**Risk of injury from electrical voltage.**

Disconnect the system from the voltage supply to prevent the system from starting unintentionally.

- ▶ Before starting work on the system, ensure that it is and remains in a de-energized state during electrical installation.

Connecting male and female connectors are required for electrical installation (see data sheet of the absolute encoder).

#### 4.1.1 Connections of the AFS60/AFM60 EtherCAT®

The connections of the AFS60/AFM60 EtherCAT® are on the back.




Figure 30: Position of the connections of the AFS60/AFM60 EtherCAT®

- ① Versorgungsspannung
- ② Port 1 IN
- ③ Port 2 OUT




Figure 31: Port 1, Port 2: Female connector, M12, 4-pin




Figure 32: Supply voltage: Male connector, M12, 4-pin

Table 89: Pin assignment for the connection of the supply voltage

| P | Signal         | Wire color <sup>1</sup> | Function                      |
|---|----------------|-------------------------|-------------------------------|
| 1 | V <sub>s</sub> | Brown                   | Supply voltage 10 ... 30 V DC |
| 2 | -              | White                   | Do not use                    |
| 3 | GND            | Blue                    | 0 V DC (Ground)               |
| 4 | -              | Black                   | Do not use                    |

<sup>1</sup> On the usage of pre-wired cables.

**NOTE**

Pin 2 and 4 are **not allowed to be assigned**, otherwise irreparable damage could be caused to the AFS60/AFM60 EtherCAT®.

Table 90: Pin assignment for the connection of Port 1 and Port 2

| PIN | Signal | Wire color <sup>1</sup> | Function |
|-----|--------|-------------------------|----------|
| 1   | TxD+   | Yellow                  | Ethernet |
| 2   | RxD+   | White                   | Ethernet |
| 3   | TxD-   | Orange                  | Ethernet |
| 4   | RxD-   | Green                   | Ethernet |

<sup>1</sup> On the usage of pre-wired cables.

**NOTE**

- ▶ **Connect the shielding to the encoder's housing!**
- ▶ Pay attention to the maximum cable lengths.
- ▶ Mount all cables with strain relief.

## 4.2 Settings on the hardware

There are the following controls for making settings under the screw cover:

- three encoding switches
- preset push-button
- ▶ Open the screw cover using a screwdriver for slot-head screws with a blade width of min. 10.0 mm.




Figure 33: Position of the controls



**NOTE**

The three encoding switches do not have any function on the AFS60/AFM60 EtherCAT®.

**Preset push-button**

The preset function is available in every status of the EtherCAT® state machine.

- ▶ To trigger the preset, press the preset pushbutton. The value from object 2005h is used as the new position value.



**NOTE**

- Only set a preset value when the encoder is at standstill.
- The preset value must lie within the measuring range configured.



**CAUTION**

**Before triggering the preset function, check whether there is a hazard from the machine or system in which the encoder is integrated!**

The preset function results in a change in the position value output by the encoder. This change could cause an unexpected movement that may result in a hazard for persons or damage to the system or other items.



## 4.3 Configuration

The AFS60/AFM60 EtherCAT® can be integrated into a Beckhoff control system. For this purpose an ESI file is loaded into the system.



### NOTE

- All software notes are displayed in English.
- All software notes are related to the TwinCAT® system manager.

### 4.3.1 Default delivery status

The AFS60/AFM60 EtherCAT® is supplied with the following parameters:

- Code sequence = clockwise
- Scaling = none
- Resolution per revolution = 262,144
- Total resolution AFS60 = 262,144
- Total resolution AFM60 = 1,073,741,823
- Preset = 0
- Speed measuring unit = rpm
- Round axis functionality = not activated
- Nominator for the number of revolutions (Round axis functionality) = 2,048
- Divisor for the number of revolutions (Round axis functionality) = 1

### 4.3.2 System configuration



### NOTE

All configuration information relates to Beckhoff controllers that are configured and diagnostics undertaken using the configuration tool TwinCAT®.




Figure 34: Integration in TwinCAT® with ESI file

- ▶ Copy the ESI file **SICK-AFx\_vX-xxx** in the TwinCAT® directory to the folder **Twin-CAT\3.1\Config\Io\EtherCAT**
- ▶ Then restart the TwinCAT® system manager.
- ▶ Add the encoder as a box manually (Add New Item) or automatically in the device tree if the encoder is connected to the controller (Scan).




Figure 35: Context menu command **Append box...**

- Choose the required encoder type under SICK AG. (... MT = Multiturn, ... ST = Singleturn)




Figure 36: Dialog box for adding an EtherCAT device




Figure 37: Encoder in the device tree

The encoder is displayed in the device tree as **Box n**.

- ▶ Then place the TwinCAT® system manager in the configuration mode.




Figure 38: Configuration mode button

Prompts are displayed as to whether the TwinCAT® system manager is to be placed in the configuration mode, whether the data are to be loaded from the I/O device and whether the system is to be placed in the Free Run operating mode.




Figure 39: Configuration mode prompt




Figure 40: Load I/O Devices prompt




Figure 41: Free Run prompt

- Click **OK** or **Yes**.



Figure 42: Status display of the free run or configuration mode (blue)

Status display of the configuration mode (no cyclical communication) - permanently blue.



Figure 43: Status display of the free run or configuration mode (red)

Status display of free run mode (extension of configuration mode with cyclical data transfer) - alternating blue and red.

The status display is permanently blue in Config mode. In free run mode, the status display alternates between blue and red.



**NOTE**

The Free Run mode of the TwinCAT® system manager described here should not be confused with the Free Run operating mode of the encoder (see "Object 2004h - Configuration Install Service", page 52).

All object parameters can now be read out or parameterized in the CoE - Online tab (see "Configurable functions", page 19).

| Index  | Name                            | Flags | Value                           | Unit |
|--------|---------------------------------|-------|---------------------------------|------|
| 1000   | DeviceType                      | M RO  | 0x00020196 (131478)             |      |
| 1001   | Error Register                  | RO    | 0x00 (0)                        |      |
| 1008   | Manufacturer Device Name        | RO    | AFM60A**E*18x12                 |      |
| 1009   | Hardware version                | RO    | HW-01.01                        |      |
| 100A   | Manufacturer Software Version   | RO    | REV_1.03                        |      |
| 1010:0 | Store parameters                | M RO  | > 1 <                           |      |
| 1011:0 | Restore parameters              | M RO  | > 1 <                           |      |
| 1018:0 | Identity Object                 | M RO  | > 4 <                           |      |
| 10F1:0 | Error Settings                  | RO    | > 2 <                           |      |
| 10F3:0 | Diagnosis History               | RO    | > 5 <                           |      |
| 10F8   | Timestamp Object                | RO P  | 0xb1eb9e95100 (122265960000...) |      |
| 1600:0 | 1st receive PDO Mapping         | RO    | > 1 <                           |      |
| 1A00:0 | 1st transmit PDO Mapping        | RW    | > 9 <                           |      |
| 1A01:0 | 2nd transmit PDO Mapping        | RW    | > 9 <                           |      |
| 1C00:0 | Sync Manager Communication Type | RO    | > 4 <                           |      |

| Name                 | Online     | Type  | Size | >Addr... | In/Out | User ID | Linked to |
|----------------------|------------|-------|------|----------|--------|---------|-----------|
| Position Value       | 1939       | UDINT | 4.0  | 122.0    | Input  | 0       |           |
| Alarm Status         | 0          | UINT  | 2.0  | 126.0    | Input  | 0       |           |
| Warning Status       | 0          | UINT  | 2.0  | 128.0    | Input  | 0       |           |
| Status Flag: S-St... | 0          | UINT  | 2.0  | 130.0    | Input  | 0       |           |
| Time Counter: S...   | 12236      | UINT  | 2.0  | 132.0    | Input  | 0       |           |
| Time Counter: ...    | 46404      | UINT  | 2.0  | 134.0    | Input  | 0       |           |
| Temperature (gr...   | 39         | INT   | 2.0  | 136.0    | Input  | 0       |           |
| Process Cycle Ti...  | 1998       | UDINT | 4.0  | 138.0    | Input  | 0       |           |
| Speed Val-16         | 0          | INT   | 2.0  | 142.0    | Input  | 0       |           |
| Diag_Flag            | 0          | BIT   | 0.1  | 144.0    | Input  | 0       |           |
| Speed Val-32         | 0          | DINT  | 4.0  | 145.0    | Input  | 0       |           |
| Position Value, R... | 1059977464 | UDINT | 4.0  | 149.0    | Input  | 0       |           |
| Status Flag: S-St... | 0          | UINT  | 2.0  | 153.0    | Input  | 0       |           |
| Status Flag: S-St... | 32768      | UINT  | 2.0  | 155.0    | Input  | 0       |           |
| Cam SubIndex 0...    | 0          | USINT | 1.0  | 157.0    | Input  | 0       |           |
| Cam SubIndex 0...    | 0          | USINT | 1.0  | 158.0    | Input  | 0       |           |

Figure 44: CoE tab - Online

4.4 Test notes



**CAUTION**

**Commissioning requires a thorough check by authorized personnel!**

Before you operate a system equipped with the AFS60/AFM60 EtherCAT® for the first time, make sure that the system is first checked and released by authorized personnel. Please read the notes see "", page 8.

## 5 Troubleshooting

### 5.1 Response to errors



#### **DANGER**

Cease operation if the cause of the malfunction has not been clearly identified!

The machine must be put out of operation if the error cannot be clearly assigned and safely rectified.

### 5.2 Support

If an error cannot be rectified using the information in this section, contact the responsible SICK representative in your country.

### 5.3 Error and status indications on the LEDs




Figure 45: Position of the LEDs

#### 5.3.1 Identification of the encoder

Place the encoder (e.g. in a system with several sensors) in the Pre-Operational status using the TwinCAT® system manager. As a result the STAT status LED flashes green every 200 ms and the encoder can be identified more easily.

#### 5.3.2 NMOD, STAT and Encoder status LEDs

Table 91: Meaning of the status LEDs NMOD, STAT and Encoder

| Display                    | Description   |
|----------------------------|---|
| <b>LED NMOD</b>            |   |
| ○ Off                      | No supply voltage<br>or<br>Network module not initialized |
| ● Green                    | Network module in operation                               |
| ● Red                      | Error in the network module                               |
| <b>STAT LED run status</b> |   |
| <b>Run status (green)</b>  |   |


| Display                     | Description   |
|-----------------------------|---|
| ○ Off                       | Status Initializing<br>or<br>No supply voltage  |
| ◐ 200 ms                    | Pre-Operational status<br>The encoder is ready for configuration, SDO transfer can take place. Can be used for identification.  |
| ◑ 200/1000 ms               | Pre-Operational status<br>EtherCAT master reads the position values from the encoder.   |
| ●                           | Operational status<br>EtherCAT master reads the position values from the encoder in real time.  |
| <b>Error status (red)</b>   |   |
| ○ Off                       | No error<br>or<br>No supply voltage   |
| ◐ 200 ms                    | Faulty configuration  |
| ◑ 200/1000 ms               | Local error<br>The encoder has changed the EtherCAT status independently.   |
| ◑ 2 × 200/1000 ms           | Watchdog time-out   |
| ●                           | Application error   |
| <b>LED Encoder</b>          |   |
| <b>Initialization phase</b> |   |
| ○ Off                       | No supply voltage   |
| ◐ Red/green                 | Self-test at power-on   |
| ● Green                     | Initialization complete/no error  |
| ◐ Green                     | Initialization completed incorrectly  |
| <b>Operational status</b>   |   |
| ● Green                     | Bus operates correct  |
| ◐ Red                       | Warning due above/below frequency/rotational speed, above/below operating temperature or above/below sensor LED current (see also object 2010h – Sensor Status (see table 76, page 53)) |
| ● Red                       | Alarm due to an EEPROM error or invalid communication with I <sup>2</sup> C device (see table 76, page 53)  |
| ◐ Orange                    | EtherCAT or CoE-specific communication error (see table 77, page 54)  |
| ◐ Green                     | Cycle time (SM/DC sync event) set for the system <480 μs (see table 77, page 54)  |

5.3.3 Ethernet Link LEDs L/A1 and L/A2

Table 92: Meaning of the LEDs L/A1 and L/A2

| Display  | Description  |
|----------|--|
| ○ Off    | No supply voltage<br>or<br>No connection established, internal ESC port closed     |
| ● Green  | Connection established, internal ESC port open, <b>no</b> data transmission active |
| ● Yellow | Interface port locked  |
| ◐ Green  | Connection established, internal ESC port open, data transmission active           |



| Display  | Description     |
|--|-----------------|
|  Yellow | Data collisions |

## 5.4 Diagnostics via EtherCAT®

### 5.4.1 Error types

The following error types can occur:

- encoder-specific errors, caused by the encoder's measuring system
- application protocol-specific (CoE) errors
- network protocol-specific (EtherCAT) error

### 5.4.2 Encoder specific errors

Encoder-specific errors must be retrieved by the master. The diagnostics messages can be read from the following objects:

- 1F03h – Diagnosis history (see table 21, page 34)
- 6503h – Alarms (see table 51, page 46)
- 6505h – Warnings (see table 55, page 47)
- 2010h – STW-1 – Device Status Word (see table 75, page 53)



#### NOTE

If a new diagnostics message has occurred, it is indicated via the subindex .4 “Diagnosis Flag” of the object 10F3h. By default this object is transferred cyclically via the process data object 1A01h.

### 5.4.3 CoE specific errors

In the case of an error during the SDO transfer, a so-called Abort-SDO-Transfer-Request is transmitted with an error code. The following errors are possible:

Table 93: CoE specific errors

| Value     | Description  |
|-----------|--|
| 05030000h | Toggle bit has not changed   |
| 05040000h | SDO protocol time-out  |
| 05040001h | Client/server command invalid or unknown                           |
| 05040005h | Memory too small   |
| 06010000h | Object access not supported  |
| 06010001h | Read access to an object that can only be written                  |
| 06010002h | Write access to an object that can only be read                    |
| 06020000h | Object not present in the object directory                         |
| 06040041h | The object cannot be mapped in the PDO                             |
| 06040042h | Number and length of the mapped objects exceed the PDO length      |
| 06040043h | General parameter incompatibility                                  |
| 06040047h | General incompatibility in the device                              |
| 06060000h | Access error due to a hardware error                               |
| 06070010h | Incorrect data type, length of the service parameters is incorrect |
| 06070012h | Incorrect data type, length of the service parameters too long     |
| 06070013h | Incorrect data type, length of the service parameters too short    |
| 06090011h | Subindex does not exist  |
| 06090030h | Parameter value range exceeded, only on write access               |

| Value     | Description   |
|-----------|---|
| 06090031h | Parameter value written too long  |
| 06090032h | Parameter value written too short   |
| 06090036h | Maximum value is smaller than minimum value   |
| 08000000h | Generic error   |
| 08000020h | Data can not be transmitted or saved in the application                               |
| 08000021h | Data can not be transmitted or saved in the application. Reason: local control system |
| 08000022h | Data can not be transmitted or saved in the application. Reason: actual device status |
| 08000023h | Dynamic object directory creation error or object directory does not exist            |

#### 5.4.4 EtherCAT® specific errors

EtherCAT-specific errors can be transmitted in the following ways:

- Emergency messages
- AL status information
- Sync Manager Watchdog
- Status LED NMOD (see "NMOD, STAT and Encoder status LEDs", page 71)
- Status LED STAT (see "NMOD, STAT and Encoder status LEDs", page 71)

#### Emergency messages

Emergency messages are automatically transmitted from the encoder to the master. The data transfer is undertaken via the EtherCAT mailbox service.

#### Structure of the emergency messages

Table 94: Mailbox service with emergency message

| Description | Mailbox header | CoE header | Emergency message |
|-------------|----------------|------------|-------------------|
| Data length | 6 byte         | 2 byte     | 8 byte            |

Table 95: Structure of the emergency messages

| Byte                 |     |                |  |        |        |        |        |
|----------------------|-----|----------------|--|--------|--------|--------|--------|
| 0                    | 1   | 2              | 3  | 4      | 5      | 6      | 7      |
| Emergency error code |     | Error register | Additional error field (diagnosis information) |        |        |        |        |
| LsB                  | MsB |                | -  | Diag 0 | Diag 1 | Diag 2 | Diag 3 |

The emergency messages comprise the emergency error code, the error register and the additional error field.

The emergency error code defines at which transition of the status of the EtherCAT® state machine the error occurred (see table 96, page 75).

The error register defines the status of the EtherCAT® state machine (see table 97, page 75).

The additional error field comprises five bytes (Diag 0 to 4). The **Diag 0** byte indicates the actual error (see table 98, page 75). The values in the bytes **Diag 1** to **Diag 4** are dependent on the code in the byte **Diag 0**. You will find detailed information in document ETG.1006, chapter "ESM Transition Error".

## Error messages via the EtherCAT® state machine

Table 96: Emergency error codes

| Emergency error code | Meaning   |
|----------------------|---|
| 0000h                | No error  |
| A000h                | Transition from Pre-Operational to Safe-Operational status was not successful |
| A001h                | Transition from Safe-Operational to Operational status was not successful     |



### NOTE

If an error condition is rectified, a new emergency message is sent with the emergency error code 0000h.

Table 97: Error register

| Error register | Meaning  |
|----------------|--|
| 01h            | Status of the EtherCAT® state machine = Initializing     |
| 02h            | Status of the EtherCAT® state machine = Pre-operational  |
| 03h            | Status of the EtherCAT® state machine = Safe-operational |
| 04h            | Status of the EtherCAT® state machine = Operational      |
| 05h            | SDO write function failed                                |

The value in byte 3 (Diag 0) shows which error has occurred in which Sync Manager:

Table 98: Additional Error Field Byte 3 (Diag 0)

| Additional Error Field Byte 3 (Diag 0) | Meaning   |                                   |
|--|---|-----------------------------------|
| 00h                                    | Sync Manager Length Error<br>Invalid length of the Sync Manager addressing.         | Sync Manager 0<br>(Write mailbox) |
| 01h                                    | Sync Manager Address Error<br>An incorrect address is assigned to the Sync Manager. |                                   |
| 02h                                    | PDO Length Error<br>The PDO length is incorrect.                                    |                                   |
| 03h                                    | Sync Manager Settings Error<br>Erroneous configuration of the Sync Manager.         |                                   |
| 04h                                    | Sync Manager Length Error<br>Invalid length of the Sync Manager addressing.         | Sync Manager 1<br>(Read mailbox)  |
| 05h                                    | Sync Manager Address Error<br>An incorrect address is assigned to the Sync Manager. |                                   |
| 06h                                    | PDO Length Error<br>The PDO length is incorrect.                                    |                                   |
| 07h                                    | Sync Manager Settings Error<br>Erroneous configuration of the Sync Manager.         |                                   |

| Additional Error Field Byte 3 (Diag 0) | Meaning   |                                      |
|--|---|--------------------------------------|
| 08h                                    | Sync Manager Length Error<br>Invalid length of the Sync Manager addressing.         | Sync Manager 2<br>(Process data out) |
| 09h                                    | Sync Manager Address Error<br>An incorrect address is assigned to the Sync Manager. |                                      |
| 0Ah                                    | PDO Length Error<br>The PDO length is incorrect.                                    |                                      |
| 0Bh                                    | Sync Manager Settings Error<br>Erroneous configuration of the Sync Manager.         |                                      |
| 0Ch                                    | Sync Manager Length Error<br>Invalid length of the Sync Manager addressing.         | Sync Manager 3<br>(Process data in)  |
| 0Dh                                    | Sync Manager Address Error<br>An incorrect address is assigned to the Sync Manager. |                                      |
| 0Eh                                    | PDO Length Error<br>The PDO length is incorrect.                                    |                                      |
| 0Fh                                    | Sync Manager Settings Error<br>Erroneous configuration of the Sync Manager.         |                                      |



**NOTE**

The values in the bytes **Diag 1** to **Diag 4** are dependent on the code in the byte **Diag 0**. You will find detailed information in document ETG.1006, chapter “ESM Transition Error”.

**Display of an error message in TwinCAT®**

| Server (Port) | Timestamp                  | Message  |
|---------------|----------------------------|--|
| (65535)       | 28.06.2012 12:57:09 859 ms | 'Box 4 (SICK AFM60A 18x12 B' (1001): CoE - Emergency (Hex: 'a000, 02, '0e 2c 00 2c 00').               |
| (65535)       | 28.06.2012 12:57:09 843 ms | 'Box 4 (SICK AFM60A 18x12 B' (1001): state change aborted (requested 'SAFEOP', back to 'PREOP').       |
| (65535)       | 28.06.2012 12:57:09 843 ms | 'Box 4 (SICK AFM60A 18x12 B' (1001): 'PREOP to SAFEOP' failed! Error: 'check device state for SAFEOP'. |

Figure 46: Display of an error message in TwinCAT®

**Example:**

The example shows a row in the TwinCAT® system manager. The hexadecimal values are to be interpreted as follows:

- A000h: Invalid transition from the Pre-Operational to Safe-Operational status
- 02h: Status of the EtherCAT® state machine = Pre-operational
- 0Eh: The PDO length in Sync Manager 3 is incorrect.



**NOTE**

The four other values are needed, for instance, for SICK support.

**AL status information**

Table 99: status information

| Value | Designation       | Description                    |
|-------|-------------------|--------------------------------|
| 0000h | No error          | No error                       |
| 0001h | Unspecified error | Error that cannot be specified |
| 0002h | No memory         | More than data memory          |

| Value | Designation                        | Description  |
|-------|------------------------------------|--|
| 0011h | Invalid requested state change     | The requested status change is not valid (e.g. from “Initializing” to “Operational”).                                |
| 0012h | Unknown requested state            | The requested status is unknown or not defined in the state machine.   |
| 0013h | Bootstrap not supported            | The slave does not support the “Bootstrap” status.   |
| 0014h | No valid firmware                  | The data loaded to the slave are not valid firmware.   |
| 0015h | Invalid mailbox configuration      | The configuration of the Mailbox Sync Manager is invalid. The error occurred during the bootstrap.                   |
| 0016h | Invalid mailbox configuration      | The configuration of the Mailbox Sync Manager is invalid. The error occurred in the Pre-Operational status.          |
| 0017h | Invalid sync manager configuration | The configuration of the Sync Manager is invalid.  |
| 0018h | No valid inputs available          | The application cannot provide any valid input data.   |
| 0019h | No valid outputs available         | The application cannot receive any valid output data.  |
| 001Ah | Synchronization error              | The encoder is not synchronized. It is not possible to define any specific cause of the error.                       |
| 001Bh | Sync manager watchdog              | Error detected by the watchdog. It has not been possible to receive any data or to receive data within the time-out. |
| 001Ch | Invalid sync manager types         | -  |
| 001Dh | Invalid output configuration       | The Sync Manager configuration for output data is incorrect.   |
| 001Eh | Invalid input configuration        | The Sync Manager configuration for input data is incorrect.  |
| 001Fh | Invalid watchdog configuration     | The watchdog configuration is incorrect (e.g. if the watchdog is activated, but a time-out is not configured).       |
| 0020h | Slave needs cold start             | Encoder must be restarted (Power on/off)   |
| 0021h | Slave needs “INIT”                 | The encoder must be set to the “Initializing” status.  |
| 0022h | Slave needs “PREOP”                | The encoder must be set to the “Pre-operational” status.   |
| 0023h | Slave needs “SAFEOP”               | The encoder must be set to the “Safe-operational” status.  |
| 0024h | Invalid input mapping              | The data mapping of the input data does not match the expected mapping.  |
| 0025h | Invalid output mapping             | The data mapping of the output data does not match the expected mapping.   |
| 0026h | Inconsistent settings              | General error  |
| 0027h | Free Run not supported             | The Free Run operating mode is not supported.  |
| 0028h | Synchronization not supported      | The synchronous operating modes are not supported.   |
| 0029h | Free Run needs 3 Buffer mode       | -  |
| 002Ah | Background watchdog                | -  |

| Value | Designation                         | Description   |
|-------|-------------------------------------|---|
| 002Bh | No valid inputs or outputs          | -   |
| 002Ch | Fatal Sync error                    | The Sync0 or Sync1 events can no longer be received by the encoder.   |
| 002Dh | No sync error                       | It was not possible for the encoder to receive the Sync0 or Sync1 events during the status change from "Safe-Operational" to "Operational". |
| 0030h | Invalid DC "SYNC" configuration     | The DC configuration is invalid.  |
| 0031h | Invalid DC latch configuration      | The DC latch configuration is invalid.  |
| 0032h | PLL error                           | Master not synchronized, however at least one DC event has been received  |
| 0033h | Invalid DC I/O error                | Several synchronization errors possible, no synchronization   |
| 0034h | Invalid DC time-out error           | Several synchronization errors possible, too many DC events "missed"  |
| 0042h | MBX_EOE                             | -   |
| 0043h | MBX_COE                             | -   |
| 0044h | MBX_FOE                             | -   |
| 0045h | MBX_SOE                             | -   |
| 004Fh | MBX_VOE                             | -   |
| 0050h | EEPROM no access                    | -   |
| 0051h | EEPROM error                        | No access to the EEPROM of the encoder  |
| 0060h | Slave restarted locally             | -   |
| 0061h | Device Identification value updated | The encoder's identification value has been successfully renewed.   |
| 00F0h | Application controller available    | -   |

5.4.5 Error messages

The error messages are output via the object **10F3h – Diagnosis History** (see table 21, page 34).

Table 100: Error messages based on the S\_STAT-A flags

| Text ID    | Flag (type) | Description   |
|------------|-------------|---|
| <b>115</b> | 0002h Error | Memory error:<br>Invalid EEPROM checksum on initialization  |
| <b>114</b> | 0002h Error | Position error:<br>Invalid communication with the I <sup>2</sup> C device in the sensor module                                    |
| <b>113</b> | 0002h Error | Reserved  |
| <b>112</b> | 0002h Error | Position error:<br>Invalid EEPROM checksum or Invalid internal SSI communication (MFP4 signal)                                    |
| <b>111</b> | 0002h Error | Position error:<br>Invalid synchronization or no synchronization of MA sensor with the LY singleturn position                     |
| <b>110</b> | 0002h Error | Position error:<br>The error register in LY is activated (MFP5 signal).<br>or<br>Invalid internal SSI communication (MFP4 signal) |

| Text ID | Flag (type)   | Description   |
|---------|---------------|---|
| 109     | 0002h Error   | Position error:<br>Error on the calculation of the vector length $\text{Sin}^2 + \text{Cos}^2$ in the multiturn stage     |
| 108     | 0002h Error   | Position error:<br>Error on the calculation of the vector length $\text{Sin}^2 + \text{Cos}^2$ in the singleturn stage    |
| 107     | 0002h Error   | Position and memory error:<br>Invalid communication with the I <sup>2</sup> C device in the main module                   |
| 106     | 0002h Error   | Position error:<br>Error on the calculation of the amplitude values $\text{Sin}^2 + \text{Cos}^2$ in the singleturn stage |
| 105     | 0001h Warning | Warning in relation to the speed:<br>Current measured value outside of the minimum or maximum limit                       |
| 104     | 0001h Warning | Position error:<br>Error on the calculation of the amplitude values $\text{Sin}^2 + \text{Cos}^2$ in the multiturn stage  |
| 103     | 0001h Warning | Warning in relation to the supply voltage:<br>Current measured value outside of the minimum or maximum limit              |
| 102     | 0001h Warning | Warning, sensor LED current critical:<br>Current measured value outside of the minimum or maximum limit                   |
| 101     | 0001h Warning | Warning in relation to the temperature:<br>Current measured value outside of the minimum or maximum limit                 |
| 100     | 0001h Warning | Warning:<br>General start-up error at power-on  |

Table 101: Error messages based on the S\_STAT-B flags

| Text ID | Flag (type)   | Description   |
|---------|---------------|---|
| 215     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (Sensor Config Data)                                    |
| 214     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (Device Configuration)                                  |
| 213     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (Diagnosis Process Data Basic)                          |
| 212     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (Diagnosis/Service Data)                                |
| 211     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (user configuration parameter or communication mapping) |
| 210     | -             | Reserved  |
| 209     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (user configuration 'CAM' parameter)                    |
| 208     | 0001h Warning | Memory error caused by invalid checksum on reading the EEPROM during encoder initialization (user configuration 'Basic xxx' parameter)              |
| 207     | 0001h Warning | Reserved  |
| 206     | 0001h Warning | Cycle time set for the system <480 $\mu\text{s}$  |

| Text ID     | Flag (type)      | Description   |
|-------------|------------------|---|
| 205         | 0001h<br>Warning | Reserved  |
| 204         |                  | Warning, triggered on executing the preset function:<br>The preset value, defined by the scaling parameter, is outside the measuring range (CMR). |
| 203 ... 200 | 0001h<br>Warning | Warning, occurred on changing or writing parameter values   |

Table 102: Error messages based on the S\_STAT-C flags

| Text ID     | Flag (type)            | Description  |
|-------------|------------------------|--|
| 315         | 0000h Infor-<br>mation | Information:<br>Encoder in the Free Run operating mode. The formation of the position is <b>synchronized</b> with the process data cycle of the master.              |
| 314         | 0000h Infor-<br>mation | Information: Encoder in the Synchronous operating mode. The formation of the position is <b>not synchronized</b> with the process data cycle of the master.          |
| 313         | 0000h Infor-<br>mation | Reserved   |
| 312         | 0001h<br>Warning       | Preset function has been triggered and confirmed by object 2000h (see table 67, page 50)   |
| 311 ... 304 | -                      | Reserved   |
| 303         | 0000h Infor-<br>mation | Status information on saving internal diagnostic data:<br>Save operation requested and operation in progress<br>or<br>Save operation complete                        |
| 302         | 0000h Infor-<br>mation | Status information on saving internal diagnostic data:<br>Save operation requested and operation in progress<br>or<br>Save operation complete                        |
| 301         | 0000h Infor-<br>mation | Saving the configuration data using the Save command (see table 15, page 33):<br>Save operation requested and operation in progress<br>or<br>Save operation complete |
| 300         | -                      | Reserved   |



## 6 Annex

### 6.1 Conformities and certificates

You can obtain declarations of conformity, certificates, and the current operating instructions for the product at [www.sick.com](http://www.sick.com). To do so, enter the product part number in the search field (part number: see the entry in the “P/N” or “Ident. no.” field on the type label).

#### 6.1.1 EU declaration of conformity

##### Excerpt

The undersigned, representing the manufacturer, herewith declares that the product is in conformity with the provisions of the following EU directive(s) (including all applicable amendments), and that the standards and/or technical specifications stated in the EU declaration of conformity have been used as a basis for this.

#### 6.1.2 UK declaration of conformity

##### Excerpt

The undersigned, representing the following manufacturer herewith declares that this declaration of conformity is issued under the sole responsibility of the manufacturer. The product of this declaration is in conformity with the provisions of the following relevant UK Statutory Instruments (including all applicable amendments), and the respective standards and/or technical specifications have been used as a basis.

**Australia**

Phone +61 (3) 9457 0600  
1800 33 48 02 – tollfree  
E-Mail sales@sick.com.au

**Austria**

Phone +43 (0) 2236 62288-0  
E-Mail office@sick.at

**Belgium/Luxembourg**

Phone +32 (0) 2 466 55 66  
E-Mail info@sick.be

**Brazil**

Phone +55 11 3215-4900  
E-Mail comercial@sick.com.br

**Canada**

Phone +1 905.771.1444  
E-Mail cs.canada@sick.com

**Czech Republic**

Phone +420 234 719 500  
E-Mail sick@sick.cz

**Chile**

Phone +56 (2) 2274 7430  
E-Mail chile@sick.com

**China**

Phone +86 20 2882 3600  
E-Mail info.china@sick.net.cn

**Denmark**

Phone +45 45 82 64 00  
E-Mail sick@sick.dk

**Finland**

Phone +358-9-25 15 800  
E-Mail sick@sick.fi

**France**

Phone +33 1 64 62 35 00  
E-Mail info@sick.fr

**Germany**

Phone +49 (0) 2 11 53 010  
E-Mail info@sick.de

**Greece**

Phone +30 210 6825100  
E-Mail office@sick.com.gr

**Hong Kong**

Phone +852 2153 6300  
E-Mail ghk@sick.com.hk

**Hungary**

Phone +36 1 371 2680  
E-Mail erteakesites@sick.hu

**India**

Phone +91-22-6119 8900  
E-Mail info@sick-india.com

**Israel**

Phone +972 97110 11  
E-Mail info@sick-sensors.com

**Italy**

Phone +39 02 27 43 41  
E-Mail info@sick.it

**Japan**

Phone +81 3 5309 2112  
E-Mail support@sick.jp

**Malaysia**

Phone +603-8080 7425  
E-Mail enquiry.my@sick.com

**Mexico**

Phone +52 (472) 748 9451  
E-Mail mexico@sick.com

**Netherlands**

Phone +31 (0) 30 204 40 00  
E-Mail info@sick.nl

**New Zealand**

Phone +64 9 415 0459  
0800 222 278 – tollfree  
E-Mail sales@sick.co.nz

**Norway**

Phone +47 67 81 50 00  
E-Mail sick@sick.no

**Poland**

Phone +48 22 539 41 00  
E-Mail info@sick.pl

**Romania**

Phone +40 356-17 11 20  
E-Mail office@sick.ro

**Singapore**

Phone +65 6744 3732  
E-Mail sales.gsg@sick.com

**Slovakia**

Phone +421 482 901 201  
E-Mail mail@sick-sk.sk

**Slovenia**

Phone +386 591 78849  
E-Mail office@sick.si

**South Africa**

Phone +27 10 060 0550  
E-Mail info@sickautomation.co.za

**South Korea**

Phone +82 2 786 6321/4  
E-Mail infokorea@sick.com

**Spain**

Phone +34 93 480 31 00  
E-Mail info@sick.es

**Sweden**

Phone +46 10 110 10 00  
E-Mail info@sick.se

**Switzerland**

Phone +41 41 619 29 39  
E-Mail contact@sick.ch

**Taiwan**

Phone +886-2-2375-6288  
E-Mail sales@sick.com.tw

**Thailand**

Phone +66 2 645 0009  
E-Mail marcom.th@sick.com

**Turkey**

Phone +90 (216) 528 50 00  
E-Mail info@sick.com.tr

**United Arab Emirates**

Phone +971 (0) 4 88 65 878  
E-Mail contact@sick.ae

**United Kingdom**

Phone +44 (0)17278 31121  
E-Mail info@sick.co.uk

**USA**

Phone +1 800.325.7425  
E-Mail info@sick.com

**Vietnam**

Phone +65 6744 3732  
E-Mail sales.gsg@sick.com

Detailed addresses and further locations at [www.sick.com](http://www.sick.com)