

# OLS10

Line guidance sensors

**SICK**  
Sensor Intelligence.



### Described product

OLS10

### Manufacturer

SICK AG  
Erwin-Sick-Str. 1  
79183 Waldkirch  
Germany

### Legal information

This work is protected by copyright. Any rights derived from the copyright shall be reserved for SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Any modification, abridgment or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks stated in this document are the property of their respective owner.

© SICK AG. All rights reserved.

### Original document

This document is an original document of SICK AG.



## Contents

<b>1</b>	<b>About this document.....</b>	<b>5</b>
1.1	Information on the operating instructions.....	5
1.2	Scope.....	5
1.3	Explanation of symbols.....	5
1.4	Further information.....	6
1.5	Customer service.....	6
<b>2</b>	<b>Safety information.....</b>	<b>7</b>
2.1	Intended use.....	7
2.2	Improper use.....	7
2.3	Notes on UL approval.....	7
2.4	Limitation of liability.....	7
2.5	Requirements for skilled persons and operating personnel.....	8
2.6	Hazard warnings and operational safety.....	8
2.7	Repairs.....	9
<b>3</b>	<b>Product description.....</b>	<b>10</b>
3.1	Product identification.....	10
3.2	Product features.....	12
<b>4</b>	<b>Transport and storage.....</b>	<b>13</b>
4.1	Transport.....	13
4.2	Transport inspection.....	13
4.3	Storage.....	13
<b>5</b>	<b>Mounting.....</b>	<b>14</b>
5.1	Preparation for mounting.....	14
5.2	Mounting the sensor.....	14
<b>6</b>	<b>Electrical installation.....</b>	<b>17</b>
6.1	Safety.....	17
6.2	Pin assignment of the connections.....	19
6.3	Connecting the supply voltage.....	20
6.4	CAN connection.....	20
<b>7</b>	<b>Commissioning.....</b>	<b>21</b>
7.1	Overview of commissioning steps.....	21
7.2	Commissioning the sensor for the first time.....	21
7.3	First step to commissioning with CANopen.....	21
<b>8</b>	<b>Operation.....</b>	<b>23</b>
8.1	Operating the sensor.....	23
8.2	Operation via TCP/IP.....	25
8.3	Operation via CANopen.....	27
8.4	General notes on operation.....	31

<b>9</b>	<b>Maintenance.....</b>	<b>33</b>
9.1	Cleaning.....	33
9.2	Maintenance.....	33
9.3	Repairs.....	33
<b>10</b>	<b>Decommissioning.....</b>	<b>34</b>
10.1	Decommissioning.....	34
<b>11</b>	<b>Troubleshooting.....</b>	<b>35</b>
11.1	Possible error indicators.....	35
11.2	Faults caused by the network connection.....	35
<b>12</b>	<b>Technical data.....</b>	<b>37</b>
12.1	Optics / Features.....	37
12.2	Supply.....	37
12.3	Interfaces.....	37
12.4	Outputs.....	37
12.5	Ambient conditions.....	38
12.6	Structural design.....	38
<b>13</b>	<b>Accessories.....</b>	<b>39</b>
13.1	Connectivity.....	39
13.2	Mounting systems.....	40
<b>14</b>	<b>Licenses.....</b>	<b>43</b>
14.1	lwIP.....	43
14.2	tinf.....	43
14.3	jQuery.....	44
14.4	Flot.....	44
<b>15</b>	<b>Menu structure.....</b>	<b>45</b>
<b>16</b>	<b>Annex.....</b>	<b>46</b>
16.1	EU declaration of conformity.....	46

# 1 About this document

## 1.1 Information on the operating instructions

These operating instructions provide important information on how to use sensors from SICK AG.

Prerequisites for safe work are:

- Compliance with all safety notes and handling instructions supplied.
- Compliance with local work safety regulations and general safety regulations for sensor applications.

The operating instructions are intended to be used by qualified personnel and electrical specialists.



### NOTE

Read these operating instructions carefully before starting any work on the sensor, in order to familiarize yourself with the sensor and its functions.

---

The instructions constitute an integral part of the product and are to be stored in the immediate vicinity of the sensor so they remain accessible to staff at all times. If the sensor is passed on to a third party, these operating instructions should be handed over with it.

These operating instructions do not provide information on operating the machine in which the sensor is integrated. For information about this, refer to the operating instructions of the particular machine.

## 1.2 Scope

These operating instructions explain how to incorporate a sensor into a customer system. Instructions are given in stages for all actions required.

These instructions apply to all available device variants of the sensor.

Available device variants are listed on the online product page.

▶ [www.sick.com/ols10](http://www.sick.com/ols10)

Commissioning is described using one particular device variant as an example.

### Simplified device designation in the document

In the following, the sensor is referred to in simplified form as “OLS10”.

## 1.3 Explanation of symbols

Warnings and important information in this document are labeled with symbols. The warnings are introduced by signal words that indicate the extent of the danger. These warnings must be observed at all times and care must be taken to avoid accidents, personal injury, and material damage.



### DANGER

... indicates a situation of imminent danger, which will lead to a fatality or serious injuries if not prevented.

---

**WARNING**

... indicates a potentially dangerous situation, which may lead to a fatality or serious injuries if not prevented.

---

**CAUTION**

... indicates a potentially dangerous situation, which may lead to minor/slight injuries if not prevented.

---

**NOTICE**

... indicates a potentially harmful situation, which may lead to material damage if not prevented.

---

**NOTE**

... highlights useful tips and recommendations as well as information for efficient and trouble-free operation.

---

### 1.4 Further information

**NOTE**

All the documentation available for the sensor can be found on the online product page at:

▶ [www.sick.com/ols10](http://www.sick.com/ols10)

The following information is available for download from this page:

- Type-specific online data sheets for device variants, containing technical data and dimensional drawings
  - EU declaration of conformity for the product family
  - Dimensional drawings and 3D CAD dimension models in various electronic formats
  - These operating instructions, available in English and German, and in other languages if necessary
  - Other publications related to the sensors described here
  - Publications dealing with accessories
  - EDS device description file
- 

### 1.5 Customer service

If you require any technical information, our customer service department will be happy to help. To find your representative, see the final page of this document.

---

**NOTE**

Before calling, make a note of all type label data such as type code etc. to ensure faster processing.

---

## 2 Safety information

### 2.1 Intended use

The OLS10 line guidance sensor is an opto-electronic sensor intended for detecting luminescent guide tracks as well as reading out 1D codes when they are driven over by automated guided vehicles.

SICK AG assumes no liability for losses or damage arising from the use of the product, either directly or indirectly. This applies in particular to use of the product that does not conform to its intended purpose and is not described in this documentation.



#### NOTICE

**Radio interference may occur when the sensor is used in residential areas.**

- ▶ Only use the device in industrial environments (EN 61000-6-4).

### 2.2 Improper use

- The sensor does not constitute a safety-relevant device according to the EC Machinery Directive (2006/42/EC).
- The sensor must not be used in explosion-hazardous areas.
- Any other use that is not described as intended use is prohibited.
- Any use of accessories not specifically approved by SICK AG is at your own risk.



#### NOTICE

**Danger due to improper use!**

Any improper use can result in dangerous situations.

Therefore, take note of the following information:

- ▶ The sensor should be used only in line with intended use specifications.
- ▶ All information in these operating instructions must be strictly complied with.

### 2.3 Notes on UL approval

The device must be supplied by a Class 2 source of supply.

UL Environmental Rating: Enclosure type 1

### 2.4 Limitation of liability

Applicable standards and regulations, the latest state of technological development, and our many years of knowledge and experience have all been taken into account when assembling the data and information contained in these operating instructions.

The manufacturer accepts no liability for damage caused by:

- Failing to observe the operating instructions
- Improper use
- Use by untrained personnel
- Unauthorized conversions
- Technical modifications
- Use of unauthorized spare parts, consumables, and accessories

With special variants, where optional extras have been ordered, or owing to the latest technical changes, the actual scope of delivery may vary from the features and illustrations shown here.

## 2.5 Requirements for skilled persons and operating personnel



### WARNING

#### Risk of injury due to insufficient training.

Improper handling of the sensor may result in considerable personal injury and material damage.

- All work must only ever be carried out by the stipulated persons.

The operating instructions state the following qualification requirements for the various areas of work:

- **Instructed personnel** have been briefed by the operating entity about the tasks assigned to them and about potential dangers arising from improper action.
- **Skilled personnel** have the specialist training, skills, and experience, as well as knowledge of the relevant regulations, to be able to perform tasks assigned to them and to detect and avoid any potential dangers independently.
- **Electricians** have the specialist training, skills, and experience, as well as knowledge of the relevant standards and provisions to be able to carry out work on electrical systems and to detect and avoid any potential dangers independently. In Germany, electricians must meet the specifications of the BGV A3 Work Safety Regulations (e.g., Master Electrician). Other relevant regulations applicable in other countries must be observed.

The following qualifications are required for various activities:

Activities	Qualification
Mounting, maintenance	<ul style="list-style-type: none"> <li>■ Basic practical technical training</li> <li>■ Knowledge of the current safety regulations in the workplace</li> </ul>
Electrical installation, device replacement	<ul style="list-style-type: none"> <li>■ Practical electrical training</li> <li>■ Knowledge of current electrical safety regulations</li> <li>■ Knowledge of the operation and control of the devices in their particular application</li> </ul>
Commissioning, configuration	<ul style="list-style-type: none"> <li>■ Basic knowledge of the design and setup of the described connections and interfaces</li> <li>■ Basic knowledge of data transmission</li> <li>■ Knowledge of the operation and control of the devices in their particular application</li> </ul>
Operation of the devices in their particular application	<ul style="list-style-type: none"> <li>■ Knowledge of the operation and control of the devices in their particular application</li> <li>■ Knowledge of the software and hardware environment in the application</li> </ul>

## 2.6 Hazard warnings and operational safety

Please observe the safety notes and the warnings listed here and in other chapters of these operating instructions to reduce the possibility of risks to health and avoid dangerous situations.

The OLS10 is equipped with LED illumination. The sensor meets the criteria of risk group 1 according to IEC 62471:2006. No special measures are required (e.g., eye protection).



## 2.7 Repairs

Repair work on the sensor may only be performed by qualified and authorized personnel from SICK AG. Interruptions or modifications to the sensor on the part of the customer will invalidate any warranty claims against SICK AG.

### 3 Product description

#### 3.1 Product identification

##### 3.1.1 Type label




Figure 1: Type label

- ① Type designation
- ② ID no.
- ③ MAC address
- ④ Serial number
- ⑤ Machine readable code

##### 3.1.2 Operating and status indicators




Figure 2: Device view

- ① Center of the optical axis
- ② Fixing hole
- ③ M12 male connector, 12-pin/M12 female connector, 4-pin, rotatable
- ④ Display and control unit
- ⑤ Function indicator (green) "ON"
- ⑥ Function indicator (yellow) "Q"
- ⑦ Function indicator (green) "Link"
- ⑧

- ⑧ Function indicator (yellow) “Act”

### Function indicators (LEDs)

Table 1: Function indicators (LEDs)

Function indicator	Description
Act	Data transfer display <ul style="list-style-type: none"> <li>Yellow LED: Data transfer</li> <li>LED off: No data transfer</li> </ul>
Link	Ethernet connection display <ul style="list-style-type: none"> <li>Green LED: Ethernet connection available</li> <li>LED off: No Ethernet connection available</li> </ul>
Q	Switching output display <ul style="list-style-type: none"> <li>Yellow LED: Output high</li> <li>LED off: Output low</li> <li>LED flashing (10 Hz): Overcurrent/short-circuit protection has triggered</li> </ul>
ON	Operating status display <ul style="list-style-type: none"> <li>Green LED: Normal operation/Supply voltage on</li> <li>LED off: No operation</li> </ul>

### Symbols on the control panel





The following three symbols may appear on the control panel: RUN, MEN and SET.

Table 2: Symbols on the control panel

Symbol	Description
RUN	RUN lights up: Sensor is in RUN operational status. The value of the detected code is displayed.
MEN	MEN lights up: The current position in the menu structure is displayed.
SET	SET lights up: Lowest menu level has been reached. Sensor settings and values can be changed here.

### Pushbuttons

Table 3: Pushbuttons

Pushbutton	Description
	<ul style="list-style-type: none"> <li>Select operating menu, parameter, or option.</li> <li>Reduce value.</li> </ul>
	<ul style="list-style-type: none"> <li>Select operating menu, parameter, or option.</li> <li>Increase value.</li> </ul>
	<ul style="list-style-type: none"> <li>Short press:                             <ul style="list-style-type: none"> <li>switch to the next-lowest menu level</li> <li>save parameter change</li> <li>confirm selection</li> </ul> </li> <li>Long press (&gt; 2 sec.):                             <ul style="list-style-type: none"> <li>entry to the operating menu.</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>Short press: Exit parameters without saving. Switch to the next-highest menu level.</li> <li>Long press: Exit parameters without saving. Switch to the default display.</li> </ul>

### 3.2 Product features

The OLS10 line guidance sensor is an opto-electronic sensor which detects the line center point of up to three luminescent tracks. To do so, the sensor stimulates the guide track(s) with blue light and detects the remitted light using a receiver array.

This track is typically conventional adhesive tape or a colorful luminescence track. It is not necessary to teach in the sensor.

For additional information on the adhesive tape and bar code labels recommended by SICK, see [\(accessories link\)](#).

In addition, the sensor reads 1D codes in “interleaved 2/5” format attached perpendicular to the track.

## 4 Transport and storage

### 4.1 Transport

#### Improper transport



#### **CAUTION DAMAGE TO THE PATTERN SENSOR DUE TO IMPROPER TRANSPORT!**

Substantial material damage may result in the event of improper transport.

For this reason:

- The device should be transported only by trained specialist staff.
- The utmost care and attention is required at all times during unloading and transportation on company premises.
- Note the symbols on the packaging.
- Do not remove packaging until immediately before starting installation work.

### 4.2 Transport inspection

Immediately upon receipt at the receiving work station, check the delivery for completeness and for any damage that may have occurred in transit. In the case of transit damage that is visible externally, proceed as follows:

- Do not accept the delivery or only do so conditionally.
- Note the scope of damage on the transport documents or on the transport company's delivery note.
- File a complaint.



#### **NOTE**

Complaints regarding defects should be filed as soon as these are detected. Damage claims are only valid before the applicable complaint deadlines.

### 4.3 Storage

Store the device under the following conditions:

- Recommendation: Use the original packaging.
- Do not store outdoors.
- Store in a dry area that is protected from dust.
- To allow any residual dampness to evaporate, do not package in airtight containers.
- Do not expose to any aggressive substances.
- Protect from sunlight.
- Avoid mechanical shocks.
- Storage temperature: [see "Ambient conditions", page 38](#).
- Relative humidity: [see "Ambient conditions", page 38](#).
- For storage periods of longer than 3 months, check the general condition of all components and packaging on a regular basis.

# 5 Mounting

## 5.1 Preparation for mounting

- 1 Select the mounting site for the OLS10 in accordance with the following chapter "[Mounting requirements](#)", page 14.
- 2 Mount the OLS10 using the fixing holes. "[Operating and status indicators](#)", page 10  
"[Mounting systems](#)", page 40

### 5.1.1 Mounting requirements

---



#### NOTICE

**Radio interference may occur when the sensor is used in residential areas.**

Only use the device in industrial environments (EN 61000-6-4).

---

- Typical space requirements for sensor, see "[Structural design](#)", page 38.
- Comply with technical parameters such as the permitted ambient conditions for the operation of the sensor (e.g., temperature range, EM interference), see "[Ambient conditions](#)", page 38.
- Protect the sensor from direct sunlight.
- Only affix the sensor using accessories supplied for this purpose -> there are no screw connections on the sensor.
- The light spot must cover the possible area of the three tracks. The center of the light spot is marked with a notch on the upper side of the housing.
- Sensing distance: 100 mm  
The sensing distance is the distance from the front sensor edge (housing edge) to the track or the ground.

### 5.1.2 Scope of delivery

The following are included with delivery:

- OLS10 Optical Line Guidance Sensor
- Blind plug for M12 Ethernet connection
- 1 quick-start guide

Accessories:

Accessories (e.g., cables, fastening adapters) are only supplied if ordered separately.

## 5.2 Mounting the sensor

### Arrangement over guide track

The OLS10 must be aligned orthogonally to the guide track with its light spot. The sensing range is 100 mm.

The sensor should be attached vertically over the guide track.

Table 4: Mounting




Figure 3: Arrangement over guide track

The code can be arranged directly on the track or next to the track. If it is arranged next to the track (field of view +/-50 mm), it is detected as an additional track.




Figure 4: Arrangement with branches and junctions

### Arrangement with branches and junctions

If there are branches or junctions, we recommend arranging the tracks as illustrated. The minimum distance between the tracks is 7 mm.

In addition, we recommend a minimum overlap length of the tracks of at least 10 cm. At speeds higher than 2 m/s as well as when commissioning via Ethernet, this area must be increased.

Figure 4 also shows the sign convention of the LCP with the factory settings. (-90 mm ... +90 mm on the cable side).



## 6 Electrical installation

### 6.1 Safety

#### 6.1.1 Notes on electrical installation



#### CAUTION

##### **Danger due to incorrect supply voltage!**

An incorrect supply voltage may result in injuries from electric shocks and/or damage to the device.

- Only operate the sensor with safety/protective extra-low voltage (SELV/PELV).



#### NOTICE

##### **Sensor damage or unpredictable operation due to working with live parts.**

Working with live parts may result in unpredictable operation.

- Only carry out wiring work when the power is off.
- Only connect and disconnect electrical connections when the power is off.

- 
- **The electrical installation must only be performed by electrically qualified personnel.**
  - **Standard safety requirements must be observed when working on electrical systems.**
  - Only switch on the supply voltage for the device when the connection tasks have been completed and the wiring has been thoroughly checked.
  - When using extension cables with open ends, ensure that bare wire ends do not come into contact with each other (risk of short-circuit when supply voltage is switched on!). Wires must be appropriately insulated from each other.
  - Wire cross-sections in the supply cable from the user's power system must be designed in accordance with the applicable standards. When this is being done in Germany, observe the following standards: DIN VDE 0100 (Part 430) and DIN VDE 0298 (Part 4) and/or DIN VDE 0891 (Part 1).
  - Electrical circuits connected to the device must be configured as SELV circuits (SELV = safety extra-low voltage/PELV = protective extra-low voltage).
  - Protect the device with a separate fuse at the start of the supply circuit.

A shielded cable is not required in order to adhere to the electromagnetic compatibility guidelines specified by DIN EN 60947-5-2. It is recommended, however, especially when working with longer connecting cables.

The IP enclosure rating for the sensor is only achieved if the connected cable is completely screwed in.

#### 6.1.2 Wiring notes



#### NOTE

Preassembled cables can be found online at:

- ▶ [www.sick.com/ols10](http://www.sick.com/ols10)

Please observe the following wiring notes:

- During installation, pay attention to the different cable groups. The cables are grouped into the following four groups according to their sensitivity to interference or radiated emissions:

- Group 1: Cables very sensitive to interference, such as analog measuring cables
- Group 2: Cables sensitive to interference, such as sensor cables, communication signals, bus signals
- Group 3: Cables which are a source of interference, such as control cables for inductive loads, motor brakes
- Group 4: Cables which are powerful sources of interference, such as output cables from frequency inverters, welding system power supplies, power cables
- ▷ Cables in groups 1, 2 and 3, 4 must be crossed at right angles, [see figure 5](#).
- ▷ Cables in groups 1, 2 and 3, 4 must be routed in different cable channels or metallic separators must be used, [see figure 6](#) and [see figure 7](#). This applies particularly where cables of devices with a high level of radiated emission, such as frequency converters, are laid parallel to sensor cables.




Figure 5: Cross cables at right angles




Figure 6: Ideal laying - Place cables in different cable channels




Figure 7: Alternative laying - Separate cables with metallic separators





**NOTE**

Prevent equipotential bonding currents via the cable shield with a suitable grounding method, [see "Safety", page 17](#).

## 6.2 Pin assignment of the connections

### M12 connection

M12 (A-coded)



Pin	Assignment
1 - BN	VIN
2 - BU	GND
3 - WH	Q2 - valid bar code read
4 - GN	CAN HIGH IN
5 - PK	reserved, do not connect
6 - YE	CAN LOW IN
7 - BK	CAN GND
8 - GY	reserved, do not connect
9 - RD	reserved, do not connect
10 - VT	Q1 - track detected
11 - GY/PK	CAN LOW OUT
12 - RD/BU	CAN HIGH OUT

### Ethernet connection diagram

The OLS10 features a 100 base-T Ethernet connection.

Table 5: Ethernet connection diagram, M12 female connector, 4-pin, D-coded



M12 (D-coded)

Table 6: Ethernet female connector description

Pin	Marking	Wire color	Description
1	Tx+	White/Orange	Send data signal, not inverted
2	Rx+	White/Green	Receive data signal, not inverted
3	Tx-	Orange	Send data signal, inverted
4	Rx-	Green	Receive data signal, inverted

### 6.3 Connecting the supply voltage

The sensor must be connected to a voltage supply with the following properties:

- Supply voltage DC 12 V ... 30 V (stabilized safety extra-low voltage (SELV/PELV) as per current standard EN 60950-1)
- Electricity source with at least 5 W power

#### Protecting the supply cables

To ensure protection against short-circuits/overload in the customer's supply cables, the wire cross-sections used must be appropriately selected and protected.

The following standards must be observed in Germany:

- DIN VDE 0100 (part 430)
- DIN VDE 0298 (part 4) and/or DIN VDE 0891 (part 1)

#### Electrical connection of OLS10

- Ensure the voltage supply is not connected.
- If necessary, turn the swivel connector into the desired position as shown in the




figure.

- Connect the sensor according to the connection diagram.

### 6.4 CAN connection

We recommend connecting the ground cable to the CANopen communication interface as a reference.

If there is no separate CAN GND in the system, this pin is to be connected to the FE.

## 7 Commissioning

### 7.1 Overview of commissioning steps

- Connect the voltage supply.
- Commission the sensor using the factory settings.
- Configure the sensor.

### 7.2 Commissioning the sensor for the first time



#### **NOTICE PUSHBUTTON DAMAGE DUE TO IMPROPER HANDLING!**

Improper handling of the pushbuttons can damage them. This will make operation difficult or impossible.

For this reason:

- Only operate the pushbuttons with your fingers or a suitable pointing device.
- Do not operate the pushbuttons using sharp or hard objects.

Establish voltage supply: When the sensor voltage supply is correct, the green “ON” LED lights up.

If at least one track is detected, switching output Q1 is “high” and the yellow “Q” LED lights up.

If an Ethernet connection is established, the green “Link” LED lights up.

### 7.3 First step to commissioning with CANopen

#### 7.3.1 Setting the ID and baud rate

The following conditions must be met for communication with the CAN master:

- A correct node ID must be set on the OLS10.  
The following are correct:
  - A node ID which is free in the CANopen network
  - A node ID which the master expects
- The same baud rate must be set in the OLS10 as in the master.

The following parameters are factory set on the OLS10:

- Node ID: 10
- Baud rate: 125 kbit/s

The following communication parameters can be allocated to the OLS10:

- Node ID: 1 to 127 (0 is generally assigned to the master)
- Baud rate: 10 kbit/s, 20 kbit/s, 50 kbit/s, 125 kbit/s, 250 kbit/s, 500 kbit/s, 800 kbit/s, 1,000 kbit/s


The sensor supports the configuration with LSS with a CANopen master.

The node ID and baud rate are otherwise set as follows:

#### **Setting the node ID via the control panel**

- 1 Press and hold the SET pushbutton for at least 2 seconds to access the menu.
- 2 Select the “Setting” option: Menu path: Setting → CAN → NodeID

The new values do not become active until the next time the sensor is switched on.



Other adjustments to the control panel see "Operating the sensor", page 23.

Additional adjustment to the node ID and baud rate via webUI see "Operation via TCP/IP", page 25.

### 7.3.2 Process data objects (PDOs)

The OLS10 supports two transmit PDOs and no receive PDO.

Objects 0x1800 and 0x1801 contain the communication parameters. The mapping is fixed and cannot be changed.

### 7.3.3 PDO communication

The transmission type is factory-set to timer-driven for TPDO1 and TPDO2. A transmission period of 20 ms is factory-set for TPDO1 so that it is transmitted on a cyclical basis. TPDO2 is deactivated in the factory settings, i.e., the value of the transmission period is 0 ms.

#### Changing the factory-set transmission type

The following options are available for the cyclical or acyclical output of transmit PDOs by the OLS10:

- Change the event timer in object 0x1800 or 0x1801 (see table 10)
- Change the transmission type in object 0x1800 or 0x1801 (see table 10)

## 8 Operation

### 8.1 Operating the sensor

#### 8.1.1 Navigation

You can select a menu, parameter, option or value using the **Set**, **▼** and **▲** pushbuttons.

The menu path is specified in the relevant chapters of these instructions. → For the overall menu structure and navigation, see "[Menu structure](#)", page 45.

#### 8.1.2 Selecting an option

- 1 Select the desired parameter using the **Set**, **▼** and **▲** pushbuttons.
- 2 Select the desired option using the **▼** or **▲** pushbutton.
- 3 Perform one of the following steps:
  - Press the **Set** pushbutton to save the change.
  - Press the **Esc** pushbutton to cancel the process. The parameter name is displayed again.
- 4 Perform one of the following steps to return to the default display:
  - Press the **Esc** pushbutton repeatedly until the status indicator is displayed again.
  - Wait for approx. one minute. The display will automatically switch back to the status indicator if no buttons are pressed. Any settings you have made will also be saved.

#### 8.1.3 Changing the value

- 1 Select the desired parameter using the **Set**, **▼** and **▲** pushbuttons.
- 2 Press the **Set** pushbutton. The current value of the parameter is displayed. The first digit on the left flashes.
- 3 Press the **▲** pushbutton to increase the digit. Press the **▼** pushbutton to decrease the digit.
- 4 Press the **Set** pushbutton to save the digit entered. The next digit flashes. Press the **Esc** pushbutton to cancel the process.
- 5 Repeat steps 3 and 4 until the last digit is saved. The parameter name is displayed.
- 6 Press the **Esc** pushbutton repeatedly until the default display is displayed again. Alternatively, you can wait for approx. one minute. The display will automatically switch back to the default display if no pushbuttons are pressed.

#### 8.1.4 Setting menu

The Setting menu – displayed as menSettng – is used to configure the sensor via the parameters listed below.

To access the parameters in the Setting menu, press **Set** then select the parameter using **▼**/**▲**.

The available options are selected by pressing **Set** and then **▼**/**▲** and confirmed with **Set**.

## 8.1.5 Ethernet configuration (Ethern) parameter

**NOTE**

Changes to the “Ethern” parameter are not adopted until the device is restarted.

Set the Ethernet configuration using the “Ethern” parameter.

→ Menu structure and navigation (see figure 10, page 45).

Table 7: “Ethern” parameter - the default values are shown

Parameter	Description
IPAdr	Enter an IP address. Factory setting <ul style="list-style-type: none"> <li>• MSB: 192</li> <li>• Byte2: 168</li> <li>• Byte1: 100</li> <li>• LSB: 100</li> </ul>
SubMas	Enter IP network mask. Factory setting <ul style="list-style-type: none"> <li>• MSB: 255</li> <li>• Byte2: 255</li> <li>• Byte1: 255</li> <li>• LSB: 0</li> </ul>
D gate	Enter default gateway. Factory setting <ul style="list-style-type: none"> <li>• MSB: 0</li> <li>• Byte2: 0</li> <li>• Byte1: 0</li> <li>• LSB: 0</li> </ul>
DHCP	Factory setting: Deactivated.
MAC ID	Individual address

**Entering IPAdr, SubMas, DHCP, MAC ID and D gate**

The “IPAdr”, “SubMas” and “D gate” parameters are entered in an identical manner. Entry for the IP address is described here.

- 1 Select the “IPAdr” parameter under “Ethern”.
- 2 Press the **Set** pushbutton. The current value for the “Most significant byte” is displayed. The first digit on the left flashes.
- 3 Press the **▲** pushbutton to increase the digit. Press the **▼** pushbutton to decrease the digit.
- 4 Press the **Set** pushbutton to save the digit entered. The next digit flashes.
- 5 Repeat steps 3 and 4 until the last digit is saved. The value of the next byte is displayed.
- 6 Repeat steps 3 to 5 for the second, third and fourth byte (least significant byte).
- 7 After you have confirmed entry for the value of the fourth byte with the **Set** pushbutton, the “IPAdr” parameter is displayed.

## 8.1.6 CANopen settings parameter

The NodeID and baud rate CANopen settings can be set via the “CAN” menu item.



Table 8: NodeID and baud rate settings

Parameter	Description
NodeID	Setting of the NodeID Options: Node ID: 1 to 127 (0 is generally assigned to the master) Factory setting: 10
Baud	Setting of the baud rate Options: 10 kbit/s, 20 kbit/s, 50 kbit/s, 125 kbit/s, 250 kbit/s, 500 kbit/s, 800 kbit/s, 1,000 kbit/s Factory setting: 125 kbit/s

### Configuring NodeID

Press and hold the SET pushbutton for at least 2 seconds to access the menu. Select the “Setting” option: Menu path: Setting → CAN → NodeID

### Configuring the baud rate

Press and hold the SET pushbutton for at least 2 seconds to access the menu. Select the “Setting” option: Menu path: Setting → CAN → Baud

## 8.1.7 Device reset (Reset) parameter

### Performing a reset

Table 9: Reset

Parameter	Description
Reset	Perform a reset. Options <ul style="list-style-type: none"> <li>• Yes: Perform a reset.</li> <li>• No</li> </ul> Factory setting <ul style="list-style-type: none"> <li>• No</li> </ul>

- 1 Select the “Reset” parameter in the “Setting” menu.
- 2 Select the “yes” option.
- 3 Press the **Set** pushbutton to reset the device to its initial state. Press the **Esc** pushbutton to cancel the process.

## 8.1.8 Info menu

The IP address, serial number and software version parameters can be viewed in the Info menu.

The respective values are displayed after **Set** (parameter selection) is pressed.

## 8.2 Operation via TCP/IP

Configuration, operation and diagnostics of the OLS10 Optical Line Guidance Sensor can be performed using the Ethernet interface as an alternative to manual operation via the operating and display elements on the device. SICK AG offers a configuration and diagnostic interface via the web server integrated in the sensor in order to activate or evaluate the OLS10 via Ethernet TCP/IP. This can be called up by a PC or an HMI with a web browser.

In addition, communication with the sensor is possible via the SICK ColaB protocol. Comprehensive documentation can be found on the SICK AG homepage ([www.sick.com/ols10](http://www.sick.com/ols10)).

### 8.2.1 Operating interface on the integrated web server

The “Device overview” tab first appears when the WebUI is started. The following information is displayed here:




Figure 8: Device overview

- 1 Device information such as device name, serial number, part number, firmware version, SOPAS interface version as well as the device status.
- 2 Visualization of the (up to) three line center points as well as the read bar code value.

Various device parameters can be modified in the “Settings” tab.

**SICK**  
Sensor Intelligence.

Device Overview Settings Developer

**1** Mounting parameters  
Sensor flipped upside down   
Save Changes

**2** Tape parameters  
Minimum tape width [mm] 5  
Maximum tape width [mm] 75  
Typical tape width [mm] 15  
Save Changes

**3** Advanced settings  
Max. number of missing track readings 5  
Save Changes

**4** Communication settings  
Note: Settings will be applied after CANopen restart (press button below) or upon device power cycle.  
CANopen node id 8  
CANopen bitrate 1M  
TPDO/Event period [ms] 20  
Save Changes

Restart CANopen  
Reset to factory defaults

**5** Current track data  
Status #LCP 3  
LCP1 [mm] -64  
LCP2 [mm] 10  
LCP3 [mm] 10  
Code reader  
Code value 27

User  
Developer Logout  
Language  
English

Figure 9: Settings

- 1 Sensor flipped upside down:  
0 => Positive positions on cable outlet side  
1 => Positive positions on display side
- 2 Minimum track width: Smaller tracks are ignored  
Maximum track width: Wider tracks are ignored  
Typical track width: Specification of the typical track width makes it possible to output the correct line center point even at the edge of the reading window
- 3 Missing line readings: If the track is not detected (contamination), the last detected line center point is output for a defined number of sensing processes
- 4 CANopen node ID: Setting of the node ID: Default value is 10  
CANopen bit rate: Setting of the bit rate. Default value is 125K  
TPDO/Event period: Setting of the TPDO/event period
- 5 Output of the three line center points, the number of detected tracks (status) as well as the read code.

## 8.3 Operation via CANopen

### CANopen object directory

This chapter contains information on integration of the sensor using CANopen.

All sensor functions can be accessed via the CANopen interface. All settings can be configured in this interface. The EDS file can also be found at [www.sick.com/ols10](http://www.sick.com/ols10).

## 8.3.1 OBD

This section only describes the objects that do not have a fixed definition in the CANopen standard. Default values are listed only for parameters that can be modified by the user.

Table 10: OBD

Index	Sub-idx	R/W	Object name	Default value	Type	Description
0x1000	-	RO	Device type		UINT32	No device profile supported
0x1001	-	RO	Error register		UINT8	
0x1008	-	RO	Manufacturer device name		STRING	Optical Line Guidance Sensor
0x1009	-	RO	Manufacturer hardware rev		STRING	Hardware version, sensor
0x100A	-	RO	Manufacturer software rev		STRING	Firmware version, sensor
0x100C	-	R/W	Guard time		UINT16	
0x100D	-	R/W	Life time		UINT8	
0x1017	-	R/W	Heart beat time		UINT16	
0x1018		RO	Identity object		UINT8	
	1	RO	Vendor ID		UINT32	0x01000056 (SICK AG)
	2	RO	Product code		UINT32	
	3	RO	Revision number		UINT32	
	4	RO	Serial number		UINT32	
0x1800			Transmit PDO communication parameter 0			
	1	R/W	COB ID	0x0000018A	UINT32	See <a href="#">chapter 8.3.2</a>
	2	R/W	Transmission type	0xFF	UINT8	See <a href="#">chapter 8.3.2</a>
	5	R/W	Event timer	0x014	UINT16	
0x1801			Transmit PDO communication parameter 2			
	1	R/W	COB ID	0x0000018A	UINT32	See <a href="#">chapter 8.3.2</a>
	2	R/W	Transmission type	0xFF	UINT8	See <a href="#">chapter 8.3.2</a>
	5	R/W	Event timer	0x014	UINT16	See <a href="#">chapter 8.3.2</a>

Index	Sub-idx	R/W	Object name	Default value	Type	Description
0x2001			Mounting parameters			
	5	R/W	Flipped upside down		BOOL	0 => Positive positions on cable outlet side 1 => Negative positions on cable outlet side
0x2002			Tape parameters			
	1	R/W	Typ. width [m]		FLOAT	Typical track width. The specification of the typical track width makes it possible to output the correct line center point even at the edge of the reading window.
	2	R/W	Min. width [m]		FLOAT	Minimum track width. Smaller tracks are ignored.
	3	R/W	Max. width [m]		FLOAT	Maximum track width. Wider tracks are ignored.
0x2003			Advanced settings			
	1	R/W	Max. number of missing line readings		UINT16	If the track is not detected (contamination), the last detected line center point is output for a defined number of sensing processes.
0x2018		RO	Device status		UINT16	0: Sensor ok. 1: There is a short-circuit at output Q1 or Q2.
0x2019		RO	Order number		UINT32	
0x2021			Result data (LCPs) <sup>1</sup>			
	1	RO	LCP1 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	2	RO	LCP2 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	3	RO	LCP3 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	4	RO	Status		UINT8	See <a href="#">chapter 8.3.2</a>
	5	RO	Width LCP1 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	6	RO	Width LCP2 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	7	RO	Width LCP3 <sup>1</sup>		INT16	See <a href="#">chapter 8.3.2</a>
	8	RO	Code		UINT8	See <a href="#">chapter 8.3.2</a>
	9	RO	Extended code		UINT32	See <a href="#">chapter 8.3.2</a>

<sup>1</sup> LCP = line center point

8.3.2 PDOs

The OLS10 has two TPDOs (TPDO01 and TPDO02) with fixed mapping and no RPDO. TPDO1 can be accessed under the index 0x0180 + node ID, TPDO02 under 0x280 + node ID. In its default state (node ID 0x0A), the index for TPDO1 is 0x018A.

The TPDO1 is structured as follows:

Table 11: CANopen PDO01

	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
<b>TPDO1</b>	LSB LCP1	MSB LCP1	LSB LCP2	MSB LCP2	LSB LCP3	MSB LCP3	Status	Bar code

Table 12: Byte 7 status

	Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5	Bit 6	Bit 7
<b>Status</b>	#LCP bit 0	#LCP bit 1	#LCP bit 2	x	Device status	x	Code flipped	Code valid

Table 13: TPDO2

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
<b>TPDO2</b>	LSB Width line 1	MSP Width line 1	LSB Width line 2	MSP Width line 2	LSB Width line 3	MSP Width line 3	x	x

<b>#LCP</b>	UINT3	The numbers are assigned the following meanings: 0 => No track found 2 => One track found 3 => Two tracks found: Diverter on minus side (factory setting) 6 => Two tracks found: Diverter on plus side (factory setting) 7 => Three tracks found
<b>Device status</b>	Bool	0 => Sensor ok 1 => Sensor not OK, see 0x2018
<b>Code flipped</b>	Bool	0 => Code was read from the minus to the plus side of the sensor 1 => Code was read from the plus to the minus side of the sensor
<b>Code valid</b>	Bool	0 => No code read 1 => Valid code has been read

Table 14: Byte 8 bar code

	Bit 0-7
<b>Bar code</b>	Code 0 ... 255

8.3.3 Transmission types

The transmission type of the respective TPDO can be set in index 0x1800 or 0x1801. This index comprises the following subindexes:

Table 15: Subindexes

Subindex	Name	Permissible values	Description
1	COB-ID	-	The COB ID is automatically adjusted to the note ID and should not be amended by the user.


Subindex	Name	Permissible values	Description
2	Transmission type	0xFE, 0xFF	The transmission type is set here. The OLS supports all transmission types in the value range 0x00 to 0xFF.
3	not used	-	Not used
4	Compatibility entry	-	Not used
5	Event timer	0 ... 65535	The event timer sets the time between two transmissions from the TPDO in [ms]. A value of 0 deactivates the transmission of the process data. The smallest logical value recommended here is 10 ms.

## 8.4 General notes on operation

### 8.4.1 Output of line center points

The OLS10 is capable of detecting up to three line center points (LCPs). The position of each line center point is output to a resolution of 1 mm. The geometric center of the sensor's longitudinal axis is the zero point, see "optical center", page 12.

By default, the positive measuring range is towards the cable outlet, and the negative measuring range is on the opposite side.



If only one line center point is found, this is output as LCP2. If a further line center point is found, it is output as LCP1 or LCP3, depending on its direction. If three LCPs are found, then each LCP is output.

If there are multiple tracks in the field of view, the track closest to zero is the main track (LCP2).

To make it easier for the control system to evaluate this data, the combination of tracks detected is output in an additional data item #LCP. The LCPs are binary-weighted:

Table 16: Line center points

LCP1 detected	LCP2 detected	LCP3 detected	#LCP	Comment
no	no	no	0	Special case: No track detected
no	yes	no	2	Only one track detected
yes	yes	no	3	Single diverter on the minus side detected (factory setting)
no	yes	yes	6	Single diverter on the plus side detected (factory setting)
yes	yes	yes	7	Double diverter detected

The principle of  $LCP1 < LCP2 < LCP3$  always applies to the LCPs.

### 8.4.2 Inversion of the relative position

This function enables the user to invert the convention that the positive range is at the cable outlet. This makes it easier to install the sensor when rotated by 180°.

The position can be inverted via CANopen or Ethernet.

The inversion of the position signal (sensor flipped) does not affect the LED behavior.

### 8.4.3 Bar code detection

The OLS10 has the option of detecting 1D bar codes in the interleaved 2/5 format. Up to 4-digit bar codes are detected and read out in this case.

The OLS10 outputs the number value of the bar code via CANopen or Ethernet.

In addition to track tape, SICK also offers a set of numbered bar codes as accessories [see "Accessories", page 39](#). The assignment of the bar code value to a certain drive command or piece of position information must be done on the control side.



## 9 Maintenance

### 9.1 Cleaning



**CAUTION DEVICE DAMAGE DUE TO IMPROPER CLEANING!**

Improper cleaning may result in device damage.

For this reason:

- Never use cleaning agents containing aggressive substances.
- Never use sharp objects for cleaning.

Clean the front screen at regular intervals with a lint-free cloth and plastic cleaning agent. Cleaning agents containing solvents are not allowed.

The cleaning interval essentially depends on the ambient conditions.

### 9.2 Maintenance

The sensor requires the following maintenance work at regular intervals:

*Table 17: Maintenance schedule*

Interval	Maintenance work	To be performed by
Cleaning interval depends on ambient conditions and climate	Clean housing, particularly the front screen.	Specialist
Every 6 months	Check the screw connections and plug connectors.	Specialist

### 9.3 Repairs

Repairs on the sensor may only be carried out by the manufacturer. Any interruption or modification of the sensor will invalidate the manufacturer warranty.

### 10 Decommissioning

#### 10.1 Decommissioning

##### Removing the sensor

1. Switch off the supply voltage to the sensor.
2. Detach all connecting cables from the sensor.
3. If the sensor is being replaced, mark its position and alignment on the bracket or surroundings.
4. Remove the sensor from the slot.

##### Disposing of the sensor

Any sensor which can no longer be used must be disposed of in an environmentally friendly manner in accordance with the applicable country-specific waste disposal regulations. The sensor is electronic waste and must under no circumstances be disposed of with general waste.

## 11 Troubleshooting

Potential faults and rectification measures are described in the table below and in the next chapter.

In the case of faults that cannot be rectified using the information below, please contact the manufacturer. See the back page for your agency.

### 11.1 Possible error indicators

Table 18: Possible error indicators

Error code indicator on the display	Possible causes	Troubleshooting
Err001	There is a short circuit at output Q1 or Q2.	Resolve short circuit.



#### NOTE

Please check the supply voltage, perform a power cycle or contact the manufacturer for other error codes.

### 11.2 Faults caused by the network connection



#### NOTE

We recommend having the network connection of the OLS10 established by your network administrator.

Check the individual items according to the following table.

Table 19: Faults caused by the network connection

Cause/Item to be checked	Check	Troubleshooting
The sensor is connected to a network using a network cable.	<ul style="list-style-type: none"> <li>The "Link" LED on the sensor must light up (Ethernet connection OK).</li> <li>The "Act" LED on the sensor must light up (data transfer).</li> </ul>	
The sensor IP configuration is not correct.	Check IP configuration on the sensor. → See " <a href="#">Ethernet configuration (Ethern) parameter</a> ", <a href="#">page 24</a> .	
After entering the new IP address, the supply voltage of the sensor was not switched off, then back on (restart). The sensor does not adopt the new IP address until the sensor is restarted.	Check IP configuration on the sensor. → See " <a href="#">Ethernet configuration (Ethern) parameter</a> ", <a href="#">page 24</a> .	Switch the supply voltage off and back on after checking the IP configuration.

Cause/Item to be checked	Check	Troubleshooting
The IP configuration for the existing network is not compatible.	<ul style="list-style-type: none"><li>• Check IP configuration, IP address, subnet mask and gateway. → See "<a href="#">Ethernet configuration (Ethernet parameter)</a>", page 24</li><li>• Use the “ping” diagnostics tool to check whether the sensor is correctly integrated in your IP network. The sensor must answer with an echo ICMP package (echo request). The “Activity” LED on the sensor must light up.</li></ul>	Contact your network administrator.

## 12 Technical data



### NOTE

The relevant online data sheet for the OLS10, including technical data, dimensions, and connection diagrams, can be downloaded, saved, and printed at [www.sick.com/ols10](http://www.sick.com/ols10).

### 12.1 Optics / Features

Table 20: Optics / Features

Light sender <sup>1</sup>	Blue LED
Wavelength	450 nm
Light spot size	180 mm x 11 mm Track field of view +/-90 mm Code field of view +/-50 mm
Sensing distance	100 mm
Sensing distance tolerance	± 10 mm
Sensing rate	10 ms (CAN), 20 ms (Ethernet)
Bar code types	2/5 interleaved
Module width (min.)	≥ 1.5 mm
Track radius (min.)	≥ 0.5 m
Initialization time	< 10 s

<sup>1</sup> Average service life 100,000 h at TU = +25 °C.

### 12.2 Supply

Table 21: Supply

Supply voltage $U_V$ <sup>1</sup>	12 V DC ... 30 V DC
Power consumption (with-out load)	< 6 W
Residual ripple	< 5 $V_{SS}$ within permitted supply voltage $U_V$ (must not exceed or be less than the $U_V$ tolerances.)

<sup>1</sup> Limit values: Max. 8 A for operation in a short-circuit protected network

### 12.3 Interfaces

Table 22: Interfaces

CANopen Ethernet	Configuration and process interfaces
---------------------	--------------------------------------

### 12.4 Outputs

Table 23: Outputs

Q1, Q2 switching outputs	PNP <ul style="list-style-type: none"> <li>• HIGH = <math>U_V - \leq 2</math> V</li> <li>• LOW &lt; 0.5 V</li> </ul>
Circuit protection	Output Q1 + Q2 overcurrent and short-circuit protection (see Table 1)
Maximum output current	< 100 mA (total $I_{OUT} = Q1 + Q2$ )

## 12.5 Ambient conditions

Table 24: Ambient conditions

Protection class	III, for operation with safety/protective extra-low voltage (SELV/PELV)
Electromagnetic compatibility	EN 61000-6-2, EN 55011, Class A
Ambient temperature range	-10 °C ... +55 °C
Storage temperature range	-20 °C ... +75 °C
Ambient light immunity	50,000 lx
Enclosure rating	IP64
Vibration resistance (sine)	EN60068-2-6
Noise	EN60068-2-64
Shock resistance/Impact load	EN 60086-2-27

## 12.6 Structural design

Table 25: Structural design

Dimensions (W x H x D)	46 mm x 77 mm x 46 mm
Weight	325 g
Materials	Housing: metal, discharge plate: glass
Connections <sup>1</sup>	<ul style="list-style-type: none"> <li>• M12 male connector, 12-pin</li> <li>• M12 Ethernet connection, 4-pin</li> </ul>
Control panel	OLED

<sup>1</sup> Use twisted and shielded cables.

## 13 Accessories

### 13.1 Connectivity

#### 13.1.1 Female cable connectors with cables



Description	M12 female cable connector, 12-pin, straight, 5 m, shielded, twisted-pair wires
Type	DOL-1212-G05MAS02
Part no.	6042754




Description	M12 female cable connector, 12-pin, angled, 5 m, shielded, twisted-pair wires
Type	DOL-1212-W05MAS02
Part no.	6044109

#### 13.1.2 Connection cable



Description	M12 connection cable. 12-pin, straight male connector/straight female connector, 5 m, shielded, twisted-pair wires
Type	DSL-1212-G05MAS02
Part no.	6045234

#### 13.1.3 Ethernet cable




Description	Ethernet cable, 4-wire, shielded, M12 male connector, straight, 4-pin (D-coded), RJ-45 male connector, 8-pin, 5 m
Type	Connection cable (male connector-male connector)
Part no.	6034415



Description	Ethernet cable, 4-wire, shielded, M12 male connector, angled, 4-pin (D-coded), RJ-45 male connector, 8-pin, 5 m
Type	Connection cable (male connector-male connector)
Part no.	6039488


## 13.2 Mounting systems

### 13.2.1 Universal clamp plate



Alle Maße in mm


Description	Plate N04 for universal clamp, steel, zinc-coated, incl. universal clamp and mounting hardware
Type	BEF-KHS-N04
Part no.	2051610



Alle Maße in mm


Description	Mounting rod, straight, 200 mm, steel, zinc-coated, without mounting hardware, plate N04 for universal clamp, steel, zinc-coated, including universal clamp and mounting hardware
Type	BEF-MS12G-A
Part no.	4056054







Alle Maße in mm







Description	Mounting rod, L-shape, 250 mm x 250 mm, steel, zinc-coated, without mounting hardware
Type	BEF-MS12L-B
Part no.	4056053



Description	Mounting rod with thread, straight, 100 mm, steel, zinc-coated, incl. mounting hardware
Type	BEF-MS12G-AG
Part no.	2062405

### 13.2.3 Track tape

	Part number	Description	Type
	5337868	Luminescent duct tape for easy application to all types of flooring	ADHESIVE TAPE, DUCT TAPE, 25.0*25M NEON ORANGE
	5338378	Luminescent rugged PVC adhesive tape for easy application to all types of flooring	ADHESIVE TAPE, PVC, 20.0*25M NEON ORANGE

	Part number	Description	Type
	5338386	Protective film for adhesive tape, slip resistance class R10, protection against abrasion and moisture	PROTECTIVE FILM, 35.0*50M NEON ORANGE
	5338387	Luminescent rugged PVC adhesive tape, prepared as 90° arc with a radius of 500 mm	ADHESIVE TAPE, PVC ARC, 500MM NEON ORANGE
	5338388	Luminescent rugged PVC adhesive tape, prepared as 90° arc with a radius of 1,000 mm	ADHESIVE TAPE, PVC ARC, 1000MM NEON ORANGE
	5338389	Protective film for adhesive tape, slip resistance class R10, protection against abrasion and moisture, prepared as 90° arc with a radius of 500 mm	PROTECTIVE FILM, ARC, 500MM NEON ORANGE
	5338390	Protective film for adhesive tape, slip resistance class R10, protection against abrasion and moisture, prepared as 90° arc with a radius of 1,000 mm	PROTECTIVE FILM, ARC, 1000MM NEON ORANGE
	5338408	1D bar codes in 2/5 interleaved format. Set of 108 bar codes on 9 A4 sheets. Luminescent PVC backing material with protective film.	SHEET, BAR CODE LINE TRACKING, A4

## 14 Licenses

### 14.1 lwIP

In the sensors, LwIP 1.4 is used in accordance with the modified BSD license, see <http://savannah.nongnu.org/projects/lwip/>

lwIP is licenced under the BSD licence:

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1 Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2 Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3 The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Registration date: Thu17 Oct 2002 21:13:13 UTC

License: Modified BSD license

### 14.2 tinf

tinf 1.00 is used in the OLS10 in accordance with the zlib license:

tinf - tiny inflate library

Copyright (c) 2003 by Joergen Ibsen / Jibz

All Rights Reserved

<http://www.ibsensoftware.com/>

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

- 1 The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
- 2 Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
- 3 This notice may not be removed or altered from any source distribution.

### 14.3 jQuery

jQuery is used in the OLS10 in accordance with the MIT license:

Copyright JS Foundation and other contributors, <https://js.foundation/>

This software consists of voluntary contributions made by many individuals. For exact contribution history, see the revision history available at <https://github.com/jquery/jquery>

The following license applies to all parts of this software except as documented below:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

All files located in the node\_modules and external directories are externally maintained libraries used by this software which have their own licenses; we recommend you read them, as their terms may differ from the terms above.

### 14.4 Flot

Flot 0.8.3 is used in the OLS10 in accordance with the MIT license:

Copyright (c) 2007-2014 IOLA and Ole Laursen

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

## 15 Menu structure




Figure 10: Menu structure

## 16 Annex

### 16.1 EU declaration of conformity

The EU declaration of conformity can be downloaded from the Internet at:

[www.sick.com/ols10](http://www.sick.com/ols10)



**Australia**

Phone +61 (3) 9457 0600  
1800 33 48 02 – tollfree  
E-Mail sales@sick.com.au

**Austria**

Phone +43 (0) 2236 62288-0  
E-Mail office@sick.at

**Belgium/Luxembourg**

Phone +32 (0) 2 466 55 66  
E-Mail info@sick.be

**Brazil**

Phone +55 11 3215-4900  
E-Mail comercial@sick.com.br

**Canada**

Phone +1 905.771.1444  
E-Mail cs.canada@sick.com

**Czech Republic**

Phone +420 2 57 91 18 50  
E-Mail sick@sick.cz

**Chile**

Phone +56 (2) 2274 7430  
E-Mail chile@sick.com

**China**

Phone +86 20 2882 3600  
E-Mail info.china@sick.net.cn

**Denmark**

Phone +45 45 82 64 00  
E-Mail sick@sick.dk

**Finland**

Phone +358-9-25 15 800  
E-Mail sick@sick.fi

**France**

Phone +33 1 64 62 35 00  
E-Mail info@sick.fr

**Germany**

Phone +49 (0) 2 11 53 01  
E-Mail info@sick.de

**Hong Kong**

Phone +852 2153 6300  
E-Mail ghk@sick.com.hk

**Hungary**

Phone +36 1 371 2680  
E-Mail ertekesites@sick.hu

**India**

Phone +91-22-6119 8900  
E-Mail info@sick-india.com

**Israel**

Phone +972-4-6881000  
E-Mail info@sick-sensors.com

**Italy**

Phone +39 02 27 43 41  
E-Mail info@sick.it

**Japan**

Phone +81 3 5309 2112  
E-Mail support@sick.jp

**Malaysia**

Phone +603-8080 7425  
E-Mail enquiry.my@sick.com

**Mexico**

Phone +52 (472) 748 9451  
E-Mail mario.garcia@sick.com

**Netherlands**

Phone +31 (0) 30 229 25 44  
E-Mail info@sick.nl

**New Zealand**

Phone +64 9 415 0459  
0800 222 278 – tollfree  
E-Mail sales@sick.co.nz

**Norway**

Phone +47 67 81 50 00  
E-Mail sick@sick.no

**Poland**

Phone +48 22 539 41 00  
E-Mail info@sick.pl

**Romania**

Phone +40 356-17 11 20  
E-Mail office@sick.ro

**Russia**

Phone +7 495 283 09 90  
E-Mail info@sick.ru

**Singapore**

Phone +65 6744 3732  
E-Mail sales.gsg@sick.com

**Slovakia**

Phone +421 482 901 201  
E-Mail mail@sick-sk.sk

**Slovenia**

Phone +386 591 78849  
E-Mail office@sick.si

**South Africa**

Phone +27 (0)11 472 3733  
E-Mail info@sickautomation.co.za

**South Korea**

Phone +82 2 786 6321  
E-Mail info@sickkorea.net

**Spain**

Phone +34 93 480 31 00  
E-Mail info@sick.es

**Sweden**

Phone +46 10 110 10 00  
E-Mail info@sick.se

**Switzerland**

Phone +41 41 619 29 39  
E-Mail contact@sick.ch

**Taiwan**

Phone +886-2-2375-6288  
E-Mail sales@sick.com.tw

**Thailand**

Phone +66 2 645 0009  
E-Mail marcom.th@sick.com

**Turkey**

Phone +90 (216) 528 50 00  
E-Mail info@sick.com.tr

**United Arab Emirates**

Phone +971 (0) 4 88 65 878  
E-Mail info@sick.ae

**United Kingdom**

Phone +44 (0)17278 31121  
E-Mail info@sick.co.uk

**USA**

Phone +1 800.325.7425  
E-Mail info@sick.com

**Vietnam**

Phone +65 6744 3732  
E-Mail sales.gsg@sick.com

Further locations at [www.sick.com](http://www.sick.com)

