

Lector85x CAN I/O

Image-based code reader

SICK
Sensor Intelligence.



Described product

Lector85x CAN I/O

Manufacturer

SICK AG
Erwin-Sick-Str. 1
79183 Waldkirch
Germany

Legal information

This work is protected by copyright. Any rights derived from the copyright shall be reserved for SICK AG. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Any modification, abridgment or translation of this document is prohibited without the express written permission of SICK AG.

The trademarks stated in this document are the property of their respective owner.

© SICK AG. All rights reserved.

Original document

This document is an original document of SICK AG.



Contents

1	About this document.....	5
1.1	Information on the operating instructions.....	5
1.2	Symbols and document conventions.....	5
1.3	Related applicable documents.....	5
1.4	Further information.....	6
2	Safety information.....	7
2.1	Basic safety notes.....	7
2.2	Intended use.....	9
2.3	Improper use.....	9
2.4	Cybersecurity.....	9
2.5	Qualification of personnel.....	10
3	Product description.....	11
3.1	Scope of delivery.....	11
3.2	Type label.....	11
3.3	Type code.....	12
3.4	Product overview.....	13
3.5	Integrated illumination unit.....	14
3.6	Display and control elements.....	14
3.7	Working distance and field of view size.....	18
3.8	Focus setting.....	18
3.9	Code object assignment.....	19
4	Mounting.....	20
4.1	Planning for mounting.....	20
4.2	Mounting the lens and illumination unit.....	20
4.3	Mounting the external illumination.....	23
4.4	Assembling the product.....	24
5	Electrical installation.....	25
5.1	Prerequisites for safe operation of the device.....	25
5.2	Pin assignment.....	29
5.3	Pin assignment for external illumination.....	31
5.4	Network services and ports.....	32
5.5	CAN interface.....	32
5.6	CAN connection principle.....	33
5.7	Connection principle for external illumination.....	35
5.8	Connection modules.....	36
6	Commissioning.....	37
6.1	Starting SOPASair.....	37
6.2	Password management.....	37
6.2.1	Password assignment.....	37
6.2.2	Changing password.....	38

6.2.3	Resetting the password.....	38
6.3	Starting SOPAS ET.....	38
6.4	External data back-up.....	39
6.5	Inserting and removing memory card.....	40
6.6	Saving the parameter set.....	40
6.7	Installing firmware updates.....	41
7	Maintenance.....	42
7.1	Maintenance.....	42
7.2	Cleaning the product.....	42
8	Troubleshooting.....	43
8.1	Troubleshooting.....	43
8.2	Repair.....	43
8.3	Removing the product.....	43
9	Decommissioning.....	44
9.1	Disposal of the product.....	44
10	Technical data.....	45
10.1	Features.....	45
10.2	Mechanics and electronics.....	46
10.3	Dimensional drawing.....	47
10.4	Performance.....	48
10.5	Interfaces.....	49
10.6	Ambient data.....	50
10.7	Field of view.....	51
10.8	Data sheet for external illumination.....	60
10.9	Dimensional drawing of external illumination.....	61
11	Accessories.....	62
12	Annex.....	63
12.1	Declarations of conformity and certificates.....	63
12.2	Licenses.....	63

1 About this document

1.1 Information on the operating instructions

Read these operating instructions carefully to familiarize yourself with the product and its functions before commencing any work.

The operating instructions are an integral part of the product. Store the instructions so they remain accessible to staff at all times. If the product is passed on to a third party, these operating instructions should be handed over with it.

These operating instructions do not provide information on the handling and safe operation of the machine or system in which the product is integrated. Information on this can be found in the operating instructions for the machine or system.

1.2 Symbols and document conventions

Warnings and other notes



DANGER

Indicates a situation presenting imminent danger, which will lead to death or serious injuries if not prevented.



WARNING

Indicates a situation presenting possible danger, which may lead to death or serious injuries if not prevented.



CAUTION

Indicates a situation presenting possible danger, which may lead to moderate or minor injuries if not prevented.



NOTICE

Indicates a situation presenting possible danger, which may lead to property damage if not prevented.



NOTE

Highlights useful tips and recommendations as well as information for efficient and trouble-free operation.

Instructions to action

- ▶ The arrow denotes instructions to action.
- 1. The sequence of instructions is numbered.
- 2. Follow the order in which the numbered instructions are given.
- ✓ The tick denotes the results of an action.

1.3 Related applicable documents

Related applicable documents from SICK

Document	Title	Part number	Source
Technical information	VI83I-xxxxxxHx illumination unit	8027770	www.sick.com/8027770

1.4 Further information

More information can be found on the product page.

The call is made via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

The following information is available depending on the product:

- Data sheets
- This document in all available language versions
- CAD files and dimensional drawings
- Certificates (e.g., declaration of conformity)
- Other publications
- Software
- Accessories

2 Safety information

2.1 Basic safety notes

Please observe the safety notes and the warnings listed here and in other sections of this product documentation to reduce the possibility of risks to health and avoid dangerous situations.

Danger due to visible radiation is product-specific. See the technical data for more information.

Laser notes




CAUTION

Optical radiation: Class 1 Laser Product

The accessible radiation does not pose a danger when viewed directly for up to 100 seconds. It may pose a danger to the eyes and skin in the event of incorrect use.

- Do not open the housing. Opening the housing may increase the level of risk.
- Current national regulations regarding laser protection must be observed.



IEC 60825-1: 2014

EN 60825-1:2014+A11:2021

Complies with 21 CFR 1040.10 and 1040.11 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.

Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

No maintenance is required to ensure compliance with the laser class.

LED notes



CAUTION

Optical radiation: LED risk group 1, visible radiation, 400 nm to 780 nm

The LEDs may pose a danger to the eyes in the event of incorrect use.

- Do not look into the light source intentionally.
- Do not open the housing. Opening the housing will not switch off the light source. Opening the housing may increase the level of risk.
- Comply with the current national regulations on photobiological security of lamps and lamp systems.

If the product is operated in conjunction with external illumination units, the risks described here may be exceeded. This must be taken into consideration by users on a case-by-case basis.

No maintenance is required to ensure compliance with the LED risk group.

For both radiation types:

It is not possible to entirely rule out temporary disorienting optical effects, particularly in conditions of dim lighting. Disorienting optical effects may come in the form of dazzle, flash blindness, afterimages, photosensitive epilepsy, or impairment of color vision, for example.

Mounting and electrical installation



CAUTION

Risk of injury due to hot device surface.

The surface of the device can become hot.

- Before performing work on the device (e.g. mounting, cleaning, disassembly), switch off the device and allow it to cool down.
 - Ensure good dissipation of excess heat from the device to the surroundings.
-



WARNING

Electrical voltage!

Electrical voltage can cause severe injury or death.

- Work on electrical systems must only be performed by qualified electricians.
 - The power supply must be disconnected when attaching and detaching electrical connections.
 - The product must only be connected to a voltage supply as set out in the requirements in the operating instructions.
 - National and regional regulations must be complied with.
 - Safety requirements relating to work on electrical systems must be complied with.
-



WARNING

Risk of injury and damage caused by potential equalization currents!

Improper grounding can lead to dangerous equipotential bonding currents, which may in turn lead to dangerous voltages on metallic surfaces, such as the housing. Electrical voltage can cause severe injury or death.

- Work on electrical systems must only be performed by qualified electricians.
 - Follow the notes in the operating instructions.
 - Install the grounding for the product and the system in accordance with national and regional regulations.
-

Repairs and modifications



WARNING

Electric shock!

Non-insulated electrical conductors are located in the housing. Electrical voltage can cause severe injury or death.

- Do not open the housing.
 - Protect the housing from damage.
 - If the housing is damaged, disconnect the device from the voltage supply and do not put it into operation.
-

2.2 Intended use

The Lector85x image-based code reader is a SICK 4Dpro sensor. The product is used for automatic, stationary identification and decoding of codes on moving or stationary objects. The product reads 1D codes (barcodes, stacked codes) and 2D codes (matrix codes). In read mode, the product sends the read results via the data interface to a controller for coordinated further processing.

The base model of the product is a camera housing with C-mount thread. The product can be assembled from individual components to suit the particular application. The individual components can be ordered separately as accessories. Only certain lenses and illumination units are compatible depending on the product type. Use only components from SICK intended for this product. Use a compatible variant of the VI83I illumination unit as the integrated illumination.

As a complete device, the product is already equipped with pre-mounted optics (lens, integrated illumination unit, spacer, optics protection hood).

To increase the irradiance in the field of view of the product, an external VI228x illumination unit can also be used. It is recommended to use polarizing filters for applications with high reflection.

The product is designed for use in industrial and logistics areas, and meets the requirements for industrial ruggedness, interfaces and data processing.

The product was developed for use in industrial environments (EN 61000-6-4).

Incorrect use, improper modification, or tampering with the product will invalidate any warranty offered by SICK AG. Furthermore, SICK AG shall not accept any responsibility or liability for any resulting damage and consequential damage.

2.3 Improper use

Impermissible use

- As a safety component as defined in the relevant applicable safety standards for machines, e.g. Machinery Directive

Impermissible ambient conditions

- Explosion-hazardous area
- Corrosive environment

2.4 Cybersecurity

Overview

To protect against cybersecurity threats, it is necessary to continuously monitor and maintain a comprehensive cybersecurity concept. A suitable concept consists of organizational, technical, procedural, electronic, and physical levels of defense and considers suitable measures for different types of risks. The measures implemented in this product can only support protection against cybersecurity threats if the product is used as part of such a concept.

You will find further information at www.sick.com/psirt, e.g.:

- General information on cybersecurity
- Contact option for reporting vulnerabilities
- Information on known vulnerabilities (security advisories)

Further topics

- [Interfaces](#)
- [Network services and ports](#)
- [Password management](#)

2.5 Qualification of personnel

Any work on the product may only be carried out by personnel qualified and authorized to do so.

Qualified personnel are able to perform tasks assigned to them and can independently recognize and avoid any potential hazards. This requires, for example:

- technical training
- experience
- knowledge of the applicable regulations and standards

3 Product description

3.1 Scope of delivery

No. of units	Component	Note
1	Device in the version ordered	<ul style="list-style-type: none"> • Camera housing with C-mount threaded connection • Order individual components separately as accessories and mount them independently. • Light inlet is sealed with a protective cap. • Electrical connections are sealed with protective caps. • Without holders and connecting cables
2	Sliding nut, 5.5 mm deep, M5 threaded mounting hole	<ul style="list-style-type: none"> • Alternative mounting option for the device instead of the threaded mounting hole • Use in pairs.
1	Hexagon key WAF 2	For mounting the VI83I illumination unit
1	Commissioning sample	For determining the camera position and adjusting the focus and aperture
1	Printed safety notes, multilingual	Brief information and general safety notes

The actual scope of delivery may differ for special designs, additional orders or due to the latest technical changes.

3.2 Type label

The type label contains information for identifying the product.



Figure 1: Lector85x type label (example)

- ① Product and type designation
- ② Product characteristics
- ③ Product ID
- ④ Conformity mark and certification mark
- ⑤ Place and date of production
- ⑥ Supply voltage and maximum power consumption
- ⑦ MAC address P1 / P2 (Ethernet)
MAC address P3 (Ethernet)
- ⑧ QR code with a link to the product and more information

3.3 Type code

Type code structure

V2D a b c d - e f g h i j k l m n

Position	Description	Characteristic
a	Product family	8: 8xx series
b	Platform, housing	5: Advanced Line
c	Resolution of the image sensor	05: 5 megapixels (2,464 px x 2,048 px) 09: 9 megapixels (4,096 px x 2,176 px) 12: 12 megapixels (4,096 px x 3,008 px)
d	Function	R: Lector - Reading
e	Generation	1: First generation
f	Image sensor type/color	M: Monochrome
g	Optical/focusing system	C: C-mount
h	Illumination unit	X: Without M: Visible red light medium L: Visible red light wide K: Visible white light medium I: Visible white light wide

Position	Description	Characteristic
i	Focal length	X: Without B: 8 mm C: 12 mm D: 16 mm E: 25 mm
j	Filter	X: Without
k	CPU	A: Advanced
l	Connection modules	L: CAN I/O F: Fieldbus
m	IP protection class and front screen	0: Without 2: IP65 Glas
n	Temperature range	S: 0 °C ... 50 °C (standard)

3.4 Product overview

Product overview



- ① C-mount thread
- ② Lens
- ③ Illumination unit
- ④ Spacer
- ⑤ Optics protection hood not mounted
- ⑥ Optics protection hood mounted
- ⑦ USB (for temporary use as a service interface)
- ⑧ Slot for a microSD memory card (accessory)

Further topics

- [Dimensional drawing](#)

3.5 Integrated illumination unit

Overview




Figure 2: VI83I illumination unit

- ① 32 illumination LEDs
- ② 1 Feedback LED, e.g., for Good Read (not available)
- ③ 1 Feedback LED, e.g., for No Read (not available)
- ④ Laser alignment aid

Feedback LED (not available)


With the default settings, for example, the green feedback LED briefly produces a green feedback spot within the field of view of the product after a successful read.

Laser alignment aid

The laser alignment aid produces a red spot (laser spot) in the field of view of the product. The alignment aid can be switched off.




















3.6 Display and control elements

Overview



- ① Status LEDs

Status LEDs

Display	LED (color)	Description	Information
Ready	 (Green)	Product is switched on and ready for use.	
	 (Red)	Error	
	 (Green)	Product is not ready for operation. Reasons <ul style="list-style-type: none"> Firmware update Parameter change by the user Parameter change by another device (e.g., PLC) 	
	 (Blue)	Product is powering up.	
Result			Not available for the product variant.
Function			Not available for the product variant.
L/A P1 GbE	 ○	No Ethernet connection	
	 (Green)	Connected to network (10/100 Mbit/s)	
	 (Green)	Data transmission over the network (10/100 Mbit/s)	
	 (Blue)	Connected to network (1 Gbit/s)	
		Data transmission over the network (1 Gbit/s)	
L/A P2 GbE	 ○	No Ethernet connection	
	 (Green)	Connected to network (10/100 Mbit/s)	
	 (Green)	Data transmission over the network (10/100 Mbit/s)	
	 (Blue)	Connected to network (1 Gbit/s)	
		Data transmission over the network (1 Gbit/s)	
L/A P3 GbE	 ○	No Ethernet connection	
	 (Green)	Connected to network (10/100 Mbit/s)	
	 (Green)	Data transmission over the network (10/100 Mbit/s)	
	 (Blue)	Connected to network (1 Gbit/s)	
		Data transmission over the network (1 Gbit/s)	

Display	LED (color)	Description	Information
SF/RUN/MS	PROFINET: system failure (SF)		Not available for the product variant.
	○	Not an error	
	☠ (Red)	DCP signal service is triggered via the fieldbus.	
	● (Red)	Watchdog timeout: Channel diagnostics, generic diagnostics, advanced diagnostics, system error	
	EtherNet/IP™: Module status (MS)		Not available for the product variant.
	● (Green)	Product is in operation.	
	☘ (Green)	Standby: Product is not configured.	
	☘ ☠ ☘ (Green, red, green)	Self-test when switching on	
	☠ ☘ ○ (Red, green, off)	Flash sequence for visually identifying the product MS and NS LEDs flash simultaneously.	
	☠ (Red)	Correctable error: e.g. incorrect configuration	
	● (Red)	Error: Device is not operational.	
	○	No supply voltage or no EtherNet/IP™ app installed	
	EtherCAT: Run (RUN)		Not available for the product variant.

Display	LED (color)	Description	Information
BF/ERR/NS	PROFINET: Bus error (BF)		Not available for the product variant.
	○	Not an error	
	⦿ (Red)	No data exchange	
	● (Red)	No configuration or no Ethernet connection, slow physical connection or no physical connection	
	EtherNet/IP™: Network status (NS)		Not available for the product variant.
	● (Green)	IP address is configured. CIP connection is established.	
	⦿ (Green)	IP address is configured but no CIP connection present.	
	⦿ ● ○ (Green, red, off)	Self-test when switching on	
	⦿ ● ○ (Red, green, off)	Flash sequence for visually identifying the product MS and NS LEDs flash simultaneously.	
	⦿ (Red)	Warning: The connection has timed out Reset due to reset or establishment of a new connection	
● (Red)	Error: IP address is already allocated to another product.		
○	No supply voltage, no IP address present, or no Ethernet/IP™ app installed.		
EtherCAT: Error (ERR)		Not available for the product variant.	
L/A P1 FB	○	No Ethernet connection/fieldbus	Not available for the product variant.
	● (Green)	Connected to network (10/100 Mbit/s)	
	● (Yellow)	Data transmission via the network (10/100 Mbit/s)	
L/A P2 FB	○	No Ethernet connection/fieldbus	Not available for the product variant.
	● (Green)	Connected to network (10/100 Mbit/s)	
	● (Yellow)	Data transmission via the network (10/100 Mbit/s)	

○ = off; ● = illuminated; ⦿ = flashing

3.7 Working distance and field of view size




Figure 3: Working distance and field of view size

- ① Min. working distance in mm
- ② Max. working distance in mm
- ③ Min. perceived field of view area: horizontal (mm)
- ④ Min. perceived field of view area: vertical (mm)
- ⑤ Max. perceived field of view area: horizontal (mm)
- ⑥ Max. perceived field of view area: vertical (mm)

The perceived field of view area is determined by the focus position, the focal length of the lens, and the working distance. The necessary working distance can be determined from the field of view diagram.

3.8 Focus setting

The focus position can be adjusted manually on the lens.

The focus position is valid for one working distance. The device does not perform automatic tracking (auto focus) if, for example, the working distance changes significantly.

3.9 Code object assignment

Overview




Figure 4: Code object assignment

Code object assignment

A trigger (e.g. photoelectric sensor) controls the start and end of the reading process. Several objects with codes may be present in the field of view of the product during the reading process. The product reads multiple codes simultaneously. The product uses the code object assignment function to correctly assign the codes it reads to the objects. An object separation of at least 50 mm is necessary for clear differentiation of successive objects.

If the speed of the conveying equipment is variable, an external encoder is required for the code object assignment.

4 Mounting

4.1 Planning for mounting

Installation site

- To prevent condensation, avoid exposing the device to rapid changes in temperature.
- The mounting site is suitable for the weight of the device.
- Mount the device in a shock and vibration insulated manner.
- Make sure the product has a clear view of the codes of the objects to be scanned.

Heat regulation

- If the ambient operating temperature will be $\geq 45\text{ }^{\circ}\text{C}$, ensure adequate heat dissipation when mounting the device. For example, mount the product using a mounting bracket on a suitable heat sink. A suitable heat sink is an aluminum profile with minimum dimensions 40 mm x 80 mm x 665 mm. To ensure air circulation, mount the product, for example, at an adequate distance from walls, ceilings and other devices.

Strong light sources, lasers and retro-reflectors

- In order to avoid reflections from the surfaces to be scanned, mount the product so that it is tilted from the perpendicular to the surface. An angle of 0° up to 45° is appropriate depending on the application.





Figure 5: Mounting angle to use, depending on the application

- ① Typical angle 10° ... 20°

4.2 Mounting the lens and illumination unit

Overview

This mounting step is only required for the product type V2D85xxx-xxCxxxxxxx.



- ① Spacer, left with electrical connection
- ② 4 long screws: M2.5; length: 12 mm (ISO 4762, hexagon socket head screw)
- ③ 4 tapped blind holes, M2.5; depth: 5.5 mm, for mounting the spacer
- ④ Electrical connection for the integrated illumination unit
- ⑤ 4 short screws: M2.5; length: 6 mm (ISO 4762, hexagon socket head screw)
- ⑥ Integrated illumination unit
- ⑦ Spacer, right
- ⑧ Light inlet with threaded connection for the lens
- ⑨ C-mount thread

Important information



NOTICE

Risk of damage due to electrostatic discharge

Electrostatic discharge from the human body may damage parts of the illumination unit or the camera housing.

- Take the necessary ESD precautions when assembling the device.
- Do not touch the open contacts of the electrical connection on the camera housing and the illumination unit.



NOTE

Possible impairment of image quality

Contamination (e.g. dust, fingerprints) on the image sensor can impair the image quality and decoding performance of the product.

- ▶ Ensure a dust-free and dry environment when mounting components.
- ▶ Do not touch the image sensor in the light inlet opening of the product with your fingers.
- ▶ Do not touch the glass lenses at either end of the lens unit with your fingers.

Prerequisites

- There is a risk of burns at ambient temperatures above 32 °C. If the ambient temperature is above 32 °C, remove the optics protection hood and perform the fine adjustments on the mounted lens within 20 minutes of switching on the cooled down device.
- Lens and illumination unit are compatible with the product. You can find compatible accessories on the product page on the Internet.
- SW 2 hex key (included with delivery)
- SW 5 socket wrench, recommendation: as a torque wrench for 65 Ncm

Approach

1. Switch off the supply voltage to the device.
2. Peel off the white protective sticker on the camera housing that covers the electrical connection for the illumination unit.
3. Place the camera housing on a nonslip base.
4. Remove the protective cap from the round light inlet.
5. Screw the lens unit into the C-mount thread until it engages.
6. Take 2 pairs of long screws and screw them into the tapped blind holes to mount each spacer on the camera housing.
7. Use the 4 short screws to fasten the illumination unit to the two spacers.
8. In systems subjected to heavy vibrations, secure the C-mount threaded connection of the lens using threadlocking adhesive.
9. Manually preset the sharpness and aperture of the lens unit.
10. Check the adjustment using SOPASair.
11. If the required adjustments to the lens are not carried out immediately, mount the optics protection hood for the lens.

4.3 Mounting the external illumination

Overview




Figure 6: Mounting the external illumination




Figure 7: Product and external illumination assembled

Prerequisites

- The camera is not mounted on the mounting bracket.
- Connecting cables have been removed.

Procedure

1. Mount the external illumination on the mounting bracket using three M5 screws (tightening torque: 5 Nm ± 0.5 Nm).
2. Mount the device on the mounting bracket using four M5 knurled screws. Tighten the knurled screws by hand without tools.

4.4 Assembling the product

Approach

1. Mount the product on suitably prepared mounting equipment using M5 screws and by means of the threaded mounting holes or sliding nuts. Mounting equipment is available as an accessory.
 - Screw the screws no more than 5 mm into the threaded mounting holes or sliding nuts.
 - To do so, either use all 4 threaded mounting holes on the rear of the product or the two sliding nuts on the side of the product.
 - Attach the optional SICK mounting equipment ordered separately using the sliding nuts on the product.
2. In application areas with severe vibrations or shocks caused by vibrations, jolts or abrupt changes in directions (e.g., when mounted to a manned forklift truck), mount the product with vibration dampers. Mount the product in a freely suspended manner.
3. Align the product taking into consideration the field of view and the application circumstances.
4. Connect the product to interfaces and supply voltage when disconnected from voltage.
5. Start the product.
- ✓ The **Ready** status LED lights up green.
6. Perform fine tuning.

5 Electrical installation

5.1 Prerequisites for safe operation of the device

Important information



WARNING

Risk of injury and damage caused by electrical current!

As a result of equipotential bonding currents between the device and other grounded devices in the system, faulty grounding of the device can give rise to the following dangers and faults:

- Dangerous voltages are applied to the metal housings.
- Devices will behave incorrectly or be destroyed.
- Cable shielding will be damaged by overheating and cause cable fires.

Remedial measures

- Only skilled electricians should be permitted to carry out work on the electrical system.
 - If the cable insulation is damaged, disconnect the voltage supply immediately and have the damage repaired.
 - Ensure that the ground potential is the same at all grounding points.
 - Where local conditions do not meet the requirements for a safe earthing method, take appropriate measures. For example, ensure low-impedance and current-carrying equipotential bonding.
-

Prerequisites for safe operation of the device

The device is connected to the peripheral devices (any local trigger sensor(s), system controller) via shielded cables. The cable shield – for the data cable, for example – rests against the metal housing of the device.

The device can be grounded through the cable shield or through a blind tapped hole in the housing, for example.

If the peripheral devices have metal housings and the cable shields are also in contact with their housings, it is assumed that all devices involved in the installation have the **same ground potential**.

This is achieved by complying with the following conditions:

- Mounting the devices on conductive metal surfaces.
- Correctly grounding the devices and metal surfaces in the system.
- If necessary: low-impedance and current-carrying equipotential bonding between areas with different ground potentials




Figure 8: Example: Occurrence of equipotential bonding currents in the system configuration

- ① System controller
- ② Device
- ③ Voltage supply
- ④ Grounding point 2
- ⑤ Closed current loop with equalizing currents via cable shield
- ⑥ Ground potential difference
- ⑦ Grounding point 1
- ⑧ Metal housing
- ⑨ Shielded electrical cable

If these conditions are not fulfilled, equipotential bonding currents can flow along the cable shielding between the devices due to differing ground potentials and cause the hazards specified. This is, for example, possible in cases where there are devices within a widely distributed system covering several buildings.

Remedial measures

The most common solution to prevent equipotential bonding currents on cable shields is to ensure low-impedance and current-carrying equipotential bonding. If this equipotential bonding is not possible, the following solution approaches serve as a suggestion.



NOTICE

We expressly advise against opening up the cable shields. This would mean that the EMC limit values can no longer be complied with and that the safe operation of the device data interfaces can no longer be guaranteed.

Measures for widely distributed system installations

On widely distributed system installations with correspondingly large potential differences, the setting up of local islands and connecting them using commercially available **electro-optical signal isolators** is recommended. This measure achieves a high degree of resistance to electromagnetic interference.




Figure 9: Example: Prevention of equipotential bonding currents in the system configuration by the use of electro-optical signal isolators

- ① System controller
- ② Electro-optical signal isolator
- ③ Device
- ④ Voltage supply
- ⑤ Grounding point 2
- ⑥ Grounding point 1
- ⑦ Metal housing
- ⑧ Shielded electrical cable
- ⑨ Optical fiber

The use of electro-optical signal isolators between the islands isolates the ground loop. Within the islands, a stable equipotential bonding prevents equalizing currents on the cable shields.

Measures for small system installations

For smaller installations with only slight potential differences, insulated mounting of the device and peripheral devices may be an adequate solution.




Figure 10: Example: Prevention of equipotential bonding currents in the system configuration by the insulated mounting of the device

- ① System controller
- ② Device
- ③ Voltage supply
- ④ Grounding point 3
- ⑤ Insulated mounting
- ⑥ Grounding point 2
- ⑦ Ground potential difference
- ⑧ Grounding point 1
- ⑨ Metal housing
- ⑩ Shielded electrical cable

Even in the event of large differences in the ground potential, ground loops are effectively prevented. As a result, equalizing currents can no longer flow via the cable shields and metal housing.




NOTICE

The voltage supply for the device and the connected peripheral devices must also guarantee the required level of insulation.

Under certain circumstances, a tangible potential can develop between the insulated metal housings and the local ground potential.

5.2 Pin assignment

Overview



- ① P1: Gigabit Ethernet 1
- ② P2: Gigabit Ethernet 2
- ③ P3: Gigabit Ethernet 3
- ④ X2: Power/CAN
- ⑤ X1: Power/CAN/serial interface/IO

Prerequisites

General

- Connect the connecting cables in a de-energized state. Do not switch on the supply voltage until installation is complete and all connecting cables are connected to the device and control.
- Wire cross-sections in the supply cable from the user's power system must be implemented in accordance with the applicable standards.
- In the case of open end cables, make sure that bare wire ends do not touch. Wires must be properly insulated from each other.
- The maximum current consumption depends on how the product is used. If outputs are used, the current consumption will be higher. Ensure that the sum of the output currents at the outputs does not exceed 400 mA.

Data cables

- Use shielded data cables with twisted-pair wires.
- Implement proper and complete shielding concept.
- To avoid interference, always use EMC-compliant cables and layouts. This applies, for example, to cables for switched-mode power supplies, motors, clocked drives, and contactors.
- Do not lay cables over long distances in parallel with voltage supply cables and motor cables in cable ducts.

Voltage supply

- Configure the circuits connected to the device as ES1 circuits or as SELV circuits (SELV = Safety Extra Low Voltage). The voltage source meets the requirements of ES1 (EN 62368-1) or SELV (EN 60950-1).
- The device must be supplied with an energy-limited source as per UL61010-1, 3rd ed. cl. 9.4 or a limited current source as per UL62368-1 or Class 2 as per NEC.
- Required power output of the voltage source: at least 48 W
- For a supply voltage of DC 24 V \pm 20%, protect the cables with a separate fuse. The required fuse depends on the cable used. Typical examples: 2 A fuse for 17-pin M12 cable, or 4 A fuse for 5-pin M12 cable. Install the fuse in the supply circuit at the start of the supply cable.
- To ensure protection against short-circuits/overload in the customer's supply cables, choose and implement wire cross-sections in accordance with the applicable standards.

Power/CAN/serial interface/IO




Figure 11: M12 male connector, 17-pin, A-coded

Contact	Signal	Description	Information
1	GND	Supply voltage: 0 V	
2	V _s	Supply voltage: DC 24 V ± 20%	
3	CAN L	CAN-Bus LOW (IN/OUT)	
4	CAN H	CAN-Bus HIGH (IN/OUT)	
5	TD+ (RS-422)	Serial data interface (Sender+)	
6	TD- (RS-422) TxD (RS-232)	Serial data interface (Sender-)	
7	TxD (RS-232)	Serial service interface (Sender)	Do not connect.
8	RxD (RS-232)	Serial service interface (Receiver)	Do not connect.
9	SensGND	Digital input ground	
10	Sensor 1	Digital input 1	
11	RD+ (RS-422)	Serial data interface (Receiver+)	
12	RD- (RS-422) RxD (RS-232)	Serial data interface (Receiver-)	
13	DIO 3	Configurable digital input and output 3	Do not connect.
14	DIO 4	Configurable digital input and output 4	
15	Sensor 2	Digital input 2	
16	DIO 5	Configurable digital input and output 5	
17	DIO 6	Configurable digital input and output 6	

Power/CAN




Figure 12: M12 male connector, 5-pin, A-coded

Contact	Signal	Description
1	-	Shielding
2	V _s	Supply voltage
3	GND	Supply voltage: 0 V
4	CAN H	CAN-Bus HIGH (IN/OUT)
5	CAN L	CAN-Bus LOW (IN/OUT)

Gigabit Ethernet




Figure 13: Female connector, M12, 8-pin, X-coded

Table 1: Pin assignment for Gigabit Ethernet

Contact	Signal	Description
1	TRD0_P	Sender+/receiver+ 0
2	TRD0_N	Sender-/receiver- 0
3	TRD1_P	Sender+/Receiver+ 1
4	TRD1_N	Sender-/Receiver- 1
5	TRD3_P	Sender+/Receiver+ 3
6	TRD3_N	Sender-/Receiver- 3
7	TRD2_N	Sender-/Receiver- 2
8	TRD2_P	Sender+/Receiver+ 2

Complementary information

Pre-assembled cables can be found on the product page.

The call is made via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Further topics

- Information on interfaces: [Technical data](#)

5.3 Pin assignment for external illumination

Prerequisites

General

- Connect the connecting cables in a de-energized state. Do not switch on the supply voltage until installation is complete and all connecting cables are connected to the device and control.

Data cables

- Use shielded data cables with twisted-pair wires.
- Implement proper and complete shielding concept.
- Length of cable for trigger signal: max. 20 m

Voltage supply

- Configure the circuits connected to the device as ES1 circuits or as SELV circuits (SELV = Safety Extra Low Voltage). The voltage source meets the requirements of ES1 (EN 62368-1) or SELV (EN 60950-1).

I1 TRIG: Synchronization




Figure 14: M12 male connector, 5-pin, A-coded

Contact	Signal	Description
1	-	-
2	Sensor 1	Digital input for external trigger
3	GND	Supply voltage: 0 V
4	-	-
5	-	-

I2 PWR / TRIG: Power / Synchronization




Figure 15: M12 male connector, 5-pin, A-coded

Contact	Signal	Description
1	-	-
2	Vs	Supply voltage
3	GND	Supply voltage: 0 V
4	Sensor 1	Digital input for external trigger
5	-	-

Complementary information

Pre-assembled cables can be found on the product page.

The call is made via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Further topics

- Information on external illumination: [Data sheet for external illumination](#)

5.4 Network services and ports

Available network services and ports can be viewed in SOPASair under Diagnostics > Cybersecurity.

5.5 CAN interface

Configuration of the CAN interface

Configure the CAN data interface using SOPASair.

Series connection

The devices communicate with each other and are supplied with voltage via the CAN interface. A maximum of 3 devices can be connected in series (line topology). The devices are connected via a Y-cable.

For a CAN network with more than 3 devices, a separate voltage supply must be used for every 3 devices. Communication between all devices in the network is done via CAN.

Complementary information

Information on using the device in conjunction with a modular system controller or a Sensor Integration Machine can be found in the associated publications. The publications can be found at sick.com/{part number}.

Publications

- MSC800 Modular System Controller operating instructions, part number 8011539
- SIM2000ST Sensor Integration Machine operating instructions, part number 8020763
- SIM2000ST-E Sensor Integration Machine operating instructions, part number 8025453

5.6 CAN connection principle

Connection to 3 devices




Figure 16: Connection principle for CAN with track and trace controller, 3 devices

- ① Software for Integration Package Analytics, image output
- ② Control cabinet
- ③ Switch
- ④ Track and trace controller (e.g., MSC800, SIM2000)
- ⑤ Fuse box
- ⑥ 26 V supply voltage
- ⑦ CAN connection A
- ⑧ Gbit P1 and P2 Ethernet: image output, parameterization
- ⑨ CAN: power, increment, trigger, focus, code
- ⑩ CAN male connector with terminating resistor

Connection to 6 devices




Figure 17: Connection principle for CAN with track and trace controller, 6 products

- ① Software for Integration Package Analytics, image output
- ② Control cabinet
- ③ Switch
- ④ Track and trace controller (e.g., MSC800, SIM2000)
- ⑤ Fuse box
- ⑥ 26 V supply voltage
- ⑦ CAN connection A
- ⑧ CAN connection B
- ⑨ Gbit P1 and P2 Ethernet: image output, parameterization
- ⑩ CAN: power, increment, trigger, focus, code
- ⑪ CAN male connector with terminating resistor

5.7 Connection principle for external illumination

Connection with track and trace controller




Figure 18: Connection of external illumination with track and trace controller

- ① External illumination
- ② Device
- ③ Synchronization between the device and external illumination
- ④ Supply voltage for the device, protected with a 4 A fuse (typ. in the control cabinet)
SICK CAN sensor network
- ⑤ Control cabinet with track and trace controller (e.g. MSC800, SIM2000)
- ⑥ Supply voltage for the control cabinet
- ⑦ Supply voltage for the external illumination, protected by a 4A fuse (typ. in the control cabinet)

Connection using a connection module




Figure 19: Connection of the external illumination using a connection module

- ① External illumination
- ② Device
- ③ Supply voltage and trigger for the device
- ④ Connection module (e.g. CDM, CDB)
- ⑤ Supply voltage for the 24 V connection module, 4 A fuse additionally required
- ⑥ Supply voltage for the external illumination, synchronization between the device and external illumination

5.8 Connection modules

Prerequisites

- Compatible connection module, to be ordered separately as an accessory.
- Only use the CDM connection module with integrated 40 W power supply with the product type V2D85xxx-xxCxxxxxxx. Note the additional current consumption in the connection module of max. 200 mA incl. output currents of the device.

Connection modules

Connection modules can be added as accessories in SOPASair when configuring the device. The wiring of the connection modules is described during configuration in SOPASair.

6 Commissioning

6.1 Starting SOPASair

Overview

SOPASair is used for operation, parameterization, and servicing purposes (e.g., diagnostics, data logger).

Prerequisites

- Device is connected to the computer via Ethernet (P1, P2 or P3) or USB.
- Voltage supply is connected.
- Computer and device are located on the same network.
- Computer and device have different IP addresses.
- Access data

Rights	Password
Read	Can be accessed without a password
Read and write	Default password: servicelevel

Approach

1. Open web browser (recommendation: Google Chrome).
2. Enter the device IP address into the address line.

Default IP addresses:

 - P1 and P2: 192.168.1.1
 - P3: 192.168.0.1
 - USB: 169.254.0.1
- ✓ The user interface is displayed.
3. To make changes, log in to the device.

6.2 Password management

6.2.1 Password assignment


Overview

Reading the parameter settings is possible without a password. A password can be assigned to protect the product against unauthorized changes to the settings.

Prerequisites


- When assigning a password for the first time, ensure the connection is secure, e.g. by using a point-to-point connection to the device.

Procedure

1. Establish a connection to the product in the web browser.
2.  Select:
3. Log in with the default password **servicelevel**.
- ✓ You will be prompted to assign a new password.
4. Assign a new password.
- ✓ The new password is valid immediately.
5. Log in again with the newly assigned password.



6.2.2 Changing password

Procedure

1. Establish a connection to the product in the web browser.
2.  Select:
3. Log in with the last assigned password.
4. Select **Change password**.
5. Assign a new password.
- ✓ The new password is valid immediately.

6.2.3 Resetting the password

Procedure

1. Establish a connection to the product in the web browser.
2.  Select:
3. Select **Password forgotten?**.
4. Send **Device key**, **Serial number** and **Part number** in an e-mail to the responsible SICK sales company or the responsible SICK service partner, see www.sick.com/worldwide.
5. Click **Next** to confirm.
- ✓ The window for entering a code appears.
You can get the code from the responsible SICK sales company or the responsible SICK service partner. The code is only valid once for the reset process. You can close the window by clicking on the x without interrupting the reset process. If you select **Cancel** or enter an incorrect code several times, the current reset process is terminated. The requested code is no longer valid. The process must be restarted.
6. Optional: close the window by clicking on x. At a later time, open the window for entering the code via  and **Password forgotten?**.
7. Enter the code.
8. Click **Reset** to confirm.
- ✓ The password is reset to the default password **servicelevel**. Parameters are not changed.

6.3 Starting SOPAS ET

Overview


The saved parameters can be manually saved, imported, and exported as a project file on the computer in the SOPAS ET configuration software.

Prerequisites

- Device is connected to the computer via Ethernet (P1, P2 or P3) or USB.
- Voltage supply is connected.
- Computer and device are located on the same network.
- Computer and device have different IP addresses.
- Computer with the SOPAS ET software installed
The most up-to-date version of the SOPAS ET software can be downloaded from www.sick.com/SOPAS_ET. The respective system requirements for installing SOPAS ET are also specified there.
- SDD file (device description file)
You can install the SDD file using the device catalog in SOPAS ET. Use the wizard in SOPAS ET to do this. The SDD file can be installed from the device or the SICK website. To install it from the SICK website, you need an Internet connection.
- Access data

User levels	Password
Maintenance personnel	Main
Authorized client	Client
Service	Service level

Approach

1. Install the latest version of the SOPAS ET configuration software. In this case, select the “Complete” option as suggested by the installation wizard. Administrator rights may be required on the computer to perform the installation.
2. Start “SOPAS ET” after completing the installation.
- ✓ SOPAS ET automatically starts the search for connected devices. Connected devices are displayed in the **Device Search** window.
3. Select the desired device in the list of available devices.
Default IP addresses:
 - P1 and P2: 192.168.1.1
 - P3: 192.168.0.1
 - Subnet mask: 255.255.255.0
 If necessary, install an updated device description file for the device.
4. Click on  **Add** to establish communication.
- ✓ SOPAS ET establishes communication with the device, loads its current device description (parameters), and displays the device in the **New Project** window.
5. Log into the device.

6.4 External data back-up

Manual data backup using project file

The parameter set can be manually saved on the computer as a project file (*.sopas). This is the generally recommended procedure. Using the project file, the parameter set can be transferred to a replacement device via download.

Automatic data backup

An additional storage medium is required to automatically save the parameter set to an external location. The device is permanently connected to the external storage medium. The externally stored parameter set is also updated automatically each time the parameterization is permanently saved.

External storage medium

- MicroSD memory card (cloning function)

Once it is switched on, the device automatically detects an external storage medium. The subsequent device behavior depends on the content of the storage medium. The goal is for the internal parameter set and the parameter set saved externally to always be identical.

Content of the storage medium	Device behavior
Empty	Once the parameter set is permanently saved, the device also saves the internal parameter set on the storage medium. The prerequisite is that there is enough storage space.
No parameter set possible to interpret	
Parameter set possible to interpret	After being switched on, the device automatically loads the compatible parameter set from the external storage medium into the working memory and internal, permanent parameter memory. The device then starts with its new valid parameter set.

6.5 Inserting and removing memory card

Important information



NOTICE

Loss of configuration data

Do not remove the memory card or switch off the supply voltage while the parameter set is being saved. Otherwise all parameters not yet saved permanently will be lost.

Prerequisites

- The supply voltage for the product is switched off.
- To remove the memory card during operation, select the **Remove SD card** option under **Analysis/SD card** in SOPAS ET.
- If the cover is open, the product does not fulfill any specified enclosure rating. Only briefly open the cover. Protect the product against moisture and dust during this time.

Approach

Inserting the memory card

1. Open the rubber cover.
2. Making sure it is in the correct position, insert the memory card into the slot until it locks into place. To do so, align the product as per the card icon.
3. Close the cover again. Make sure that the cover is completely flush with the product when closed.
4. Switch on the supply voltage for the product.

Removing memory card


1. Push the memory card into the slot until it is released.
2. Remove the memory card.
3. Close the cover again. Make sure that the cover is completely flush with the product when closed.
4. Switch on the supply voltage for the product.

6.6 Saving the parameter set

Overview

The device is configured for the application using SOPASair. The parameter set can be permanently saved in SOPASair. To be able to restore the parameter set to a replacement device, for example in the event of a device failure, you should also save the parameter set externally.

Approach

1. Permanently saving the parameters in SOPASair:
 - ✓  The device stores the parameter set internally in the permanent parameter memory.
 - ✓ If a memory card is installed in the device, the device also saves the parameter set externally on the memory card.
2. Open SOPAS ET.
3. In SOPAS ET, manually save the parameter set as a project file on the computer.
 - ✓ The parameter set is also saved externally. The parameter set in the project file can be transferred to a replacement device via download.

6.7 Installing firmware updates

Prerequisites

- Computer with the SICK AppManager software installed
The current version of SICK AppManager can be downloaded from www.sick.com/SICK_AppManager. To install SICK AppManager, open the installation file (*.exe) and follow the instructions on the screen.
- Ethernet port P1, P2 or P3

Procedure

1. Open SICK AppManager.
 2. Drag and drop the file into the **Firmware** window.
 3. In the **Firmware** window, select the file to be installed.
 4. In the bottom right window, click the **Install** button.
- ✓ The firmware update is installed.

7 Maintenance

7.1 Maintenance

Table 2: Maintenance schedule

Maintenance work	Interval
Check device and connecting cables for damage at regular intervals.	Depends on ambient conditions and climate.
Check the housing and viewing window for contamination and clean if necessary.	Depends on ambient conditions and climate.
Check the screw connections and plug connections.	Depends on the place of use, ambient conditions or operating requirements. Recommended: At least every 6 months.
Check that all unused connections are sealed with protective caps.	Depends on ambient conditions and climate. Recommended: At least every 6 months.

7.2 Cleaning the product

Important information



NOTICE

- ▶ Never use sharp objects for cleaning.
- ▶ Recommendation: Use anti-static cleaning agents.
- ▶ Recommendation: Use anti-static plastic cleaners and lens cloths from SICK.



NOTICE

If the viewing window is scratched or damaged, take the product out of operation and have it repaired by SICK.

Approach

1. If possible, switch off the voltage supply to the product. If this is not possible, wear suitable laser safety goggles. These must effectively absorb the radiation of the wavelength used by the product.
2. Clean the viewing window according to the material:
 - Glass window: remove dust from the viewing window using a soft, clean brush. If necessary, also clean the viewing window with a clean, damp, lint-free cloth, and a mild anti-static lens cleaning fluid.
 - Plastic window: clean the viewing window only with a clean, damp, lint-free cloth, and a mild anti-static lens cleaning fluid.
3. Remove any dust from the housing using a soft brush.

8 Troubleshooting

8.1 Troubleshooting

Faults, warnings and errors

Situation	Error or fault
Mounting	<ul style="list-style-type: none"> ■ Device poorly aligned to objects with codes (e.g. glare) ■ Trigger sensor for reading cycle incorrectly positioned (e.g. internal reading interval is opened too late or closed too early) ■ Incremental encoder (optional) incorrectly positioned
Electrical installation	<ul style="list-style-type: none"> ■ Interfaces of the device incorrectly wired
Configuration	<ul style="list-style-type: none"> ■ Functions not adapted to local conditions, e.g., parameters for the data interface not set correctly ■ Device limits not observed, e.g., working range, aperture angle ■ Trigger source for read cycle not selected correctly
Operation	<ul style="list-style-type: none"> ■ Start/stop operation: external read cycle missing, more than one object is in the reading field ■ Device faults (hardware, software)

Diagnostics using SOPASair

The error log contains current error messages.

You can create and download a diagnostic file in the configuration software for service purposes. The diagnostic file contains data required for fault analysis.

Complementary information

For faults that cannot be rectified based on the error description, please contact SICK Service. To help us to resolve the matter quickly, please note down the details on the type label.

8.2 Repair

Repairs on the device may only be performed by qualified and authorized personnel from SICK AG. Interference with or modifications to the device on the part of the customer will invalidate any warranty claims against SICK AG.

8.3 Removing the product

Approach

1. Switch off the supply voltage.
2. Mark the position and alignment of the device on the bracket or surroundings.
3. Disconnect and remove the connecting cables of the device.
4. Remove the device from the bracket.

Complementary information

If you replace the product, you can transfer the parameter values to the replacement product by downloading them. If only the camera housing and not the lens is replaced, readjust the focus position on the lens.

9 Decommissioning

9.1 Disposal of the product

Procedure

- ▶ Always dispose of unusable products in accordance with national waste disposal regulations.



Complementary information

SICK will be glad to help you dispose of these products on request.

10 Technical data



NOTE

The relevant online product page for your product, including technical data, dimensional drawing, and connection diagrams, can be downloaded, saved, and printed from the Internet.

The product page can be accessed via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}** {P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

Please note: This documentation may contain further technical data.

10.1 Features

Typical application	indoor area
Variant	Base device Complete device
Optical focus	Adjustable focus Manual sharpness and aperture setting on optional lens
Sensor	CMOS matrix sensor, grayscale values
Sensor resolution	V2D8505x-xxxxxxx: 5 megapixel (2,464 px x 2,048 px) V2D8509x-xxxxxxx: 9 megapixel (4,096 px x 2,176 px) V2D8512x-xxxxxxx: 12 megapixel (4,096 px x 3,008 px)
Integrated illumination unit	Order separately as an accessory, e.g. variant of the VI83I illumination unit Variants of the VI83I illumination with 32 LEDs: <ul style="list-style-type: none"> • Visible white light medium, aperture angle: 31° • Visible white light wide, aperture angle: 47° • Visible red light medium, peak wavelength: $\lambda = 660 \text{ nm} \pm 20 \text{ nm}$, aperture angle: 31° • Visible red light wide, peak wavelength: $\lambda = 660 \text{ nm} \pm 20 \text{ nm}$, aperture angle: 47°
Feedback LED	Not available due to the variant of the VI83I illumination unit
LED risk group of the illumination unit (visible white light variant + feedback LED)	Risk group 1 (low risk) according to IEC 62471-1: 2006-07 / EN 62471-1: 2008-09 Radiance: <ul style="list-style-type: none"> • $L_B^{1): < 10 \times 10^3 \text{ W}/(\text{m}^2\text{sr})$ within 100 seconds; at a distance $\geq 200 \text{ mm}$ • $L_R^{2): < 2.5 \times 10^6 \text{ W}/(\text{m}^2\text{sr})$ within 10 seconds; at a distance $\geq 200 \text{ mm}$ Risk RG 0 (no risk group) corresponding to $L_B < 100 \text{ W}/(\text{m}^2\text{sr})$ within 10×10^3 seconds for distances $> 0.8 \text{ m}$.
LED risk group of the illumination unit (visible red light variant + feedback LED)	Risk group 1 (low risk) according to IEC 62471-1: 2006-07 / EN 62471-1: 2008-09 Radiance: <ul style="list-style-type: none"> • $L_B^{1): < 10 \times 10^3 \text{ W}/(\text{m}^2\text{sr})$ within 100 seconds; at a distance $\geq 200 \text{ mm}$ • $L_R^{2): < 2.5 \times 10^6 \text{ W}/(\text{m}^2\text{sr})$ within 10 seconds; at a distance $\geq 200 \text{ mm}$ Risk RG 0 (no risk group) corresponding to $L_B < 100 \text{ W}/(\text{m}^2\text{sr})$ within 10×10^3 seconds for distances $> 0.3 \text{ m}$.
Laser alignment aid ³⁾	1 laser, can be switched off Visible red light ($\lambda = 630 \text{ nm} \dots 680 \text{ nm}$)

Laser class of the alignment aid	Class 1 Laser Product according to IEC 60825-1: 2014 and EN 60825-1:2014+A11:2021. Complies with 21 CFR 1040.10/11 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56 dated 8 May 2019. P < 0.39 mW
Scanning frequency	30 Hz, at 5 megapixels resolution 20 Hz, at 9 megapixels resolution 15 Hz, at 12 megapixels resolution
Code resolution	≥ 0.1 mm (depending on the lens)
Working distance	500 mm ... 3,000 mm
Lens	C-mount
Sensor format	V2D8505x-xxxxxxx: 1/1.8" V2D8509x-xxxxxxx: 1/1.2" V2D8512x-xxxxxxx: 1/1.1"

- 1) L_B= Hazard from blue light.
- 2) L_R= Hazard to the retina of the eye due to heating.
- 3) Not available.

10.2 Mechanics and electronics

Connection type	<ul style="list-style-type: none"> • 1 M12 male connector, 17-pin, A-coded (Power, CAN, serial interface, I/O) ¹⁾ • 1 M12 male connector, 5-pin, A-coded (Power, CAN) • 3 M12 female connectors, 8-pin, X-coded (Gigabit Ethernet)
Supply voltage Vs	DC 24 V ± 20% Voltage source in accordance with ES1 (EN62368-1) or SELV (EN60950-1)
Power consumption	Operation: Typically 24 W ²⁾
Current consumption	Max. 2.0 A
Output current	<ul style="list-style-type: none"> • Output current per output: max. 200 mA • Sum of output currents: max. permissible 400 mA
Housing material	Aluminum die cast
Housing color	Anthracite gray (RAL 7016)
Viewing window material	Glass, 2 mm thick, scratch-proof coating
Cover (top of device)	<p>Material: Plastic</p> <p>Function</p> <ul style="list-style-type: none"> • Insert or remove optional memory card • Temporary use of the USB interface as a service interface <p>Function: For temporary access to the microSD memory card slot and the USB connection</p> <p>Foldable ³⁾</p>
Enclosure rating	IP 65 (IEC 60529:2013 +C1:2013 +C2:2015 +AMD2 C1:2019, EN 60529:1991 +A1:2010 +A2:2013 +AC:2019-02) ⁴⁾
Electrical safety	EN 61010-1:2010 EN 61010-1:2010/A1:2019 EN 61010-1:2010/A1:2019/AC:2019-04
Regulatory notes	NFPA79 applications only. Adapters including connecting cables are available.
Weight	Max. 640 g, without lens and connecting cables

Dimensions (L x W x H)	143.4 mm x 90 mm x 46 mm ⁵⁾
MTBF	100,000 h ⁶⁾

- 1) Maximum length of cable: 10 m
- 2) The typical power consumption depends on the product configuration. The specified value applies to digital outputs without load.
- 3) When the cover is open, the device no longer conforms with the specified protection class. Protect the device against moisture and dust when the cover is open temporarily.
- 4) Prerequisites:
 - The optics protection hood must be screwed tightly onto the device.
 - The cover on the top of the device is closed.
 - The cables plugged into the electrical connections must be screwed tight. Unused electrical connections are sealed off with a protective cap.
- 5) Housing only, without lens and optics protection hood.
- 6) At 25 °C ambient operating temperature.

10.3 Dimensional drawing

Base device




Figure 20: Structure and device dimensions, unit: mm (inch), decimal separator: period

- ① 4 tapped blind holes, M2.5, 5.5 mm deep, for mounting the spacer
- ② 2 M5 sliding nuts; 5.5 mm deep; pivoting; as an alternative method of mounting the device
- ③ 4 M5 tapped blind holes, 5.5 mm deep; for mounting the device

Complete device

Product type: V2D8505x-xxxxxxxxx




Figure 21: Structure and device dimensions, unit: mm (inch), decimal separator: period

- ① 2 M5 sliding nuts; 5.5 mm deep; pivoting; as an alternative method of mounting the device
- ② 4 M5 tapped blind holes, 5.5 mm deep; for mounting the device

Complete device

Product type: V2D8509x-xxxxxxxxx, V2D8512x-xxxxxxxxx




Figure 22: Structure and device dimensions, unit: mm (inch), decimal separator: period

- ① 2 M5 sliding nuts; 5.5 mm deep; pivoting; as an alternative method of mounting the device
- ② 4 M5 tapped blind holes, 5.5 mm deep; for mounting the device

10.4 Performance

Readable code structures	1D codes, Stacked, 2D codes
1D code types (bar code types)	GS1-128 / EAN 128, UPC/GTIN/EAN, 2/5 Interleaved, Code 39, Code 128, Codabar, Code 93
2D code types	Data-Matrix ECC200, MaxiCode, QR code

Stacked code types	PDF417
Code qualification	On the basis of ISO/IEC 16022, ISO/IEC 15415, ISO/IEC 18004
Internal image memory	Not available

10.5 Interfaces

Communication interfaces	<ul style="list-style-type: none"> • Gigabit Ethernet: P1/P2 • Ethernet P3 • Ethernet via USB (RNDIS) ¹⁾ • CAN 1 (male connector, M12, 17-pin, A-coded) • CAN 2 (male connector, M12, 5-pin, A-coded) • Serial data interface • Serial service interface
Ethernet	Protocol: TCP/IP Function: Data interface (read result output), service interface, FTP (image transfer) Data transmission rate: 10/100/1,000 Mbit/s MAC address P1 / P2 / P3, see type label
Serial	RS-232, RS-422 Data transmission rate: 1.2 kBaud ... 115.2 kBaud
Digital inputs	2 ("Sensor 1", "Sensor 2"), isolated Function: Encoder input, external trigger
Configurable digital inputs and digital outputs	X1: 4 (DIO 3 ²⁾ , DIO 4, DIO 5, DIO 6)
CAN	Protocol: SICK CAN sensor network CSN (CAN Device) Function: Data interface (read result output), trigger interface Data transmission rate: 500 kbit/s
USB	USB 2.0 Function: Service interface, Ethernet via USB (RNDIS) ^{1) 3)}
Reading pulse	Digital inputs, CAN, PROFINET via trigger bit, EtherNet/IP™ via trigger bit
Optical displays	10 status LEDs
Operator interfaces	Web server
Configuration software (parameterization)	SOPASair (web interface)
microSD memory card ⁴⁾	Function: Cloning (external storage medium)
Data storage and retrieval	Image and data storage via external FTP
External illumination control	Via digital output (max. 24 V trigger)
Encoder Frequency	Max. 50 kHz

Encoder resolution	0.2 mm/pulse ... 10 mm/pulse
---------------------------	------------------------------

- 1) For temporary use as a service interface only.
- 2) Not available.
- 3) If the cover is open, the device does not fulfill any specified enclosure rating. Only briefly open the cover. Protect the device against moisture and dust during this time.
- 4) Memory card is available as an optional accessory. To ensure that the memory card functions reliably, only use card types (industrial standard) approved by SICK. Other functions are available upon request.

10.6 Ambient data

Electromagnetic compatibility (EMC)	Immunity: IEC 61000-6-2:2016, EN IEC 61000-6-2:2019 Emission: IEC 61000-6-4:2018, EN IEC 61000-6-4:2019
Vibration resistance	EN 60068-2-6:2007, EN 60068-2-64:2019
Shock resistance	EN 60068-2-27:2008
Ambient operating temperature	0 °C ... +50 °C ¹⁾
Storage temperature	-20 °C ... +70 °C ²⁾
Permissible relative humidity	0% ... 90%, non-condensing
Ambient light immunity	2,000 lx on code
Ambient conditions	Degree of contamination 2 (according to EN 61010-1)
Altitude	< 5,000 m above sea level

- 1) If the ambient operating temperature will be ≥ 45 °C, ensure adequate heat dissipation when mounting the device, see ["Assembling the product", page 24](#).
To prevent condensation, avoid exposing the device to rapid changes in temperature.
- 2) Store in a place protected from moisture and dust.

10.7 Field of view

V2D8505R-xxxxxxxxx, focal length: 8 mm




Figure 23: Field of view V2D8505R-xxxxxxxxx, focal length: 8 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 3: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	453	376
1000	875	727
1500	1297	1078
2000	1719	1429
2500	2141	1779
3000	2563	2130

Table 4: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.22	0.36
1000	0.43	0.72
1500	0.63	1.06
2000	0.84	1.4
2500	1.04	1.74
3000	1.25	2.08

V2D8505R-xxxxxxx, focal length: 12 mm




Figure 24: Field of view V2D8505R-xxxxxxx, focal length: 12 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 5: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	301	251
1000	583	484
1500	864	718
2000	1145	952
2500	1427	1186
3000	1708	1420

Table 6: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.15	0.24
1000	0.28	0.48
1500	0.42	0.70
2000	0.56	0.92
2500	0.69	1.16
3000	0.83	1.38

V2D8505R-xxxxxxx, focal length: 16 mm




Figure 25: Field of view V2D8505R-xxxxxxx, focal length: 16 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Min. perceived field of view area: horizontal (mm)

Table 7: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	230	191
1000	441	366
1500	652	542
2000	863	717
2500	1073	892
3000	1284	1068

Table 8: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.11	0.18
1000	0.21	0.36
1500	0.32	0.52
2000	0.42	0.7
2500	0.52	0.88
3000	0.63	1.04

V2D8505R-xxxxxxx, focal length: 25 mm




Figure 26: Field of view of V2D8505R-xxxxxxx, focal length: 25 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 9: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	144	120
1000	279	232
1500	414	344
2000	549	456
2500	684	569
3000	819	681

Table 10: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.07	0.12
1000	0.14	0.22
1500	0.20	0.34
2000	0.27	0.44
2500	0.33	0.56
3000	0.40	0.66

V2D8509R-xxxxxxx, focal length: 12 mm




Figure 27: Field of view V2D8509R-xxxxxxx, focal length: 12 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 11: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	497	264
1000	965	513
1500	1433	761
2000	1900	1010
2500	2368	1258
3000	2836	1506

Table 12: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.15	0.24
1000	0.28	0.48
1500	0.42	0.70
2000	0.56	0.92
2500	0.69	1.16
3000	0.83	1.38

V2D8509R-xxxxxxx, focal length: 16 mm




Figure 28: Field of view V2D8509R-xxxxxxx, focal length: 16 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 13: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	380	202
1000	731	388
1500	1081	574
2000	1432	761
2500	1783	947
3000	2133	1133

Table 14: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.11	0.18
1000	0.21	0.36
1500	0.32	0.52
2000	0.42	0.70
2500	0.52	0.88
3000	0.62	1.04

V2D8509R-xxxxxxx, focal length: 25 mm




Figure 29: Field of view V2D8509R-xxxxxxx, focal length: 25 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 15: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	245	130
1000	470	250
1500	694	369
2000	919	488
2500	1143	607
3000	1368	727

Table 16: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.07	0.12
1000	0.14	0.22
1500	0.20	0.34
2000	0.27	0.44
2500	0.33	0.56
3000	0.40	0.66

V2D8512R-xxxxxxx, focal length: 12 mm




Figure 30: Field of view V2D8512R-xxxxxxx, focal length: 12 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Min. perceived field of view area: horizontal (mm)

Table 17: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	497	365
1000	965	709
1500	1433	1052
2000	1900	1396
2500	2368	1739
3000	2836	2082

Table 18: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.15	0.24
1000	0.28	0.48
1500	0.42	0.70
2000	0.56	0.92
2500	0.69	1.16
3000	0.83	1.38

V2D8512R-xxxxxxx, focal length: 16 mm




Figure 31: Field of view V2D8512R-xxxxxxx, focal length: 16 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 19: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	380	279
1000	731	537
1500	1081	794
2000	1432	1052
2500	1783	1309
3000	2133	1567

Table 20: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.11	0.18
1000	0.21	0.36
1500	0.32	0.52
2000	0.42	0.70
2500	0.52	0.88
3000	0.62	1.04

V2D8512R-xxxxxxxx, focal length: 25 mm




Figure 32: Field of view V2D8512R-xxxxxxxx, focal length: 25 mm

- ① Working distance in mm
- ② Perceived field of view area: horizontal (mm)
- ③ Perceived field of view area: vertical (mm)

Table 21: Perceived field of view area

Working distance (mm)	Horizontal (mm)	Vertical (mm)
500	245	180
1000	470	345
1500	694	510
2000	919	675
2500	1143	840
3000	1368	1004

Table 22: Minimum resolution

Working distance (mm)	1D code (mm)	2D code (mm)
500	0.07	0.12
1000	0.14	0.22
1500	0.20	0.34
2000	0.27	0.44
2500	0.33	0.56
3000	0.40	0.66

10.8 Data sheet for external illumination

Operating mode	Pulsed
Field of view, illumination	32 LEDs, visible light
Color	VI228U-WH5031F3: Visible white light medium, aperture angle: 31° VI228U-WH5047F3: Visible white light wide, aperture angle: 47°
LED class	Risk group 0 (free group) according to IEC 62471-1: 2006-07/EN 62471-1: 2008-09

Supply voltage Vs	DC 24 V ± 20%
Current consumption	Max. average current: 2 A Max. peak current 2.5 A
Frequency	1 ... 120 Hz
Pulse duration	50 ... 350 µs
Enclosure rating	IP 65 (IEC 60529:2013 +C1:2013 +C2:2015 +AMD2 C1:2019, EN 60529:1991 +A1:2010 +A2:2013 +AC:2019-02) ¹⁾
Ambient operating temperature	0 °C ... +40 °C ²⁾
Storage temperature	-20 °C ... +70 °C ³⁾
Permissible relative humidity	0% ... 90%, non-condensing

- 1) Prerequisites:
- The cables plugged into the electrical connections must be screwed tight. Unused electrical connections are sealed off with a protective cap.
- 2) Ensure adequate heat dissipation when mounting the device.
- 3) Store in a place protected from moisture and dust.

10.9 Dimensional drawing of external illumination




Figure 33: Structure and device dimensions, unit: mm (inch), decimal separator: period

- ① Electrical connections
- ② Polarizing filter
- ③ Screws for mounting the polarizing filter
- ④ M5 screws for mounting the external illumination unit on the mounting bracket

11 Accessories

Accessories and, if applicable, associated mounting information can be found on the product page.

The call is made via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

12 Annex

12.1 Declarations of conformity and certificates

You can download declarations of conformity and certificates via the product page.

The call is made via the **SICK Product ID: pid.sick.com/{P/N}/{S/N}**

{P/N} corresponds to the part number of the product, see type label.

{S/N} corresponds to the serial number of the product, see type label (if indicated).

12.2 Licenses

SICK uses open source software which is published by the rights holders under a free license. Among others, the following license types are used: GNU General Public License (GPL version 2, GPL version 3), GNU Lesser General Public License (LGPL), MIT license, zlib license and licenses derived from the BSD license.

This program is provided for general use without warranty of any kind. This warranty disclaimer also extends to the implicit assurance of marketability or suitability of the program for a particular purpose.

See the GNU General Public License for more information.

For license texts, see www.sick.com/licensetexts. Printed copies of the license texts are also available on request.

Australia
Phone +61 (3) 9457 0600
1800 33 48 02 – tollfree
E-Mail sales@sick.com.au

Austria
Phone +43 (0) 2236 62288-0
E-Mail office@sick.at

Belgium/Luxembourg
Phone +32 (0) 2 466 55 66
E-Mail info@sick.be

Brazil
Phone +55 11 3215-4900
E-Mail comercial@sick.com.br

Canada
Phone +1 905.771.1444
E-Mail cs.canada@sick.com

Czech Republic
Phone +420 234 719 500
E-Mail sick@sick.cz

Chile
Phone +56 (2) 2274 7430
E-Mail chile@sick.com

China
Phone +86 20 2882 3600
E-Mail info.china@sick.net.cn

Denmark
Phone +45 45 82 64 00
E-Mail sick@sick.dk

Finland
Phone +358-9-25 15 800
E-Mail sick@sick.fi

France
Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Germany
Phone +49 (0) 2 11 53 010
E-Mail info@sick.de

Greece
Phone +30 210 6825100
E-Mail office@sick.com.gr

Hong Kong
Phone +852 2153 6300
E-Mail ghk@sick.com.hk

Hungary
Phone +36 1 371 2680
E-Mail erteakesites@sick.hu

India
Phone +91-22-6119 8900
E-Mail info@sick-india.com

Israel
Phone +972 97110 11
E-Mail info@sick-sensors.com

Italy
Phone +39 02 27 43 41
E-Mail info@sick.it

Japan
Phone +81 3 5309 2112
E-Mail support@sick.jp

Malaysia
Phone +603-8080 7425
E-Mail enquiry.my@sick.com

Mexico
Phone +52 (472) 748 9451
E-Mail mexico@sick.com

Netherlands
Phone +31 (0) 30 204 40 00
E-Mail info@sick.nl

New Zealand
Phone +64 9 415 0459
0800 222 278 – tollfree
E-Mail sales@sick.co.nz

Norway
Phone +47 67 81 50 00
E-Mail sick@sick.no

Poland
Phone +48 22 539 41 00
E-Mail info@sick.pl

Romania
Phone +40 356-17 11 20
E-Mail office@sick.ro

Singapore
Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Slovakia
Phone +421 482 901 201
E-Mail mail@sick-sk.sk

Slovenia
Phone +386 591 78849
E-Mail office@sick.si

South Africa
Phone +27 10 060 0550
E-Mail info@sickautomation.co.za

South Korea
Phone +82 2 786 6321/4
E-Mail infokorea@sick.com

Spain
Phone +34 93 480 31 00
E-Mail info@sick.es

Sweden
Phone +46 10 110 10 00
E-Mail info@sick.se

Switzerland
Phone +41 41 619 29 39
E-Mail contact@sick.ch

Taiwan
Phone +886-2-2375-6288
E-Mail sales@sick.com.tw

Thailand
Phone +66 2 645 0009
E-Mail marcom.th@sick.com

Turkey
Phone +90 (216) 528 50 00
E-Mail info@sick.com.tr

United Arab Emirates
Phone +971 (0) 4 88 65 878
E-Mail contact@sick.ae

United Kingdom
Phone +44 (0)17278 31121
E-Mail info@sick.co.uk

USA
Phone +1 800.325.7425
E-Mail info@sick.com

Vietnam
Phone +65 6744 3732
E-Mail sales.gsg@sick.com

Detailed addresses and further locations at www.sick.com