



VMS 100

Volume Measurement System

SICK

Software versions described

Software/Tool	Function	Version
gnu960_VMS100_2-21	Evaluation Software (Firmware)	V2.21 20-09-2001
VMS100_setup	Commissioning Software	V2.11 20-09-2001

Windows '95TM; Windows '98TM and Windows NTTM are registered trade marks or trade marks of the Microsoft Corporation in the USA and other countries.

Contents

1	About this document	9
1.1	Function	9
1.2	Target group	9
1.2.1	Mounting, electrical installation, device replacement	9
1.2.2	Commissioning, maintenance	9
1.2.3	Operation	9
1.3	Depth of information	9
1.4	Symbology used	10
2	For your safet	11
2.1	Authorized personnel	11
2.1.1	Mounting and maintenance	11
2.1.2	Electrical installation and replacement of devices	11
2.1.3	Commissioning, operation and parameter-setting	11
2.2	Proper use	11
2.3	General safety information and protective measures	12
2.4	Quick stop and quick start	13
2.4.1	Switching off the VMS 100	13
2.4.2	Switching on the VMS 100	13
2.5	Environmental friendliness	13
2.5.1	Energy requirement	13
2.5.2	Disposal after final decommissioning	13
3	Product description	14
3.1	System components	14
3.1.1	Equipment supplied	14
3.1.2	System requirements	14
3.1.3	System view	15
3.2	The operating principle of the VMS 100	16
3.3	Indicators and operating elements	19
3.3.1	Operating elements	19
3.3.2	Functions of the LED indicators	19
3.4	Requirements and measurement accuracy	20
3.5	Overview of commissioning	22
4	Mounting	23
4.1	Overview of the steps involved in mounting	23
4.2	Preparing for mounting	23
4.2.1	Prepare the components for mounting	23
4.2.2	Prepare the accessories	23
4.2.3	Prepare mounting aids	23
4.2.4	Selecting the mounting location	23
4.2.5	Mounting accessories	24
4.3	Mounting the LMS 200	24
4.4	Mounting the VMC 100	25
4.5	Adjusting the LMS 200	25

4.6	Dismantling the system	26
5	Electrical installation	27
5.1	Overview of the installation steps	27
5.2	Electrical connections and cables.....	27
5.3	Pin configuration for the connections.....	28
5.3.1	LMS 200 connections.....	28
5.3.2	VMC 100 connections	29
5.4	Carrying out the electrical installation	32
6	Commissioning and parameter-setting.....	33
6.1	Starting the VM 100 Commissioning Software	33
6.2	Setting parameters.....	33
6.2.1	Setting measurement area parameters	34
6.2.2	Setting detection zone parameters	35
6.2.3	Setting velocity parameters	36
6.2.4	Setting process control parameters	36
6.2.5	Setting optional device parameters	37
6.2.6	Data transfer	37
6.3	Output of measurement data on the screen	37
6.4	Completion and test measurements.....	38
7	Maintenance	39
7.1	Maintenance during operation.....	39
7.2	Maintenance	40
7.3	Disposal.....	40
8	Troubleshooting.....	41
8.1	Overview of possible faults and problems	41
8.1.1	Mounting error.....	41
8.1.2	Error in the electrical installation.....	41
8.1.3	Parameterisation error.....	41
8.1.4	Operating difficulties.....	41
8.2	Monitoring signs of faults and problems	41
8.3	Identifying faults and remedying them.....	41
8.4	SICK Support.....	43
9	Technical data	44
9.1	Data sheet for the VMS 100 Volume Measurement System.....	44
9.2	Dimensional drawings	45
9.2.1	LMS 200-30106 Laser Measurement System dimensional drawing	45
9.2.2	VMC 100-0000 evaluation unit dimensional drawing	46
9.2.3	View of Mounting Set for LMS 200-30106	47
9.2.4	View of VMC 100-0100	48
10	Appendix.....	49
10.1	Overview of the Appendix.....	49
10.2	Telegram structure	49
10.2.1	Telegram format.....	49
10.2.2	VMC 100 status.....	50

VMS 100

10.2.3 LMS 200 device status	50
10.2.4 Replacing a system or components	51
10.3 Available accessories (order details)	52
10.3.1 The complete VMS 100 systems	52
10.3.2 Accessories	52
10.3.3 View of the accessories	53
10.4 Supplementary documentation	53
10.5 The EU Declaration of Conformity	54
10.5.1 The LMS 200 EU Declaration of Conformity	54
10.5.2 The VMC 100 EU Declaration of Conformity	56
10.6 Commissioning log	58
10.7 Inde	59

Abbreviations used

HD	H igh d ensity
LED	L ight e mitting d iode
LMI	L aser M easurement I nterface
LMS	L aser M easurement S ystem
VMS	V olume M easurement S ystem
VMC	V olume M easurement C ontroller

Tables

Table 3-1: VMC 100 LED indicators.....	19
Table 3-2: LMS 200 LED indicators.....	19
Table 3-3: Minimum and maximum dimensions of rectangular objects.....	20
Table 3-4: Object gaps typically required.....	20
Table 3-5: Typical accuracy for an object with dimensions > 200 x 200 x 200 mm ³ (L x W x H).	20
Table 3-6: Levels of accuracy for an object with dimensions > 200 x 200 x 200 mm ³ (L x W x H).	21
Table 5-1: LMS 200: pin configuration on the 9-pin D-sub device plug.....	28
Table 5-2: LMS 200: pin configuration on the 9-pin D-sub device socket.	28
Table 5-3: VMC 100: Configuration of the plug-in terminal strips for VMS 100 functions.	30
Table 5-4: VMC 100: Pin configuration for the 9-pin D-sub device socket ("COM" connection).	31
Table 5-5: LIM 200: "COM" data interface communication parameter values.....	31
Table 5-6: VMC 100: pin configuration for 15-pin D-sub HD device socket ("BUS" connection).	32
Table 6-1: Setting parameters for maximum detectable object lengths and possible speed ranges.	36
Table 7-1: LMS 200: LED error indicators on contamination of the front window.....	39
Table 7-2: VMC 100: LED error indicators on contamination of the LMS front window.	39
Table 8-1: Troubleshooting table.	42
Table 9-1: Technical specifications for the VMS 100.....	44
Table 10-1: Telegram format at the COM data interface (VMC 100).....	49
Table 10-2: Structure of external telegrams.....	50
Table 10-3: Output telegram: meaning of the VMC 100 status.	50
Table 10-4: Output telegram: meaning of the LMS 200 device status.....	50
Table 10-5: Order details: the complete VMS 100 system.	52
Table 10-6: Order details: optional accessories for operation.	52
Table 10-7: Order details: optional accessories for commissioning.	52
Table 10-8: Supplementary documentation.....	53

VMS 100

Illustrations

Fig. 2-1: Laser warning plates attached to the LMS 200.....	12
Fig. 3-1: Structure of the VMS 100-0000 with the VMC 100-0000 evaluation unit.....	15
Fig. 3-2: View inside the VMC 100-0100 evaluation unit.....	16
Fig. 3-3: The LMS 200-30106.....	16
Fig. 3-4: The LMI 200.....	17
Fig. 3-5: Sketch of the VMS 100 with its frame above the transport system.....	17
Fig. 3-6: Schematic diagram of VMS 100 components and peripheral devices.....	18
Fig. 3-7: Schematic diagram showing LMS 200 installation above a transport system.....	21
Fig. 4-1: Dimensional drawing for Mounting Set with LMS 200.....	24
Fig. 4-2: Mounting of the LMS 200 from above the transport system.....	24
Fig. 4-3: Definition of the LMS 200 angles α , β and γ	25
Fig. 4-4: View from above the LMS 200 with plumbline and measurement line.....	26
Fig. 5-1: VMC 100: position of the terminal strips and D-sub plug connections on the front panel.....	29
Fig. 6-2: Sketch of the measurement area and detection zone with the height of the detection line.....	35
Fig. 6-3: Display of measurement data, an example after a restart.....	38
Fig. 9-1: Dimensions of the LMS 200-30106 Laser Measurement System.....	45
Fig. 9-2: Dimensions of the VMC 100-0000 evaluation unit.....	46
Fig. 9-3: Structure of Mounting Set no. 2 020 925.....	47
Fig. 9-4: Dimensions of the VMC 100-0100 evaluation unit.....	48
Fig. 10-1: Structure and electrical connection of the heating plate no. 2 019 522.....	53
Fig. 10-2: The EU Declaration of Conformity for the LMS 200, Page 3 (reduced in size).....	54
Fig. 10-3: The EU Declaration of Conformity for the LMS 200, Page 2 (reduced in size).....	55
Fig. 10-4: The EU Declaration of Conformity for the VMC 100, Page 3 (reduced in size).....	56
Fig. 10-5: The EU Declaration of Conformity for the VMC 100, Page 2 (reduced in size).....	57

VMS 100

1 About this document

1.1 Function

This document provides instructions for commissioning, operating and maintaining the SICK VMS 100 Volume Measurement System.

The document contains information on:

- mounting and electrical installation,
- commissioning,
- operation and configuration (parameter-setting),
- maintenance,
- replacing system components.

The VMS 100 Volume Measurement System will simply be described as the VMS 100 in this document.

1.2 Target group

The target group of this document are persons carrying out the following activities:

1.2.1 Mounting, electrical installation, device replacement

Specialist personnel such as service technicians or factory electricians

1.2.2 Commissioning, maintenance

Specialist personnel such as technicians or engineers

1.2.3 Operation

Specialist personnel for operation and parameterisation of the transport system

1.3 Depth of information

This document contains all the information necessary for the mounting, electrical installation and commissioning of the VMS 100 with the basic operational settings. Step-by-step instructions are provided for all activities.

Configuration (parameter-setting) of the VMS 100 for on-site application is carried out using the VMS 100 Commissioning Software. Installation of the software and interaction with the user interface is described in *Chapter 6 Commissioning and parameter-setting*.

The document provides information on the working principle and the technical data of the VMS 100 Volume Measurement System. Details on the LMS 200 Laser Measurement System (Type 30106) and the VMC 100 evaluation unit (based on the SICK device LMI 200) can be found in the appropriate documentation, see *Chapter 10.4 Supplementary documentation*.

Further information on Volume Measurement Systems, Laser Measurement Systems and bar-code scanners can be obtained from SICK AG, Division Auto Ident.

1.4 Symbology used

Some information in this documentation is given particular emphasis to make it easier to find it quickly.



ATTENTION

WARNING!

Warnings prevent physical injury or serious damage to the VMS 100.

- Always read warnings attentively and follow instructions carefully.

Recommendation A recommendation helps you carry out an activity more efficiently.

Please note Such notes provide information on special features.

Font This style of writing signifies an input or term in the user interface of the VMS 100 Commissioning Software.

Reference Italics are used to refer to more detailed information elsewhere.

- You must do something here. This symbol signifies an action comprising a single-step instruction. Instructions involving more than one step are signified by the use of successive numbers.

VMS 100

2 For your safety

2.1 Authorised personnel

Sufficiently qualified personnel must mount and operate the VMS 100 to ensure proper and safe function.

The following qualifications are required for the various activities:

2.1.1 Mounting and maintenance

- Practical technical training
- Knowledge of current safety regulations for the workplace

2.1.2 Electrical installation and replacement of devices

- Practical training in electrical engineering
- Knowledge of the current electrical engineering safety regulations
- Knowledge on the operation and use of transport systems

2.1.3 Commissioning, operation and parameter-setting

- Knowledge of the mechanical and electrical engineering parameters of transport systems and the properties of transport systems regarding their operation and use
- Basic knowledge of Windows NTTM/Windows 95
- Basic knowledge of data transfer

2.2 Proper use

The VMS 100 Volume Measurement System measures rectangular objects on transport systems. The VMS 100 determines the length, width and height of rectangular objects and transfers this information, via a data interface, to a higher-ranking computer for further processing.

The measurement system is not a device for protecting persons as defined by current machine safety standards.

The system consists of an LMS 200 Laser Measurement System of type 30106 (enclosure rating IP 65) and a VMC 100 Controller, also known as an evaluation unit (VMC 100-0000: enclosure rating IP 20, VMC 100-0100: enclosure rating IP 65). There is a switchable RS-232/RS-422 interface on the evaluation unit for data output. Devices such as a bar-code scanner or weighing machine can be connected to an RS-485 interface. A shaft encoder and photoelectric switch can be connected to the VMC 100.

All warranty claims against SICK AG are forfeited in the case of any other use, or alterations being made to devices, even as part of their mounting or electrical installation.

2.3 General safety information and protective measures

- Read the general safety information attentively and follow it carefully during all activities with the VMS 100. Similarly, pay attention to the warnings before instructions in the individual chapters of this document.



ATTENTION

Danger of injury through electrical current

The VMC 100 (DC 24 V) can also be connected to the power supply network (AC 230 V 50 Hz) via a power supply unit.

- Follow the current safety regulations when working with electrical equipment.



ATTENTION

Laser radiation

The LMS 200 operates using a Class 1 infrared laser.

- Follow laser protection regulations according to DIN EN 60825-1 (latest version).

Laser warning plate

The laser warning plate and laser warning symbol (*Fig. 2-1*) are located on the right-hand side of the LMS 200 Laser Measurement System, as seen from the front.




Fig. 2-1: Laser warning plates attached to the LMS 200.

Please note:

If the Laser Measurement System is installed within a machine/casing in such a way that the laser warning plates are covered up, more warning plates (not supplied) must be attached to the machine/casing next to the laser beam exit window!

VMS 100

2.4 Quick stop and quick start

2.4.1 Switching off the VMS 100

- Switch off the VMC 100's power supply.
The VMS 100 retains permanently stored parameters in its internal memory. Measurement data are lost.

2.4.2 Switching on the VMS 100

- Switch on the VMC 100's power supply.
The VMS 100 restarts operation with the parameters that were most recently saved.

2.5 Environmental friendliness

The VMS 100 is constructed in such a way that it adversely affects the environment as little as possible.

2.5.1 Energy requirement

The VMS 100, with the LMS 200 and VMC 100, has a maximum consumption of approx. 60 W.

2.5.2 Disposal after final decommissioning

Dispose of unusable or irreparable devices in an environmentally friendly manner according to the particular waste disposal regulations valid in the country of use. The VMS is constructed to allow separation into recyclable secondary raw materials and special waste (electronic scrap). See *Chapter 7.3 Disposal*.

SICK AG does not currently take back any unusable or irreparable devices.

3 Product description

3.1 System components

3.1.1 Equipment supplied

The VMS 100 is supplied with:

- one LMS 200-30106 Laser Measurement System,
- one Mounting Set for adjusting the LMS 200-30106, two-axis, fine adjustment,
- one VMC 100 Volume Measurement Controller with VMS 100 Evaluation Software installed.
VMC 100-0000 with Mounting Set for wall mounting.
VMC 100-0100 with switching cabinet incl. power supply unit,
- one Set for the electrical connection of the LMS 200-30106 to the VMC 100,
- one diskette with VMS 100 Commissioning Software for a PC under Windows NT™/Windows 95,
- one set of VMS 100 Operating Instructions

Chapter 10.3 Available accessories (order details) provides an overview of the accessories for operation, installation and electrical connection, as well as supplementary documentation.

3.1.2 System requirements

The following are required for commissioning and operating the VMS 100:

- Installation of the LMS 200 typically requires 1300 mm space above the tallest object.
- VMC 100-0000 operating voltage DC 24 V \pm 15% acc. to IEC 742 (functional low voltage), consumption ca. 60 W. VMC 100-0100 operating voltage AC 230 V -15%/+10% 50 Hz.
- PC with Windows NT™/Windows 95 operating system and RS-232 interface.
- RS-232 data connection cable with two 9-pin D-sub sockets, e.g. order no. 2 016 401.
- RS-232 or RS-422 data interface on measurement result destination computer.
- Connection module for bus systems available on request.
- Transport system: constant transport speed or shaft encoder (resolution min. 1 incr./mm, see *Chapter 10.3 Available accessories*) and a flat transport surface.

Optional:

- A switch or host telegram to start the measurement process if "limited measurement readiness" is selected as the operating mode.
- An auxiliary device (e.g. bar-code scanner) with data output via telegram for joint output of separately determined information.

VMS 100

3.1.3 System view

LMS 200 and VMC 100-0000




Fig. 3-1: Structure of the system with the VMC 100-0000 evaluation unit.


VCM 100-0100

Fig. 3-2: View inside the VMC 100-0100 evaluation unit.

The VMC 100-0000 is integrated inside a switching cabinet (not yet completely wired up in the picture).

3.2 The operating principle of the VMS 100

The VMS 100 Volume Measurement System determines the length, width and height of rectangular objects in any alignment on transport systems without contact and in real time. An optional input and output of separately determined information (e.g. bar-codes) can take place.

The operating principle of the LMS 200-30106

The Laser Measurement System LMS 200-30106 scans a two-dimensional measurement area without contact. The LMS requires no reflectors or position marks. No illumination of objects is necessary as it is an active system with an infrared laser.



Fig. 3-3: The LMS 200-30106.

VMS 100

The LMS operates according to the time-of-flight principle. The distance from the object to the system is determined from the time between the transmission of a light pulse and the reception of the light reflected by the object, as measured by the LMS.

The operating principle of the VMC 100

The VMC 100 Laser Measurement Interface is based on the LMI 200. The LMI 200 is a multifunctional evaluation unit specially developed for processing LMS data. The LMI 200 can process and transmit, via digital and analogue interfaces, the process data obtained for various measurement commands. The MST 200 Measurement Software Tool is available for the development of customer-specific evaluation software.



Fig. 3-4: The LMI 200.

According to its configuration, the LMI 200 processes data supplied by the LMS 200 Laser Measurement System together with other information. These data are processed in real time and given out at the interfaces as measurement results.

The operating principle of the VMS 100

An LMS 200 Laser Measurement System is installed above the transport system. It scans the surface of the transport system and the transported objects about every 13.3 ms. The distance data obtained by the LMS 200 are transferred to the VMC 100 in real time. The speed of the transported objects is set as a constant or can be provided using an optional shaft encoder.




Fig. 3-5. Sketch of the VMS 100 with its frame above the transport system.

The three-dimensional information on the rectangular object is available after the distance data have been determined and the speed calculated in. The VMS program calculates the length, width and height of the rectangular object from the measurement data. Output of the data takes place at the VMC 100's selectable RS-232/RS-422 interface.

VMS 100 layout

The measurement data is made available at an RS-232/RS-422 interface. Connection to a data transfer system can take place via gateways or interface converters.

A shaft encoder can be connected to the VMC 100. The VMC 100 can receive results from auxiliary devices (e.g. bar-code measurements) via the RS-485 interface and give them out in real time together with the dimensional data at the RS-232/RS-422 interface of the VMC 100.

Please note:

Customers require their own Windows NT/Windows 95 PC with RS-232 interface and a data cable (e.g. 2016401) for commissioning and parameter-setting.

The following schematic diagram shows the components of the VMS 100.




Fig. 3-6: Schematic diagram of VMS 100 components and peripheral devices.

VMS 100

3.3 Indicators and operating elements

3.3.1 Operating elements

Parameterisation of the VMS 100 takes place via the supplied VMS 100 Commissioning Software, installed on the PC by the customer. The VMS 100 can be operated with permanent or limited measurement readiness:

- With permanent measurement readiness objects are automatically detected and the data recorded. The object data is calculated and given out after the end of the object has been reached.
 - Automatic Mode
- With limited measurement readiness the next object is only automatically detected and the data recorded after activation. The object data is calculated and given out after the end of the object has been reached; the VMS 100 is then only ready for renewed measurement after reactivation. Activation can be carried out by:
 - a digital switch (falling flank),
 - a host telegram (renewed host request only after object measurement completed).

3.3.2 Functions of the LED indicators

Two LED indicators on the VMC 100 provide optical information on the operating state and errors. The LED indicators are located on the front panel.

LED	Indicator	VMC 100 state
POWER	green	switched on (DC 24V supplied)
	off	switched off (no power supply)
MODE	green	Measurement Mode active
	off	Setup Mode
	10% green blinking	Service Mode
	90% green blinking	Measurement Mode is being activated
	red	Software Download Mode (VMC 100 busy)
	green/red blinking	Warning (e.g. front window contamination entered in error log), Measurement Mode is still active ¹⁾
	red blinking	VMC 100 error (error entered in error log) ¹⁾
1) Run VMC 100 Diagnostics with User Software		

Table 3-1: VMC 100 LED indicators.

Three LED indicators on the LMS 200 provide optical information on the operating state and errors.

LED	Normal operation	Initialisation	Contamination warning	Contamination error	Error	Fatal error
Green	100% on	off		off	off	off
Yellow (1 Hz)	off	100% on	50% on / 50% off	90% on / 10% off	10% on / 90% off	50% on / 50% off
Red	off	100% on		on	on	on

Table 3-2: LMS 200 LED indicators.

3.4 Requirements and measurement accurac

Object requirements

The VMS 100 is designed for determining the volumes of rectangular objects. Rectangular objects have straight sides with no curves or projections. The minimum and maximum object dimensions are summarised in the following table:

Object dimension	Minimum value	Maximum value
Length along direction of transport	200 mm	1500 mm to 7500 mm
At right angles to direction of transport	200 mm	1500 mm
Height on the transport system	100 mm	1500 mm

Table 3-3: Minimum and maximum dimensions of rectangular objects.

Please note:

The maximum value for the dimension along the direction of transport is 1500 mm as standard. How the maximum value can be varied is described in *Table 6-1* in *6.2 Setting parameters*.

The transport speed must be at least 0.1 m/s and at most 2 m/s. The time periods between objects must typically be: at least 1/10 of the maximum object dimension along the direction of transport. See following table.

Object dimension along the direction of transport	Gaps required between objects
< 1000 mm	100 mm
< 1500 mm	150 mm

Table 3-4: Object gaps typically required.

VMS 100 measurement accurac

Typical levels of accuracy are provided in *Table 3-5*.

Speed	Typical accuracy
Speed < 1 m/s	± 15 mm in length, width and height
1 m/s ≤ speed ≤ 2 m/s	± 25 mm in length ± 20 mm in width and height

Table 3-5: Typical accuracy for an object with dimensions > 200 x 200 x 200 mm³ (L x W x H).

The following accuracies apply at room temperature, with an object reflectivity of 10% to 1000% and for recommended device structures corresponding to SICK documentation. Restricted ranges for object reflectivity and object dimensions provide higher levels of accuracy. Highly reflective surfaces and other effects can lower accuracy.

VMS 100

Speed	Accuracy
Speed < 1 m/s	± 30 mm in length, width and height
1 m/s ≤ speed ≤ 2 m/s	± 50 mm in length ± 35 mm in width ± 30 mm in height

Table 3-6: Levels of accuracy for an object with dimensions > 200 x 200 x 200 mm³ (L x W x H).

Transport system requirements

The typical space requirement for installation of the LMS is about 1300 mm above the tallest object. The distance between the LMS and the upper surface of the tallest object must be at least about 700 mm, while a distance of about 1000 mm is recommended. Central mounting above the middle of the transport system is recommended, see Fig.3-2. If the objects are fed in at one of the transport system's sides mounting can be carried out asymmetrically above the transport system.




Fig. 3-7: Schematic diagram showing LMS 200 installation above a transport system.

Objects can be moved using any transport system with a flat transporting surface.

Rotation, vibration, rolling motion and slippage of objects on the transport system, or uneven transport surfaces, can reduce accuracy and have an adverse effect on data capture by the VMS. Curves, induction lines, start-stop sections, rising/falling sections and gaps in the transport system should be a sufficient distance from the measurement area for high accuracy and proper data capture.

The LMS 200 must have a clear view of the transport system.

The transport system must either have a constant transport velocity or a shaft encoder signal with a resolution of at least 1 Incr./mm must be installed, see 10.3 Available accessories (order details).

LMS 200 mounting requirements

The LMS 200 must be mounted in such a way that it is:

- stable above the transport system (an LMS 200 unit weighs approx. 4.5 kg),
- shock-free and vibration-free,
- above the transport system.

Fig. 3-2 shows an LMS 200 installation above the transport system with typical distances.

Please note:

The Mounting Set is easy to attach to an 8 mm item aluminium profile as it is designed for this profile. The dimensional drawing in *Fig. 4-1* is to be complied with for mounting using other equipment.

3.5 Overview of commissioning

1. Mount the LMS 200 (see *4 Mounting*).
2. Connect the LMS 200 to the VMC 100 with a data cable (see *5 Electrical installation*).
3. Connect the LMS 200 to the VMC 100 with a power supply cable (see *5 Electrical installation*).
4. Connect the power supply to the VMC 100 (see *5 Electrical installation*).
5. Adjust the LMS 200 (see *4 Mounting*).
6. Set VMS 100 parameters (see *6 Commissioning and parameter-setting*).

VMS 100

4 Mounting

4.1 Overview of the steps involved in mounting

- If necessary: mount the frame in the desired area of the transport system
- Attach the LMS Mounting Set to the frame or onto stable equipment
- Attach the LMS 200 to the Mounting Set
- Mount the VMC 100 evaluation unit

4.2 Preparing for mounting

4.2.1 Prepare the components for mounting

- The LMS 200 Laser Measurement System
- The LMS 200 Mounting Set
- The VMC 100 evaluation unit

4.2.2 Prepare the accessories

The following accessories will be needed for the Mounting Set and LMS 200-30106:

- Screws for attaching the Mounting Set to the frame or other equipment. The Mounting Set has 8xD6.6 drilled holes, see *Fig. 4-1*.
The LMS 200 weighs approx. 4.5 kg
- Four M8x12 screws with washers (supplied) for attaching the LMS 200 to the Mounting Set

4.2.3 Prepare mounting aids

- Plumblin
- Spirit level
- Measurement tape (up to 3000 mm) or folding metre-rule
- Scanfinder
- Pencil
- Tools, M6 screws

4.2.4 Selecting the mounting location

The VMS 100 is supplied with a power supply cable and data transfer cable that are each 10 m long. Select an appropriate mounting location for the LMS 200 and VMC 100.

4.2.5 Mounting accessories

A Mounting Set is supplied for mounting the LMS 200. It can be finely adjusted in two axes.




Fig. 4-1: Dimensional drawing for Mounting Set with LMS 200

Measurements in mm. Total LMS 200 weight is approx. 4.5 kg. The angles are based on Fig. 4-3.

4.3 Mounting the LMS 200

Fig. 4-2 shows the mounting of the LMS 200 from above the transport system. The angles α , β and γ are defined in Fig. 4-3.




Fig. 4-2: Mounting of the LMS 200 from above the transport system.

VMS 100




Fig. 4-3: Definition of the LMS 200 angles α , β and γ .

During preparation ensure that the LMS 200 and the Mounting Set can be mounted horizontally to the transport system: α , β , $\gamma = 0$.

LMS 200 angles α and β can be adjusted with the Mounting Set.

To align the LMS 200 above the middle of the transport area turn an M6 screw in the middle drilled hole at the base of the LMS 200 and attach the plumbline to it with the lead touching the transport system. Determine the middle of the transport area with transported objects on the transport system. Align the LMS 200 until the lead touches the middle of the transport area.

4.4 Mounting the VMC 100

The VMC 100 must be freely accessible so that the electrical supply and data cables can be connected. The VMC 100-0000 can be mounted on a standard mounting rail or the supplied bracket can be used. The VMC 100-0100 is supplied as a version with a switching cabinet.

4.5 Adjusting the LMS 200

Please note:

Electrical installation (*5 Electrical installation*) must be completed before adjustment.

Spatial alignment of the LMS 200

1. Turn an M6 screw in the middle drilled hole in the base of the LMS 200. Attach the plumbline in such a way that it meets the end of the housing.
2. Turn the adjustment screw that is perpendicular to the direction of transport until the measurement line of the LMS 200 is located below the LMS 200 exactly 6.3 cm from where the plumbline meets the transport system in the direction of transport, see *Fig. 4-4*. Use the switched on Scanfinder to detect the measurement line (IR laser light).
3. Turn the adjustment screw that is in the direction of transport until the measurement line is on the transport system and perpendicular to the transport direction, see *Fig. 4-4*. For this purpose, use the switched on Scanfinder to detect the measurement line (IR laser light) on the left or right side of the transport system.




Fig. 4-4: View from above the LMS 200 with plumbline and measurement line.

Recommendation:

Mount and adjust the LMS 200 carefully to achieve the highest levels of measurement value accuracy.

4.6 Dismantling the system

1. Switch off the power supply to the VMC 100 evaluation unit.
2. Remove the data cable, power supply cable and, if necessary, the clock-pulse cable from the VMC 100.
3. Remove the cables between the VMC 100 and the LMS 200 Laser Measurement System.
4. Remove the LMS 200 from the Mounting Set above the transport system.
5. Unscrew the VMC 100.

In the final decommissioning follow the instructions in *Chapter 7.3 Disposal* for environmentally friendly disposal.

VMS 100

5 Electrical installation

5.1 Overview of the installation steps

- Connect the VMC 100 to the LMS 200 (data transfer and power supply)
- Connect the VMC 100 with the higher-ranking destination computer (data transfer)
- Temporarily: connect the VMC 100 with a PC for commissioning, parameterisation and diagnostics

5.2 Electrical connections and cables

The electrical connection of the VMS 100 consists of interfaces within the system and interfaces to the outside.

LMS 200:

Via 9-pin D-sub plug connections with plug modules:

- power supply (the "DC 24 V power supply" connection)
- a serial data interface (the "RS-422" connection)

VMC 100:

Via plug-in terminal strips and a 9-pin D-sub / 15-pin D-sub HD plug connection on the front panel:

- power supply (the "DC 24 V power IN" connection)
- power supply to LMS 200 (the "DC 24 V power OUT" connection)
- a data interface to the LMS 200 (the "RS-422 sensor" connection)
- four digital switching inputs (the "digital IN" connections)
- two inputs for shaft encoder signals (the "shaft encoder IN" connections)
- a data interface to higher-ranking destination computer or temporarily to PC (the "COM" connection)
- a data interface to connect optional devices (the "BUS" connection)

The LMS 200 is connected to the VMC 100 via two pre-assembled cables each 10 m long.

- cable 1 (power supply):
plug module with 9-pin D-sub socket (LMS 200) on 6-pin connector strip nos. 1-6 (VMC 100)
- cable 2 (data transfer):
plug module with 9-pin D-sub plug (LMS 200) on 10-pin connector strip nos. 7-16 (VMC 100)

5.3 Pin configuration for the connections

5.3.1 LMS 200 connections

The "DC 24 V power supply" connection


	PIN	Signal	Function	Cable colour
	1	GND	Ground	Brow
	2	New start	-	Blue
	3	24 V DC	Power supply	Red
	4	n.c.	-	-
	5	OUT C	Output C	Grey
	6	n.c.	-	-
	7	n.c.	-	-
	8	OUT B	Output B	Turquoise
	9	OUT A	Output A	Orange

Table 5-1: LMS 200: pin configuration on the 9-pin D-sub device plug.

The "RS-422" connection (data interface)


	PIN	Signal RS-422	Function	Cable colour
	1	RxD-	Receiver -	Yello
	2	RxD+	Receiver +	Green
	3	TxD+	Transmitter +	White
	4	TxD-	Transmitter -	Brow
	5	GND	Ground/screen	Black
	6	n.c.	-	
	7	bridged with PIN 8	Switches to RS-422	
	8	bridged with PIN 7	Switches to RS-422	
	9	n.c.	-	

Table 5-2: LMS 200: pin configuration on the 9-pin D-sub device socket.

VMS 100

5.3.2 VMC 100 connections

Fig. 5-1 shows the location of the terminal strips and D-sub plug connections on the front panel.




Fig. 5-1: VMC 100: position of the terminal strips and D-sub plug connections on the front panel.

The VMC 100 is based on the LMI 200 and has the same plug connections.

Terminal strips (functional interfaces)

The terminal strips, with a total of 58 terminals, are organised in seven functional groups.

Terminal	VMC 100 connection	VMC 100 signal	Connected device signal	Function
1	POWER DC 24V IN	DC +24 V	DC +24 V	Power supply VMC 100
2	POWER DC 24V IN	GND	GND	Ground
3	POWER DC 24V OUT	DC +24 V	DC +24 V	Power supply to LMS 200
4	POWER DC 24V OUT	GND	GND	Ground
5	POWER DC 24V OUT	DC +24 V	-	-
6	POWER DC 24V OUT	GND	-	-
7	SENSOR RS-422 (1)	R+	T+ (pin 3, white)	Data transfer to LMS 200
8	SENSOR RS-422 (1)	R-	T- (pin 4, brown)	Data transfer to LMS 200
9	SENSOR RS-422 (1)	T-	R- (pin 1, yellow)	Data transfer to LMS 200
10	SENSOR RS-422 (1)	T+	T+ (pin 2, green)	Data transfer to LMS 200
11	SENSOR RS-422 (1)	GND	GND (pin 5)	Ground
12 - 16	SENSOR RS-422 (2)	-	-	-
17 - 20	ANALOGUE IN	-	-	-
21	DIGITAL IN 1 (+)	-	-	Photoelectric switch Q
22	DIGITAL IN 1 (ground)	-	-	Ground

Terminal	VMC 100 connection	VMC 100 signal	Connected device signal	Function
23	DIGITAL IN 2 (+)	-	-	Photoelectric switch /Q
24	DIGITAL IN 2 (ground)	-	-	-
25	DIGITAL IN 3 (+)	DC +24V	DC +24V	Switch (optional: 'Digital Switch' Mode): measurement readiness on brief switching (falling flank min. 20 ms before object on measurement line) activate, no pallet
26	DIGITAL IN 3 (ground)	GND	GND	Ground
27	DIGITAL IN 4 (+)	DC +24V	DC +24V	Switch (optional: 'Digital Switch' Mode): measurement readiness on brief switching (falling flank min. 20 ms before object on measurement line), pallet height taken into account
28	DIGITAL IN 4 (ground)	GND	GND	Ground
29	INCREMENT IN 1 (0°)	IN (+24V)	+24V	Shaft encoder 0° (optional)
30	INCREMENT IN 1 (90°)	IN (+24V)	+24V	Shaft encoder 90°(optional)
31	INCREMENT IN 1 (ground)	GND	GND	Ground
32 - 34	INCREMENT IN 2	-	-	-
35	DIGITAL OUT 1	0 V bei AUS, + 24 V wenn aktiv	0 V bei AUS, + 24 V wenn aktiv	Measurement readiness indicator (blinking: LMS error)
36	DIGITAL OUT 1 (ground)	GND	GND	Ground
37 - 38	DIGITAL OUT 2	as 35 - 36	as 35 - 36	
39 - 40	DIGITAL OUT 3	as 35 - 36	as 35 - 36	
41	DIGITAL OUT 4	0 V when OFF, + 24 V when active	0 V when OFF, + 24 V when active	Measurement process active indicator (blinking: LMS error)
42	DIGITAL OUT 4 (ground)	GND	GND	Ground
43 - 44	DIGITAL OUT 5	as 41 - 42	as 41 - 42	
45 - 46	DIGITAL OUT 6	as 41 - 42	as 41 - 42	
47	DIGITAL OUT 7	0 V when OFF, + 24 V when active	0 V when OFF, + 24 V when active	Indicator warning: object too long
48	DIGITAL OUT 7 (ground)	GND	GND	Ground
49 -50	DIGITAL OUT 8	-	-	
51 -58	ANALOGUE OUT 8	n.c.	n.c.	

Table 5-3: VMC 100: Configuration of the plug-in terminal strips for VMS 100 functions.

VMS 100

"COM" connection (data interface)


	VMC 100 RS-232/RS-422			Connected device	
	PIN	RS-232	RS-422	RS-232	RS-422
	1	n.c.	R-	n.c.	T-
	2	RxD	R+	TxD	T+
	3	TxD	T+	RxD	R+
	4	n.c.	T-	n.c.	R-
	5	GND	GND	GND	GND
	6	n.c.	n.c.	n.c.	n.c.
	7	n.c.	Bridge to PIN 8	n.c.	n.c.
	8	n.c.	Bridge to PIN 7	n.c.	n.c.
9	n.c.	n.c.	n.c.	n.c.	

Table 5-4: VMC 100: Pin configuration for the 9-pin D-sub device socket ("COM" connection).

Communication parameter	Value
Baud rate	9600 bit/s
Data bits	8
Parity	none
Stop bit	1

Table 5-5: LIM 200: "COM" data interface communication parameter values.

Please note:

After a configuration of the VMS 100 by means of the VMS 100 Commissioning Software the power supply to the VMC 100 evaluation unit must be briefly interrupted.

After the restart interface parameters are set as shown in *Table 5-5*.

The "BUS" connection (data interface)

The RS-485 interface allows the input of additional information (e.g. bar-code or weight information) from the appropriate devices.

Please note:

The entire external telegram must be received by the VMC 100 while the object is crossing the measurement line.

Table 5-6 shows the pin configuration. A termination resistance of 120 Ohms must be used on the receiver for cable lengths of more than 50 m.


	VMC 100		Connected device
	PIN	Signal RS-485	External device: e.g. bar-code scanner
	11	R-	T-
	12	R+	T+
	13	T-	(R-)
	14	T+	(R+)
	15	GND	GND

Table 5-6: VMC 100: pin configuration for 15-pin D-sub HD device socket ("BUS" connection).

The interface also operates with the communication parameters shown in *Table 5-5*.

5.4 Carrying out the electrical installation

Data output takes place at the front panel via a 9-pin D-sub RS-232/RS-422 plug connection. The connection of further devices takes place at the front panel via a 15-pin D-sub RS485 plug connection.

The data and power supply lines between the LMS 200 and VMC 100 are supplied with cabled LMS 200 plug modules and with VMC 100 plugs for connector strips for connecting the LMS 200 to the VMC 100. Connect the LMS 200 to VMC 100:

1. Connect data cable plug module to LMS 200
2. Wire up the data cable connection strip to the connection strip and plug into the VMC 100 plug connection
3. Connect power supply plug module to LMS 200
4. Wire up the power supply cable connection strip to the connection strip and plug into the VMC 100 socket

Please note:

Only operate the LMS 200 with correctly attached plug modules.

Waterproofing is only guaranteed, with the device corresponding to IP65 and with EMC requirements (EMD) according to CE, when the plug modules have been completely mounted onto the scanner. The plug modules must be provided with locking screws or PG screws with seals and D-sub device plugs.

5. Connect the VMC 100-0000 according to *Table 5-3* (PIN 1 and 2) or VMC 100-0100 to the power supply.

The VMC 100 and LMS 200 commence operation after the power supply has been switched on. The start process can take a few minutes. The LMS 200 and VMC 100 are in an operating state when the green LEDs on both devices are lit.

Adjustment of the LMS 200 (*4.5 Adjusting the LMS 200*) can take place after the electrical installation.

VMS 100

6 Commissioning and parameter-setting

A PC with the Windows '95™ or Windows NT™ operating system and an RS-232 interface and an RS-232 male/female-crossed data cable (see 10.3 Available accessories (order details)) is required for commissioning and parameter-setting.

6.1 Starting the VMS 100 Commissioning Software

VMS 100 parameters are set using the VMS 100 Commissioning Software. The VMS 100 Commissioning Software is started on the PC.

1. Connect PC to the VMC 100 RS-232 COM interface with an RS-232 male/female-crossed data cable.
2. Insert the diskette with the VMS 100 Commissioning Software in diskette drive.
3. Copy files into their own directory on the PC.
4. Select and run the `VMS100_Setup` file using the Start menu.

The VMS 100 Commissioning Software starts and opens a window labelled VMC 100 User Software for VMS 100.

Recommendation:

After commissioning keep the diskette with the VMS 100 Commissioning Software in a safe place to allow subsequent re-setting of parameters.

6.2 Setting parameters

The VMS 100 can be parameterised after the VMS 100 Commissioning Software has been started.

- Click on the `Parameters` entry in the sub-menu `VMS 100` in the `Start` menu.
The menu window `Parameters for the VMS 100 Volume Measurement System` appears.
The menu window is divided up into six sections and shows a schematic representation of the VMS 100.

In the

- `LMS/conveyor position`
- `Zone of detection`
- `Velocity`
- `Process`
- `Peripherals`

sections there are fields, some of which have pull-down menus, for entering parameter values.

In the

- `Controls` section

there are four buttons for operating and checking the menu window and for data exchange from the PC to VMC 100.

Fig. 6-1: VMS 100 Commissioning Software: example of the Parameters for VMS 100 window.

Please note:

All parameters in the Parameters for the Volume Measurement System VMS 100 Vx.xx menu window must be entered as positive values.

- Close window with Exit.

In order to achieve greater accuracy, it is recommended that parameters are reset if the LMS 200 is replaced.

6.2.1 Setting measurement area parameters

Turn an M6 screw in the middle drilled hole in the base of the LMS 200 and attach the plumbline and let the lead weight touch the transport system. Note the distance to the left and right sides of the transport system from the lead weight, see *Fig. 6-2*.

The measurement area is defined in the *LMS/conveyor position* section on the basis of the LMS 200 position.

1. Enter the distance to the left edge of the transport area from the lead weight of the LMS 200 in mm in the *Left conveyor (mm)* field.

VMS 100

2. Enter the distance to the right edge of the transport area from the lead weight of the LMS 200 in mm in the `Right conveyor (mm)` field.
3. Enter the height of the LMS 200 above the transport system in the `Height LMS/conveyor (mm)` field.

Please note:

No object other than the object to be measured may be detectable for the LMS 200 in the measurement area during Measurement Mode.




Fig. 6-2: Sketch of the measurement area and detection zone with the height of the detection line.

The left/right limits of the measurement are to be entered in the `Left/Right conveyor (mm)` fields as seen when looking at the bottom of the LMS 200, and similarly for the detection zone.

6.2.2 Setting detection zone parameters

The detection zone is defined in the `Zone of Detection` section. When ready for measurement a volume measurement is started as soon as an object enters the detection zone, see *Fig. 6-2*. The detection zone parameters must be at least 50 mm smaller on each side than the values of the measurement area. No objects except the target object may be present in the detection zone.

1. Enter the left limit of the detection zone in mm from the lead weight of the LMS 200 in the `Left (mm)` field. This value should not exceed the value in the `Left conveyor (mm)` field.
2. Enter the right limit of the detection zone in mm from the lead weight of the LMS 200 in the `Right (mm)` field. This value should not exceed the value in the `Right conveyor (mm)` field.
3. Enter the height of the detection line above the transport system in the `Height Zo (mm)` field. This switching limit allows objects with lower heights to be suppressed. The height of the detection line should be at least 50 mm and at most 200 mm.

6.2.3 Setting velocity parameters

Speed parameters are set in the `Velocity` section.

1. Enter the transport speed in the `Conveyor velocity (cm/min)` field. The value is required if no shaft encoder is used.
2. Select whether a shaft encoder or a constant speed is to be used in the `Incremental encoder` field (the `Peripherals` section).
3. Enter shaft encoder resolution in the `1/1000 mm per increment` field. The value is required if a shaft encoder is used. E.g., a `1000` entry means 1 mm/Incr.

6.2.4 Setting process control parameters

Parameters for process control are selected from pull-down menus in the `Process` section.

- Selection in the `Send parcel data` field is about whether the data is to be transmitted automatically at the end of every measurement and calculation (entry: `End of parcel`) or whether only the values for the last object are to be sent in response to a host request (entry: `Host`). A host telegram can call up the last measurement data repeatedly.
- Selection in the `Trigger source` field is about whether the start of a measurement should be triggered automatically (entry: `Automatic`), after a brief switching of the VMC 100 (entry: `Digital Output`), or after a host request (entry: `Host`). The `Digital Output` entry: by switching two different digital switches on the VMC 100 decisions can be made on when pallet height is to be taken into account for each object. The flanks of the switching signal must fall at least 20 ms before the object crosses the measurement line. The `Host` entry: the entire telegram must be received by the VMS 100 at least 20 ms before the object crosses the measurement line.
- A pallet height can be entered in the `Spacer height` field. The entry is only active with the `Digital Output` setting.
- The entry in the `Scans sample` field defines whether all the scans are to be used for determining volume. With the default setting `All scan` the maximum object length is 1500 mm at speeds of from 0.5 m/s to 2 m/s. *Table 6-1* shows the possible maximum object lengths and speeds.

	At speeds of 0.5 m/s to 2 m/s:		At maximum object lengths of 1500 mm:
Entry in 'Scans sample' field	Max. object length	Entry in 'Scans sample' field	Speed
All scan	1500 mm	All scan	0.50 m/s to 2.0 m/s
1/2	3000 mm	½	0.25 m/s to 0.5 m/s
1/3	4500 mm	1/3	0.20 m/s to 0.25 m/s
1/4	6000 mm	¼	0.15 m/s to 0.25 m/s
1/5	7500 mm	1/5	0.10 m/s to 0.15 m/s

Table 6-1: Setting parameters for maximum detectable object lengths and possible speed ranges.

- If `No` is entered in the `Length always > Width` field it defines that the length along the direction of transport is provided. If `Yes` is entered, the length value provided is the length of the longest side of the object.
- Height output can be modified in the `Height = Height max` field. An entry of `No` provides the most accurate value for the height of the rectangular object. An entry of `Yes` can be selected to take the maxi-

VMS 100

imum height value more into account at speeds of less than 0.5 m/s, which can result in the values provided being less accurate.

6.2.5 Setting optional device parameters

The VMS 100 Commissioning Software is informed about the optional connectable devices in the `Peripherals` section.

- If a bar-code reader is connected to the RS-485 interface of the VMC 100 as an auxiliary device it must be defined in the `Barcode reader` field (entry of `No` if no bar-code reader is connected). The following time window is available for receiving bar-code telegrams: the telegram starts no earlier than 20 ms after the object has crossed the measurement line, the telegram ends no later than 20 ms after the object has left the measurement line.
- The `Weighter type` field is used to define whether one of the selectable weighing machines is connected to the RS-485 interface of the VMC 100 as an auxiliary device (the entry `No Weighter` is used when no scales are connected). This auxiliary device is contacted after the end of the object. Connection should be carried out by SICK Service.
- The `Increm. encoder` field is used to define whether a shaft encoder is used: `No` = no shaft encoder, `Yes` = operation with a shaft encoder.
- The `Photocell` field can be used to register an optional photoelectric switch at the VMS 100. Such a photoelectric switch should be installed perpendicular to the direction of transport directly above the measurement line of the LMS 200.

6.2.6 Data transfer

The handling of parameterisation data is defined in the `Controls` section.

- The `Get values` button inserts the parameterisation data available in the VMC 100 into the menu window. Data previously entered in the menu window are deleted.
- The `Default values` button provides the fixed standard parameterisation data. These provide guidelines for a standard application. Data previously entered in the menu window are deleted.
- The `Send values` buttons transmits the data visible in the menu window to the VMC 100. Data previously available in the VMC 100 are deleted.
- The `Exit` button closes the menu window without triggering any data transfer.

6.3 Output of measurement data on the screen

VMS 100 measurement values can be received on the PC in real time after starting the VMS 100 Commissioning Software. This display is useful for testing the parameterisation – the display is not suitable for normal measurement operation. Click on the `See Values` entry in the sub-menu `VMS 100` of the `File` menu. The `Volume Measurement System 100` menu window appears. The menu window shows the measurement data and two buttons.

Under `Volume Measurement` there is:

- the `Length` field showing the length of the object,
- the `Width` field with the width of the object, and
- the `Height` field showing object height.

Furthermore, the results of any optional connectable devices are also displayed if available:

- the `Weight` field may show the weight of the object,
- the `Barcode` field may show the bar-code on the object. Display is limited to 15 characters.

As regards the buttons:

- The `Test Request` button transmits a telegram for measurement readiness.
- The `Exit` button closes the window.




Fig. 6-3: Display of measurement data, an example after a restart.

6.4 Completion and test measurements

- Log all the parameters in the commissioning log and save the document somewhere safe.

Customers should select a typical measurement object for the test measurements, selecting the following properties:

- typical object surface material
 - typical object surface colour
 - typical object size
- Carry out several measurements with the object.
Measure the object precisely with a measuring tape or metre-rule and note the values for its length, width and height, and compare them with the VMS 100 measurement values.
 - If necessary, reset the parameters.
The output of the object dimension along the direction of transport can be optimised with the parameters `Conveyor velocity` or `1/1000 mm per increment`. The `LMS/conveyor position` parameter affects the output of the height and the object dimension across the direction of transport of the object. Angle α must be carefully adjusted for a correct output of height readings. The LMS 200 angle γ can be re-adjusted to optimise object dimension values across the direction of transport.

Recommendation:

Parameterise and adjust the VMS 200 carefully to achieve high accuracies.

VMS 100

7 Maintenance

7.1 Maintenance during operation

To retain maximum performance the LMS 200 Laser Measurement System needs a clean front window (reading window). A weekly front window contamination check is recommended in harsh operating environments (dust, grindings, damp, etc.), in particular. More frequent checks may be required depending on the conditions. Clean the LMS 200 housing every six months to ensure sufficient cooling.

Contamination indicator:

Depending on the degree of front window contamination the LMS 200 provides the following warnings by means of the yellow LED (middle) and red LED (left):

LED behaviour	Meaning
Yellow LED blinks at rate of 1 Hz, 50% on and 50% off	Warning: weak contamination. The LMS 200 can still be used in this condition.
Yellow LED blinks at rate of 1 Hz, 90% on and 10% off. The red LED is continuously lit	Contamination error: strong contamination. The LMS 200 is no longer capable of operation.

Table 7-1: LMS 200: LED error indicators on contamination of the front window.

Depending on the degree of front window contamination the VMC 100 also issues the following warning by means of the "MODE" LED:

"MODE" LED behaviour	Meaning
Green / red blinking	Warning (weak contamination). Measurement Mode still active.
Red blinking	Error (strong contamination). The VMC 100 is no longer capable of operation.

Table 7-2: VMC 100: LED error indicators on contamination of the LMS front window.

Cleaning the front window of the LMS 200:



ATTENTION

Damage to the front window!

The front window is made of plastic. System performance can be reduced as a result of scratches and streaks on the front window.

- Use mild detergent without any powder.
- Avoid scratching and scouring movements.

- Clean the front window at regular intervals, e.g. with an anti-static glass cleaning liquid. Use a soft, non-fluffy cloth for cleaning.
- If necessary also clean the LED indicators of the LMS 200 and the front panel of the VMC 100.

7.2 Maintenance

The VMS 100 operates without the need for maintenance. Any errors that crop up are reported by the system via the "MODE" LED on the front panel of the VMC 100 and by the output of the device status, separately for the LMS 200 and the VMC 100, in the measurement results. See also *Table 7-2* and *Chapter 3.3.2 Functions of the LED indicators*.

Test measurement:

A test measurement every month is recommended with a typical rectangular reference object with known dimensions.

- Measure the object several times with the VMS 100 and compare the values received with the known object dimensions.

7.3 Disposal

Dispose of unusable or irreparable devices in an environmentally friendly manner after a final decommissioning:

1. Follow valid local waste disposal regulations.
2. Dismantle the housing.
3. Dismantle the electronic assemblies.
4. Remove the front window (LMS 200) and dispose of it for plastic recycling.
5. Remove the chassis and dispose of it for aluminium die cast recycling.
6. Dispose of the electronic assemblies as special waste.
7. Dispose of cable wiring for metal recycling

SICK AG does not currently accept the return of devices that are unusable or irreparable.

VMS 100

8 Troubleshooting

8.1 Overview of possible faults and problems

8.1.1 Mounting error

- The LMS 200 is not well aligned upon the object on the transport system
- The shaft encoder (optional) is wrongly sited

8.1.2 Error in the electrical installation

- VMC 100 data interface (COM connection) wrongly wired
- Bad connection between LMS 200 and VMC 100

8.1.3 Parameterisation error

- Functions not adapted to the conditions on site
- Trigger source wrongly selected
- Technical device limits not taken sufficiently into account

8.1.4 Operating difficulties

- Object gap too small
- Device fault (hardware/software)

8.2 Monitoring signs of faults and problems

The VMS 100 monitors itself during operation:

- After switching on the power supply the VMS 100 carries out a self-test before initialisation (loading of the parameter set and initialisation of the device functions) involving the testing of important hardware components.
- If the VMS 100 discovers a device fault during the self-test or during self-monitoring, the VMC 100 gives out appropriate numerical values in the measurement result output telegram for VMC 100 status and LMS 200 device status in a coded form.
See Chapter 10.2.2 VMC 100 status and 10.2.3 LMS 200 device status.
- The red and yellow LEDs of the LMS 200 and the "Mode" LED of the VMC 100 signal the system's error state.
See Chapter 3.3.2 Functions of the LED indicators.

8.3 Identifying faults and remedying them

The following aids are necessary for remedying the faults described in the table below:

- these Operating Instructions
- tools
- a measuring tape (up to 2000 mm)
- a digital measurement device (current / voltage measurements)
- a PC with VMS 100 Commissioning Software
- RS-232 data connection cable, e.g. order no. 2 016 401

Problem	Possible cause	Remedial action
VMC 100: "power" LED does not light	VMS 100 has no power supply	- Check the cables - Measure power supply
VMC 100: "mode" LED blinks first green and then red/green	Bad connection to LMS 200	Check cables
VMC 100: "mode" LED blinks red/green	The system is issuing a warning: e.g. LMS 200 front window contaminated	Check the values for VMC 100 status and LMS 200 device status in the measurement results using the PC. See <i>Chapter 10.2.2 VMC 100 status and 10.2.3 LMS 200 device status</i>
VMC 100: "mode" LED blinks red	Device fault	Run Diagnostics with software
LMS 200: yellow LED blinks at rate of 1Hz (50% on and 50% off)	LMS 200 front window slightly contaminated. VMS 100 still ready for operation	Clean LMS 200 front window. See <i>Chapter 7.1 Maintenance during operation</i>
LMS 200: yellow LED blinks at rate of 1Hz (90% on and 10% off). Red LED lit constantly	LMS 200 front window strongly contaminated. VMS 100 not ready for operation	Clean LMS 200 front window. See <i>Chapter 7.1 Maintenance during operation</i>
Higher-ranking computer cannot receive measurement results	- VMC 100 data interface wrongly wired - Destination computer interface not adapted	- Check wiring - Set communication parameters correctly
Object is not detected	- Parameter value "Height above transport system" selected too high - Trigger source wrongly selected - Problem with connection to LMS 200	- Enter the correct value - Select the right trigger source - Check connection
Measurement result: data given out contains 9999, 9999, 9999	Detection zone too large	Adapt detection zone
Measurement result: data incorrect	Object gap too small	- Correct measurement area - Increase object gap
Measurement result: dimension at right angles to direction of transport too small	Parameter values for measurement area "left & right limits" too small	Increase parameter values
Measurement result: object height too small/large	Parameter value "height" is too large/small	Correct the value
Measurement result: dimension of object along direction of transport is too small/large	Parameter value "speed" or "increments/mm" is too large/small	Correct the value
Measurement result: object length is always zero	Incr. encoder option is activated, but no signal available	Deactivate Incr. encoder option or connect shaft encoder

Table 8-1: Troubleshooting table.

VMS 100

8.4 SICK Support

If a fault cannot be remedied by any of the above-mentioned measures, the VMS 100 may be defective. The system does not contain any components whose functionality can be restored by the user repairing them after a breakdown.

Please contact your local SICK office or subsidiary:

- The telephone and fax numbers are listed on the *back page* of these Operating Instructions.
- Please do not send in the device without contacting SICK Service.

9 Technical data

9.1 Data sheet for the VMS 100 Volume Measurement System

Type	VMS 100
Read window (LMS 200-30106)	plastic, semi-circular
Laser diode	IR light, 905 nm
Laser protection class (LMS 200-30106)	1 (eye-safe), acc. to DIN EN 60825-1
Usable slit angle	max. 180°
Detectable object shape	rectangles
Min. object dimensions (L x B x H)	200 mm x 200 mm x 100 mm
Max. length x width x height	7500 mm x 1500 mm x 1500 mm
Min. object gap	typ. > 100 ms
Transport velocity	0.1 ... 2 m/s, constant or variable (shaft encoder required)
Typ. accuracy (L, W, H) up to 1 m/s up to 2 m/s	with min. object size of 200 mm x 200 mm x 200 mm: ±15 mm, ±15 mm, ±15 mm ±25 mm, ±20 mm, ±20 mm
Optical indicators	LMS 200: 3 LEDs, VMC 100: 2 LEDs
Data interface COM (VMC 100)	RS-232 or RS-422 (configurable)
Communication parameter	9600 bits/s, 8 data bits, no parity, 1 stop bit
Output data	length, width, height, optional: e.g. bar-code when bar-code scanner connected
Data interface BUS (VMC 100)	RS-485
Communication parameter	9600 bits/s, 8 data bits, no parity, 1 stop bit
Functional switching inputs	4 x digital DC 24 V, 2 x shaft encoder 24V / 100 max. KHz
Functional switching outputs	3 x digital DC 24 V
Electrical connections (VMC 100)	7 connection strips, 1 x 9-pin D-sub socket, 1 x 15-pin D-sub HD socket
Operating voltage/power consumption	VMC 100-0000: DC 24 ±15% / 56 W total VMC 100-0100: AC 230 V -15%/+10% / 50 Hz
Housing	LMS 200-30106: die-cast aluminium; VMC 100-0000: aluminium continuous cast profile, -0100: lacquered sheet steel, PC window
Protection class	LMS 200-30106: Class 2/ VMC 100-0000: Class 2, acc. to DIN 40 050
Enclosure rating (acc. to VDE 0106/IEC 1010-1)	LMS 200-30106: IP 65 VMC 100-0000: IP 20, acc. to VDE 0106/IEC 1010-1, VMC 100-0100: IP 65
EMC test	acc. to IEC 801, Part 2-4; EN 50081-1/50082-2
Vibration/shock tests	LMS 200-30106: acc. to IEC 68-2-6, Tab. 2c/ IEC 68-2-27, Tab. 2 VMC 100-0000: acc. to DIN EN 60068-2-6/ DIN EN 60068-2-27 VMC 100-0100: acc. to DIN EN 60068-2-6 Test FC/ DIN EN 60068-2-27 Test EA
Weight	LMS 200-30106: ca. 4.5 kg, VMC 100-0000: ca. 1.7 kg, VMC 100-0100: ca. 11 kg
Temperature (operating/storage)	LMS 200-30106: 0 ... +50 °C/ -30 ... +70 °C VMC 100-0000: 0 ... +50 °C/ -20 ... +70 °C, 0100: 0 ... +50 °C/ -25 ... +70 °C

Table 9-1: Technical specifications for the VMS 100.

9.2.2 VMC 100-0000 evaluation unit dimensional drawing




Fig. 9-2: Dimensions of the VMC 100-0000 evaluation unit

VMS 100

9.2.3 View of Mounting Set for LMS 200-30106




Fig. 9-3: Structure of Mounting Set no. 2 020 925

9.2.4 View of VMC 100-0100




Fig. 9-4: Dimensions of the VMC 100-0100 evaluation unit.

VMS 100

10 Appendix

10.1 Overview of the Appendix

The appendix contains the following supplements and auxiliary information:

- Telegram structure
- System or component replacement
- Available accessories (order details)
- Information on supplementary documentation
- The EU Declaration of Conformity
- Index

10.2 Telegram structure

10.2.1 Telegram format

The telegram given out by the VMC 100 as the measurement result via its COM data interface, is composed as follows in *Tab. 10-1* from the top downwards:

Description	Bytes	Meaning
Header	8	Header, beginning with ST
Object length in mm	4	ASCII data
Separator	1	09(hex)
Object width in mm	4	ASCII data
Separator	1	09(hex)
Object height in mm	4	ASCII data
Separator	1	09(hex)
Object weight in kg	4	ASCII data
Separator	1	09(hex)
Bar-code length	2	ASCII data
Separator	1	09(hex)
Bar code	n	ASCII data
Separator	1	09(hex)
Device status	1	he
VMC 100 status	1	he
Checksum	2	CRC 16

Table 10-1: Telegram format at the COM data interface (VMC 100).

The VMS 100 can receive an external telegram during Measurement Mode and integrate it in the output telegram. The entire external telegram must be received by the VMC 100 during the measurement of the object. A measurement is active while an object is on the measurement line.

The structure of a telegram that can be sent from an auxiliary device to the RS-485 interface of the VMS 100, is defined as follows:

Description	Bytes	Meaning
Start characters	1	STX
Number of characters in bar code	2	Separator, CL code length, before code (trigger for digital in: flank high)
Bar code		Length depending on application
Block check (BCC)		Block check, XOR linkage via all preceding characters (hex-ASCII format)
End characters	1	ETX

Table 10-2: Structure of external telegrams.

10.2.2 VMC 100 status

The VMC 100 device status transferred in the telegram has the following meaning:

Code	Meaning
0	Normal Measurement Mode
1	Warning: LMS window contaminated
2	Problem LMS 200
3	Problem bar-code scanner
4	Problem weighing machine

Table 10-3: Output telegram: meaning of the VMC 100 status.

10.2.3 LMS 200 device status

In the LMS 200 status byte information is provided bit-wise.

Bit	Meaning
0 - 2	Classification: 0 = Normal Measurement Mode 1 = Information 2 = Warning 3 = Error 4 = Fatal error
3 - 4	Cause: 0 = Software VMC 100 1 = Software VMS 100 2 = LMS 200 3 = Not used (reserved)
5	Contamination: 0 = None 1 = Contamination of LMS window
6 - 7	Not used (reserved)

Table 10-4: Output telegram: meaning of the LMS 200 device status.

VMS 100

Triggering measurement readiness with a telegram from the host:

If the system is in "Limited measurement readiness" mode (`Request`) measurement readiness is activated by the following telegram to the VMC 100: 02 00 08 00 7D 74 08 06 C0 01 00 07 8F 56

See also the `Test Request` button in *Fig. 6-3* in *Chapter 6.3 Output of measurement data on the screen*.

The telegram shown above is sent to the VMC 100 by pressing this button.

Request for measurement values with telegram from host

The measurement values of the VMS 100 can be requested with the following telegram:

02 00 08 00 7D 74 08 06 C0 01 00 02 8A 56. The telegram can be sent to the VMS 100 several times for repeated requests.

10.2.4 Replacing a system or components

Proceed as follows if the system or individual components need replacement:

LMS 200:

1. Switch off VMC 100 power supply.
2. Loosen and remove the plug modules of both connection cables on the LMS 200.
3. Loosen and remove the Mounting Set screws on the LMS 200 and remove the device.
4. Mount and connect the replacement device appropriately.
5. Switch on the VMC 100 power supply.
6. Connect PC to the VMC 100 "COM" connection via the data cable and start up PC.
7. Start the VMS 100 Commissioning Software and completely reset the system parameters as described in *Chapter 6*.

This ensures that a high level of measurement accuracy is also achieved with the new LMS 200.

VMC 100:

1. Note all the parameters with the help of the Commissioning Software.
2. Switch off the VMC 100 power supply.
3. Remove all connection cables on the VMC 100.
4. Disassemble the VMC 100. Unscrew the VMC 100-0000 with its wall bracket from the base or unclip the VMC 100-0000 from the mounting rail. Or remove the VMC 100-0100 from the attachment equipment.
5. If necessary remove the VMC 100 from the wall bracket.
6. Mount the new device. First screw the new VMC 100-0000 onto the wall bracket and then together with it onto the base, or snap the device onto the mounting rail. Or mount the VMC-0100 onto the attachment equipment.
7. Re-attach all the connection cables to the VMC 100.
8. Switch on the VMC 100 power supply.
9. Connect the PC to the VMC 100 COM connection via the data cable and start the PC up.
10. Start the VMS 100 Commissioning Software and enter the parameters that were noted before with the parameterisation software or completely reset the system parameters as described in *Chapter 6*.

See *Chapter 7.3 Disposal* for disposal of unusable or irreparable devices.

10.3 Available accessories (order details)

10.3.1 The complete VMS 100 systems

Order no.	Description
1 022 987	<p>The complete VMS 100-0000 system, consisting of:</p> <ul style="list-style-type: none"> - 1 LMS 200-30106 Laser Measurement System - 1 Connection Set 2 for the LMS 200: 2 cables for electrical supply and data transfer, each 10 m long, with one connection plug module each for the LMS 200 - 1 Mounting Set, two-axis, fine adjustment - 1 VMC 100-0000 evaluation unit with installed VMS 100 Evaluation Software, for clip-on mounting rail, with a mounting set for wall mounting - 1 diskette (3½ inch) with VMS 100 Commissioning Software for Windows-NT/Windows 95

Table 10-5: Order details: the complete VMS 100 system.

Also available on request as a device version, with VMC 100-0100 in an IP 65 protective cabinet with power supply.

10.3.2 Accessories

Optional accessories for operation:

Order no.	Description
On request	Photoelectric switch
On request	Shaft encoder, resolution min. 1 mm
On request	Bar-code scanner
On request	Power supply unit
On request	Adapter for connection to Bus systems
2 019 522	Heating plate for LMS 200 for operation between -12°C ...+50°C, though no LMS operation outdoors 230 VAC ± 10 %, 30 W (cyclic, thermostat-controlled), IP 65

Table 10-6: Order details: optional accessories for operation.

Accessories for commissioning:

Order no.	Description
2 016 401	Data cable for connection of PC/Laptop to VMC 100, with 2 x 9-pin D-sub plugs, length 3 m (RS-232 male/female-crossed)
6 020 756	Scan finder

Table 10-7: Order details: optional accessories for commissioning.

VMS 100

10.3.3 View of the accessories

Heating plate




Fig. 10-1: Structure and electrical connection of the heating plate no. 2 019 522

10.4 Supplementary documentation

Order no.	Title
8 008 969	Technical Description "LMS 210 ... 290", German
8 008 970	Technical Description "LMS 210 ... 290", English
8 008 871	Technical Description "LMI 200", German
8 008 872	Technical Description "LMI 200", English
8 008 930	Operating Instructions "LMI 200 User Software", German
8 008 931	Operating Instructions "LMI 200 User Software", English
8 008 929	Technical Description "MST 200 - LMI 200 version", German/English

Table 10-8: Supplementary documentation.

10.5 The EU Declaration of Conformity

10.5.1 The LMS 200 EU Declaration of Conformity

SICK

EC Declaration of Conformity

In Compliance with the EC Directive on Electromagnetic Compatibility 89/336/EEC

We hereby declare that the devices (see page 2)

of the product family LMS2..-.....

comply with the basic requirements of the EC Directive specified under Point 1. If an item of equipment listed overleaf is modified without our approval then this declaration loses its validity for this equipment.

We employ a quality system certified by the DQS (German Quality Assurance Society), No. 19 462-01, as per ISO 9001 and have therefore observed the regulations in accordance with module H as well as the following EC directives and EN standards during development and production:

1. EC directives	EC EMC directive 89/336/EEC as per 92/31/EEC, 93/68/EEC, 93/465/EEC		
2. Harmonized standards and preliminary standards used	EN 50081-1	Emitted interference, residential commercial and light industry	Ed. 92-01
	EN 50082-2	Immunity, industry	Ed. 95-03

Conformance of a type sample belonging to the above-mentioned product family with the regulations from the listed EC directives has been certified by:

Test authority } The tests were carried out and documented on our own responsibility.

Reute, 1998-08-16

 i. V. Pierenkemper (Manager Development Division Auto Ident)	 i. V. Walter (Manager Production Division Auto Ident)
--	--

The declaration certifies conformance with the listed directives, but does not guarantee product characteristics.
The safety instructions contained in the product documentation must be observed.

Mat. No.: 9 055 675
Page 3, engl.
Update no.: see page 2

SICK AG
Nimburger Str. 11
D-79276 Reute

Telefon (0 7641) 469-0
Telefax (0 76 41) 469-149

Aufsichtsratsvorsitzender:
Dr. Horst Skoludek
Vorstand:
Volker Reiche (Vors.)
Anne-Kathrin Deutrich
Dieter Fischer

Sitz: Waldkirch i.Br.
Handelsregister
Emmendingen HRB 355 W

S VMS 100 440 104597 BR - 15A
E 110500

Fig. 10-2: The EU Declaration of Conformity for the LMS 200, Page 3 (reduced in size).

VMS 100

The EC Declaration of Conformity No. 9055675 is valid for the following types of the product family LMS:

Type	Id.-No.
LMS200-30106	1015850
LMS210-20201	1013859
LMS210-20202	1013856
LMS210-20204	1013860
LMS210-30206	1017812
LMS211-20201	1013853
LMS211-20202	1013854
LMS211-20204	1013855
LMS211-30206	1018023
LMS220-20203	1013865
LMS220-30106	1015945
LMS220-30206	1017811
LMS221-20203	1015833
LMS221-30206	1018022
LMS290-S01	1016024
LMS291-S01	1016078
LMS209-S02	1016414
LMS299-S03	1016829
LMS200-S04	1016828
LMS290-S05	1018027
LMS291-S05	1018028
LMS219-S06	1018761
LMS229-S06	1018764
LMS211-S07	1018966
LMS221-S07	1018965

end of list -

SICK AG
Nimburger Str. 11
D-79276 Reute

Telefon (0 7641) 469-0
Telefax (0 76 41) 469-149

Aufsichtsratsvorsitzender:
Dr. Horst Skoludek
Vorstand:
Volker Reiche (Vors.)
Anne-Kathrin Deutrich
Dieter Fischer

Mat.-No.: 9 055 675
Page 2
Update no.: K438

Sitz: Waldkirch i.Br.
Handelsregister
Emmendingen HRB 355 W

Fig. 10-3: The EU Declaration of Conformity for the LMS 200, Page 2 (reduced in size).

10.5.2 The VMC 100 EU Declaration of Conformit

SICK

EC Declaration of Conformity

In Compliance with the EC Directive on Electromagnetic Compatibility 89/336/EWG

We hereby declare that the devices (see page 2)

of the product family VMC100

comply with the basic requirements of the EC Directive specified under Point 1. If an item of equipment listed overleaf is modified without our approval then this declaration loses its validity for this equipment.



We employ a quality system certified by the DQS (German Quality Assurance Society), No. 462, as per ISO 9001 and have therefore observed the regulations in accordance with module H as well as the following EC directives and EN standards during development and production:

1. EC directives	EC EMC Directive 89/336/EEC as per 92/31/EEC, 93/68/EEC, 93/465/EEC		
2. Harmonized standards used	EN 55011	Emitted interference, industry	Ed. 98-05
	EN 61000-6-2	Immunity, industry	Ed. 00-03

Conformance of a type sample belonging to the above-mentioned product family with the regulations from the listed EC directives has been certified by:

The tests were carried out and documented on our own responsibility.

Reute, den 2001-11-07

 ppa. Pierenkemper (Manager Development Division Auto Ident)	 ppa. Walter (Manager Production Division Auto Ident)
--	--

The declaration certifies conformance with the listed directives, but does not guarantee product characteristics. The safety instructions contained in the product documentation must be observed.

Mat. No.: 9 066 207
Page 3
Update no.: see page 2

SICK AG • Nimburger Str. 11 • D-79276 Reute • Telefon 0 76 41- 4 69-0 • Telefax 0 76 41- 4 69-11 49 • www.sick.de
 Aufsichtsrat: Gisela Sick (Ehrevorsitzende) • Dr. Horst Skoludek (Vorsitzender)
 Vorstand: Volker Reiche (Vorsitzender) • Dr. Robert Bauer • Anne-Kathrin Deutrich • Dieter Fischer • Walter Schmitz (Stellvertr.)
 Sitz: Waldkirch i. Br. • Handelsregister: Emmendingen HRB 355 W

8 008 410/0/99 BK-BK II - 19896

Fig. 10-4: The EU Declaration of Conformity for the VMC 100, Page 3 (reduced in size).

VMS 100

SICK

Type	Id.-No.
VMC100-0100	1022172
VMC100-0000	1022163

- end of list -

Mat. No.: 9 066 207
Page 2
Update no.: AE 0

SICK AG • Nimburger Str. 11 • D-79276 Reute • Telefon 0 76 41- 4 69-0 • Telefax 0 76 41- 4 69-11 49 • www.sick.de
Aufsichtsrat: Gisela Sick (Ehrenvorsitzende) • Dr. Horst Skoludek (Vorsitzender)
Vorstand: Volker Reiche (Vorsitzender) • Dr. Robert Bauer • Anne-Kathrin Deutrich • Dieter Fischer • Walter Schmitz (Stellvertr.)
Sitz: Weidkirch i. Br. • Handelsregister: Emmendingen HRB 356 W

Fig. 10-5: The EU Declaration of Conformity for the VMC 100, Page 2 (reduced in size).

10.6 Commissioning log

Prepared by:

Date:

Parameter	Unit	Value / entry
LMS/conveyor position		
Left conveyor	mm	
Right conveyor	mm	
Height LMS/conveyor	mm	
Zone of detection		
Left	mm	
Right	mm	
Height zone/conveyor	mm	
Velocity		
Conveyor velocity	cm/min	
1/1000 mm per incr.		
Process		
Send parcel data	-	
Trigger source	-	
Spacer height	mm	
Scans sample	-	
Length always > Width	-	
Height = max height	-	
Peripherals		
Barcode reader	-	
Weighter Type	-	
Increm. encoder	-	
Photocell	-	

VMS 100

10.7 Index

Baud rate	31
Data bits.....	31
Dimensional drawing for Mounting Set	24
Distance between objects.....	20
Frame.....	23
Laser Measurement System	6
Laser Measurement Interface	16
Length	19, 39
LMS 200-30106	15, 52
Measurement readiness	18
Measurement Software Tool	14
Mounting, requirements for	21
Object height.....	20
Object length.....	20
Object width	20
Output	15, 17
Parity.....	31
Plumblines	36
Reflectivity	20
Scanfinder.....	23
Shaft encoder signal.....	21
Space requirement	20
Stop bit.....	31
Time between objects.....	20
Transport speed.....	20
Transport system.....	20
VMC 100.....	16, 52

Australia

Phone +61 3 9497 4100
(0 8) 33 48 02-toll free
Fax +61 3 9497 1187

Austria

Phone +43 22 36/62 28 8-0
Fax +43 22 36/62 28 85

Belgium/Luxembourg

Phone +32 24 66 55 66
Fax +32 24 63 31 04

Laser Measurement Systems:

Phone +32 9 2240 394
Fax +32 9 2235 645

Brazil

Phone +55 11 5561 2683
Fax +55 11 5535 4153

China

Phone +85 2 2763 6966
Fax +85 2 2763 6311

Czech Republic

Phone +42 02-579 11 850
+42 02-578 10 561
Fax +42 02-578 10 559

Denmark

Phone +45 45 82 64 00
Fax +45 45 82 64 01

Finland

Phone +358 9-728 85 00
Fax +358 9-72 88 50 55

France

Phone +33 1 64 62 35 00
Fax +33 1 64 62 35 77

Germany

Phone (+49 2 11) 53 01-0
Fax (+49 2 11) 53 01-1 00

Great Britain

Phone +44 17 27-83 11 21
Fax +44 17 27-85 67 67

Italy

Phone +39 02-92 14 20 62
Fax +39 02-92 14 20 67

Japan

Phone +81 3 3358 1341
Fax +81 3 3358 0586

Netherlands

Phone +31 30 229 25 44
Fax +31 30 229 39 94

Laser Measurement Systems:

Phone +31 73 599 50 44
Fax +31 73 599 47 18

Norway

Phone +47 67 56 7500
Fax +47 67 56 6100

Poland

Phone +48 22 837 40 50
Fax +48 22 837 43 88

Singapore

Phone +65 744 3732
Fax +65 841 7747

Spain

Phone +34 93 4 80 31 00
Fax +34 93 4 73 44 69

Sweden

Phone +46 8-680 64 50
Fax +46 8-710 18 75

Switzerland

Phone +41 41 61 92 93 9
Fax +41 41 61 92 92 1

Taiwan

Phone +886 2 2365-6292
Fax +886 2 2368-7397

USA

Phone +1(952) 941-6780
Fax +1(952) 941-9287

Representatives and agencies in all major industrial countries.

SICK