



# SICK

8016392

## Betriebsanleitung, Ergänzung DEUTSCH

Bitte lesen Sie die beiliegende Betriebsanleitung und diese Betriebsanleitungsergänzung sorgfältig durch.

### Ergänzung/Abweichung der technischen Daten zur Betriebsanleitung WT18-3:

**Typ: WT18-3P430S33**

**Artikelnr.: 1044259**

Funktionsprinzip	Vordergrundaussblendung
Tastweite	50 ... 350 mm / 90%

#### Einstellhinweise:

Lichtfleck auf Hintergrundobjekt ausrichten. Potentiometer im Uhrzeigersinn drehen bis gelbe Anzeige-LED aufleuchtet, Schaltausgang Q schaltet EIN. Detektionsobjekt im Lichtstrahl positionieren → gelbe Anzeige-LED erlischt, Schaltausgang Q schaltet AUS.

Irrtümer und Änderungen vorbehalten

SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)

## Operating Instruction, Supplement ENGLISH

Please read the enclosed operating instruction and this operating instruction supplement carefully.

### Supplement/deviation of technical data of the operating instructions WT18-3:

**Model Name: WT18-3P430S33**

**Part No.: 1044259**

Functional principal	Foreground suppression
Scanning range	50 ... 350 mm / 90%

#### Scanning range setting:

Align light spot onto the background object. Turn potentiometer clockwise until yellow indicator LED switches on, switching output Q switches ON. Position the detection object into the light beam → yellow indicator LED switches off, switching output Q switches OFF.

Subject to change without notice

SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)