



SICK

8024141

Betriebsanleitung, Ergänzung DEUTSCH

Bitte lesen Sie die Online-Betriebsanleitung des Sensors WTT2SLC-2P3292B02 und diese Betriebsanleitungsergänzung sorgfältig durch.

Ergänzung/Abweichung der technischen Daten zur Betriebsanleitung WTT2SL(C), 8021879:

Typ: WTT2SLC-2P3292B02

Artikelnr.: 1101641

IO-Link Voreinstellung

- Tastweite QL1, SP1 voreingestellt auf 350 mm
- Pin 2 deaktiviert (Index 121, Wert = 0)
- Inverter 1 aktiv (Index 1089, Wert = 1)
- Voreinstellung geht bei Factory Reset verloren

Operating Instruction, Supplement ENGLISH

Please read the online operating instruction for the sensor WTT2SLC-2P3292B02 and this operating instruction supplement carefully.

Supplement/deviation of technical data of the operating instructions WTT2SL(C), 8021879:

Model Name: WTT2SLC-2P3292B02

Part No.: 1101641

IO-Link Presetting

- Sensing range QL1, SP1 preset to 350 mm
- Pin 2 deactivated (Index 121, Value = 0)
- Inverter 1 active (Index 1089, Value = 1)
- Presetting gets lost upon factory reset