



# SICK

8025197

## Betriebsanleitung, Ergänzung DEUTSCH

Bitte lesen Sie die beiliegende Betriebsanleitung und diese Betriebsanleitungsergänzung sorgfältig durch.

### Ergänzung/Abweichung der technischen Daten zur Betriebsanleitung MLG-2 PRO, 8016616:

**Typ: MLG20A-0140R1S108**

**Artikelnr.: 1109052**

Sonderausführung mit folgender Voreinstellung:

- Q1: Ausgang, !NBB $\geq$ 1
- Q2: Keine Funktion
- Q3: Keine Funktion
- Q4: Keine Funktion
- Automatischer Teach-In aktiv
- VMA  $\geq$  3 Strahlen (VMA-Schwelle 62%)
- Um MLG-1 Kompatibilität zu erreichen werden folgende Adapter benötigt:
  - Empfänger: 6057013
  - Sender: 6057015

Irrtümer und Änderungen vorbehalten

SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)

## Operating Instruction, Supplement ENGLISH

Please read the enclosed operating instruction and this operating instruction supplement carefully.

### Supplement/deviation of technical data of the operating instructions MLG-2 PRO, 8017460:

**Model Name: MLG20A-0140R1S108**

**Part No.: 1109052**

Special version with the following default settings:

- Q1: Output, !NBB $\geq$ 1
- Q2: No Function
- Q3: No Function
- Q4: No Function
- Auto Teach-In active
- VMA  $\geq$  3 beams (VMA threshold 62%)
- For MLG-1 compatibility, the following adapters are required:
  - Receiver: 6057013
  - Transmitter: 6057015

Subject to change without notice.

SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)