



# SICK

8019095

## Betriebsanleitung, Ergänzung DEUTSCH

Bitte lesen Sie die beiliegende Betriebsanleitung und diese Betriebsanleitungsergänzung sorgfältig durch.

### Ergänzung/Abweichung der technischen Daten zur Betriebsanleitung WSE100-2, 8017528:

**Typ: WS100-2D3030S03**

**Artikelnr.: 6060418**

Sendeeinheit (WS100-2) für Einwegsystem (WS/WE100-2),  
Infrarot Sende-LED  
kein Zubehör  
Testeingang auf Pin 4 zur De-/aktivierung der Sende-LED:  
Pin 4 nicht verbunden → Sende-LED aus  
Pin 4 verbunden mit High-Signal ( $\geq 19V$ ) → Sende-LED an  
Pin 4 verbunden mit Low-Signal ( $< 19V$ ) → Sende-LED aus  
Keine UL/UR-Zertifizierung

Irrtümer und Änderungen vorbehalten  
SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)

## Operating Instruction, Supplement ENGLISH

Please read the enclosed operating instruction and this operating instruction supplement carefully.

### Supplement/deviation of technical data of the operating instructions WSE100-2, 8017528:

**Model Name: WS100-2D3030S03**

**Part No.: 6060418**

Sender unit (WS100-2) for through-beam system (WS/WE100-2),  
infrared sender-LED  
no accessories  
test input on pin 4 for de-/activation of sender LED:  
pin 4 not connected → sender LED off  
pin 4 connected to high signal ( $\geq 19V$ ) → sender LED on  
pin 4 connected to low signal ( $< 19V$ ) → sender LED off  
No UL/UR-Certification

Subject to change without notice.  
SICK AG, D-79183 Waldkirch, Erwin-Sick-Str. 1, [www.sick.com](http://www.sick.com)